

FREQUENCY INVERTER

VFR-080

VFR-081

0.75kW TO 500kW

USER'S GUIDE



iNORéA

60, Route Principale du Port
92 230 Gennevilliers

Tel : +33(0)147994710

contact@inorea.com

www.inorea.com

Foreword

Thank you for purchasing VFR-080 and VFR-081 series Frequency Inverters. These series are designed based on the experience of INORÉA in the design and sale of inverters. They are suitable for general-purpose machine, fan/pump drive, medium frequency drive and heavy load machine.

The range adopts the advanced sensorless vector control technology to achieve high-performance V/F control, high-performance speed sensorless vector control and high-performance close loop vector control.

This User's Manual covers VFR-080/VFR-081, general purpose control and special purpose control.

The general purpose controls are F, G, M and H; the special purpose controls are S, T and Z:

- F:** FLOW LOAD
- G:** GENERAL LOAD
- M:** MIDDLE LOAD
- H:** HEAVY LOAD.
- S:** TEXDRIVE.
- T:** WINDLASS.
- Z:** JETDRIVE.

Please contact the local dealers or contact us directly.

Please keep this user's manual in good condition, as it will be helpful to program, diagnose your inverter.

For information about other product, please visit our website: <http://www.inorea.com>.

CONTENTS

Section I	Inspection & Safety Precautions.....	1
Section II	Installation & Standby Circuit	3
Section III	Operating Keyboard.....	14
Section IV	Test Running.....	22
Section V	Parameter Function Table	25
Section VI	Fault Diagnosis & Solutions	102
Section VII	Standard Specifications.....	104
Section VIII	Maintenance.....	119
Section IX	Options	121
Section X	Quality Assurance	125
Appendix I	RS485 Communication Protocol	126
Appendix II	Instruction of the Proportional Linkage Function	141
Appendix III	RS485 PG Card Instruction	144
Appendix IV	Converter Water Supply Controller Instruction	147

Section I. Inspection & Safety Precautions


INORÉA VFR-080 frequency inverters have been tested and inspected before leaving our production plant. Before unpacking the product, please check if the package is not damaged and if the specifications and type of the product complies with the order.

Please contact your local dealer should you have any question.


1-1. Inspection after Unpacking

- Inspect the contents: one inverter, one operation manual
- Check the nameplate on the side of the frequency inverter to ensure that the product you have received is correct.

1-1-1. Name plate



1-1-2. Model description :



Section I Inspection & Safety Precaution

1-2. Safety Precautions

- Never connect the A.C. power supply to the output terminals (U, V, W) of the frequency inverter.
- Fix and lock the panel before supplying power so as to avoid the danger caused by the poor capacity or other components inside the inverter.
- After the power supply is switched on, do not perform wiring or check, etc.
- Don't touch the circuit boards or its parts or components in the inverter when it is powered, so as to avoid danger of electric shock.
- If the power supply is switched off, do not touch the PCB or other parts inside the inverter within 5 minutes after the keyboard indicator lamp goes off, and you must check by using the instrument that the inverter has completely discharged all its capacity before you start to work inside the inverter. Otherwise, there will be the danger of electric shock.
- The static electricity in human body will cause serious damage to the MOS field effect transistor in the inverter. Please keep your hands away from the PCB, IGBT and other internal parts before taking actions to prevent static electricity. Otherwise, faults may be caused.
- In use, the earthing terminal (\perp) of the frequency inverter must be grounded to the earthing connections correctly and securely according to the national electrical safety specifications and other applicable standards.
- Please don't shut off the unit by turning off the power supply. Turn off the power supply after the motor has stopped its operation.
- Meet CE standard with EMI filter.

1-3. Application

- INORÉA inverter is generally applied to 3 phase AC asynchronism motors.
- INORÉA inverter is applied to the admissible occasion, the occasion where is not admissible may lead to fire, electric shock, explosion and so on.
- If the inverter seizes up when it is applied to the equipment which may lead danger (e.g. lift tools of transportation, aviation system, safety equipment, etc), it should be managed carefully.

Only well-trained engineers are allowed to use this unit. Please read carefully this manual related to safety, installation, operation and maintenance before using the unit. Safe operations of this unit depend on correct transport, installation, operation and maintenance!



Section II. Installation & Standby Circuit

2-1. Conditions for Use

- 1) Ambient temperature -10°C and 40°C.
- 2) Avoid electromagnetic interference and keep the unit away from the interference source.
- 3) Prevent dropping water, steam, dust, powder, cotton fiber or fine metal powder from entering it.
- 4) Prevent oil, salt and corrosive gas from entering it.
- 5) Avoid vibration.
- 6) Avoid high temperature and moisture and avoid being wet due to rain, with relative humidity below 90%.
- 7) Prohibit the use in the dangerous environment where inflammable or combustible or explosive gas, liquid or solid exists.

2-2. Installation

The frequency inverter must be wall mounted, indoor with adequate ventilation, with enough space surrounding it, as shown in the below figure:




2-3. Wiring


The wiring of frequency inverter includes two parts: main circuit and control circuit. The user must ensure correct connections according to the following connection diagram.

2-3-1. VFR-080 Diagram

1. Wiring diagram 11kW ~15kW and below (80N2)




2. Wiring diagram 18.5kW~355kW(80N3/80N4 /80N5 /80N6 /80N7 /80N8 /80N9 /80NA /80NB)



2-3-2. VFR-081 Diagram


1. Wiring diagram 11kW and below (70N2 /70N3 /70N4)




Main Circuit Terminals(G Series)

2-4-1. VFR-080 Main Circuit Terminals


1. 11~15kW (380V) Main Circuit Terminals



2. 18.5~37kW (380V) Main Circuit Terminals




3. 45~250kW (380V) Main Circuit Terminals




Note: DC+1/DC+2 Standard setting is short circuit; if it is with external reactance, please disconnect and then connect it.

4. 280~355kW (380V) Main Circuit Terminals



2-4-2. VFR-081 Main Circuit Terminals

1. 7.5kW below (380V) Main Circuit Terminals



Note: The above kW categories are for G type inverter.

2-4-3. Terminal Function

Terminal	Description	Functions
R/L1	Power input for frequency inverter	Connected to 3-phase power (Single input connected to R, T)
S/L2		
T/L3		
⊕	Grounding point	Grounded to the earth
B1, B2	Connection point for braking resistance	Connect brake resistance
U/T1	3 Phase Output	Connected to 3-phase motor
V/T2		
W/T3		
DC+2, DC-	DC Bus output	Connect the brake unit.
DC+1, DC+2	DC reactance connection terminal.	Connect DC reactance (No short circuit).

2-4. Control Circuit Terminals

2-5-1. Control Circuit Terminals Description


Classify	Terminal	Description	Functions
Input signal	DI1	DI1 Input Terminal	Multi-functions input terminal.For details Please read o36~o46 Enter a valid polarity can be controlled by o47 DI1~DI4 Drive model can be controlled by JP4 Above 11kW: DI5~DI8 Drive model can be controlled by PLC output terminal DI6 can as digital pulse input Below 11kW: DI5~DI6 Drive model can be controlled by PLC output terminal DI6 can as digital pulse input
	DI2	DI2 Input Terminal	
	DI3	DI3 Input Terminal	
	DI4	DI4 Input Terminal	
	DI5	DI5 Input Terminal	
	DI6	DI6 Input Terminal	
	DI7	DI7 Input Terminal	
	DI8	DI8 Input Terminal	
	PLC	PLC Control Terminal	PLC Control DI5~DI8 Drive model Drain Drive : PLC connect 24VDC or external power Source Drive: PLC connect COM
Assistant Power	24V	Power positive	The biggest output 24V/200mA, Can not connect COM with GND in any situation
	COM	Common terminal	
Output signal	SPA/COM	Output signal 1	Open Collector signal when the output action (24VDC/50mA) Common terminal COM , the output function can set by o21, o22 SPA ,SPB provide hi-speed pulse output function. After setting functions by o61~o64,Frequency inverter will take effect again.
	SPB/COM	Output signal 2	
	TA1/TB1/TC1	Output signal 3	
	TA2/TB2/TC2	Output signal 4	
Analog input signal	+10V, GND	Analog power	+10V, 50mA
	AI1	Multifunction Analog input signal 1	JP5 cut/JP3 1-2: -10V~+10V JP5 cut/JP3 2-3: 0~10V JP5 connect: 0~20mA can be regulated o00/o01 Set the input voltage / current range o06/o07 Set the input signal corresponding to set value
	AI2	Multifunction Analog input signal 2	JP6cut: 0~10V JP6connect: 0~20mA can be regulated o02/o03can set input voltage/ current arrange o08/o09 Set the input signal corresponding to set value
	AI3	Multifunction Analog input signal 3	JP7cut: 0~10V JP7connect: 0~20mA can be regulated o04/o05can set input voltage/ current arrange

			o10/o11 Set the input signal corresponding to set value
	DA1	More function analog output 1	JP1 1-2: 0~20mA JP1 2-3: 0~10VDC o15 Set analog output analog functions o17/o18set the output signal arrange
	DA2	More function analog output 2	JP2 1-2: 0~20mA JP2 2-3: 0~10VDC o16 Set analog output analog functions o19/o20 set the output signal arrange

2-5-2. Control circuit terminal

1. 8KLCB Control circuit terminal


TA1 TC1 TB1 COM DI8 DI7 DI6 DI5 DI4 DI3 DI2 DI1 +10V DA1 GND



TA2 TC2 TB2 SPA SPB COM+24V PLC COM AI3 AI2 AI1 +10V DA2 GND

2. 8KSCB Control circuit terminal

TC1 TB1 COM SPA DI5 DI3 DI1 COM PLC +24V+10V GND



TA1 COM SPB DI6 DI4 DI2 AI3 AI2 AI1 DA1 DA2 GND

2-5. Connection Precautions

- Don't install power factor capacitance or resistance-capacitance absorbing device between the output terminals U, V, W of the frequency inverter.
- To disassemble or replace the motor, the input power supply must be turned off for the frequency inverter.
- Do not drop Metal scrap foam or lint into the frequency inverter, otherwise the machine will be faulted.
- The motor or power supply can be switched on/off only after the inverter stops its output.
- In order to minimize the effect of electromagnetic interference, a surge absorbing device should be installed if used electromagnetic contactor and relay, etc. is near to the frequency inverter.
- For external control of frequency inverter, a isolation device should be used for the control lines or screened cable should be used.
- A screened cable should be used as the signal connection line for input command and must be routed separately as well, and it had better be installed far from the main circuit.

- When the carrier frequency is less than 3kHz, the distance between the frequency inverter and motor must not be greater than 50 meters (maximum). When it is above 4kHz, this distance should be reduced. The cable for this connection had better be laid in metal conduit.
- If the frequency inverter is equipped with peripheral devices (such as filter, reactor), first measure its insulation resistance to the earth with 1000V megohm meter, and ensure the resistance value is not below 4MΩ.
- If the frequency inverter must be started frequently, don't switch off its power supply, and the operator must start or stop the inverter by using the COM/FWD of the control terminal or Keyboard or RS485, in order to avoid damage to the bridge rectifier.
- Don't connect A.C. input power to the output terminals U, V, W of the frequency inverter.
- In order to prevent unexpected accidents, earthing terminal E or \perp must be grounded to the earth securely (the grounding resistance should be below 100Ω). The cable size should be greater than half of below- mentioned corresponding cable size; otherwise current leakage will happen possibly.
- For wiring of main circuit, please refer to national rule.
- Capacity of the motor should be equal to or smaller than that of the inverter.
- Specification of MCCB、 electric cable and contractor

Type	MCCB(A)	In/out Cable (Copper Core)mm ²	Rated Operational Current Of Contractor A(voltage:380V or 220V)
VFK-081-T4-0K75	16A	2.5	10
VFK-081-T4-1K5	20A	2.5	16
VFK-081-T4-2K2	32A	4	20
VFK-081-T4-004K	40A	6	25
VFK-081-T4-5K5	63A	6	32
VFK-080-T4-7K5	100A	10	63
VFK-080-T4-011K	125A	10	95
VFK-080-T4-015K	160A	25	120
VFK-080-T4-018K	160A	25	120
VFK-080-T4-022K	200A	25	170
VFK-080-T4-030K	200A	35	170
VFK-080-T4-037K	250A	35	170


VFK-080-T4-045K	250A	70	230
VFK-080-T4-055K	315A	70	280
VFK-080-T4-0K75	10A	1.5	10
VFK-080-T4-1K5	16A	1.5	10
VFK-080-T4-2K2	16A	2.5	10
VFK-080-T4-004K	25A	2.5	16
VFK-080-T4-5K5	25A	4	16
VFK-080-T4-7K5	40A	4	25
VFK-080-T4-011K	63A	6	32
VFK-080-T4-015K	63A	6	50
VFK-080-T4-018K	100A	10	63
VFK-080-T4-022K	100A	10	80
VFK-080-T4-030K	125A	16	95
VFK-080-T4-037K	160A	25	120
VFK-080-T4-045K	200A	35	135
VFK-080-T4-055K	250A	35	170
VFK-080-T4-075K	315A	70	230
VFK-080-T4-093K	400A	70	280
VFK-080-T4-110K	400A	95	315
VFK-080-T4-132K	400A	95	380
VFK-080-T4-160K	630A	150	450
VFK-080-T4-187K	630A	185	500
VFK-080-T4-	630A	240	580

200K			
VFR-080-T4-220K	800A	150*2	630
VFR-080-T4-250K	800A	150*2	700
VFR-080-T4-280K	1000A	185*2	780
VFR-080-T4-315K	1200A	240*2	900
VFR-080-T4-355K	1280A	240*2	960
VFR-080-T4-400K	1380A	185*3	1035
VFR-080-T4-500K	1720A	185*3	1290

2-6. Standby circuit

When the fault or trip of the inverter may cause great loss or accident, please add the standby circuit.


Note: confirm and test the running characteristic of the standby circuit, in order to ensure the industrial phase and the converter phase are in the same direction.




Section III. Operating Keyboard

3-1. Operating keyboard

3-1-1. VFR-08E-KBR specification and function description(Standard)




3-1-2. VFR-08C-KBR keyboard specification and function description(Optional)



Section III

3-2. Example for parameters set


3-2-1. F01 keyboard set the frequency from 50.00Hz to 25.00Hz.



1. Under monitoring status, press **PRG** into parameter group to query status;
2. Through **potentiometer** Switch to **F00-63 Basic FG**;
3. Press **PRG**, or **ENTER**, enter into **F00-63 Basic FG** parameter group to query status;
4. Through **potentiometer** Switch to **F01Fre. Set by K**;
5. Press **PRG**, or **ENTER**, enter into **F01 Fre. Set by K** parameter modify status;
6. Through **PRG**, or **ENTER**, adjust the value is modified bit;
7. Through **potentiometer** Has been modified to adjust the bit values;
8. Finish the adjustment, press **SET**; if cancle the change, press **ESC** to escape to the modify status;
9. Press **ESC** to exit to previous menu .

3-2-2. Parameter upload to the keyboard

Parameter Item	Description	
y01 parameter upload to the keyboard	N function	0
	System parameter upload to the memory area1 in the keyboard	1
	System parameter upload to the memory area2 in the keyboard	2
	System parameter upload to the memory area3 in the keyboard	3
	System parameter upload to the memory area4 in the keyboard	4
	Clear memory area in the keyboard1, 2, 3, 4	5




Example . System parameter upload to the memory area3 in the keyboard

- Under monitoring status, press **PRG** into parameter group to check status;
- Through **potentiometer** Switch to **y00-23 System FG**;
- Press **PRG**, or **ENTER**, enter into **y00-23 System FG** parameter group to check status;
- Through **potentiometer** Switch to **y01P Upload To K**;
- Press **PRG**, or **ENTER**, enter into **y01P Upload To K** parameter modify status;
- Through **potentiometer** adjust value to be 3 ;
- Finish the adjustment, press **SET**; the speed for upload will display on the LED; if cancel the change, press **ESC** to escape to the modification status;
- Press **ESC** to exit to previous menu.

3-2-3. Reset system parameters


Parameter Item	Description	
y00 Reset system parameters	N function	0
	memory area1 in the keyboard to reset system parameter	1
	memory area2 in the keyboard to reset system parameter	2
	memory area3 in the keyboard to reset system parameter	3
	memory area4 in the keyboard 1to reset system parameter	4
	Use the factory setting reset system parameter	5



Example 1: memory area3 in the keyboard 1 to reset system parameter

- Under monitoring status, press **PRG** into parameter group to query status
- Through **potentiometer** Switch to **y00-23 System FG**;
- Press **PRG**, or **ENTER**, enter into **y00-23 System FG** parameter group to query status;
- Through **potentiometer** Switch to **y01P Upload To K**;
- Press **PRG**, or **ENTER**, enter into **y00 Reset SP** parameter modify status;
- Through **potentiometer** adjust to 3 ;
- Finish the adjustment, press **SET**; the speed for download will display on the LED; if cancel the change, press **ESC**;
- Press **ESC** to exit to previous menu.

Example 2 Clear memory area 1, 2, 3, 4 in the keyboard



1. Under monitoring status, press **PRG** into parameter group to check status
2. Through **potentiometer** Switch to **y00-23 System FG**;
3. Press **PRG**, or **ENTER**, enter into **y00-23 System FG** parameter group to check status;
4. Through **potentiometer** Switch to **y01P Upload To K**;
5. Press **PRG**, or **ENTER**, enter into **y01P Upload To K** parameter modify status;
6. Through **potentiometer** adjust to 5 ;
7. Finish the adjustment, press **SET**; the speed for Clear memory area will display on the LED; if cancel the change, press **ESC**;
8. Press **ESC** to exit to previous menu.

3-2-4. F02 the main set mode of set frequency is set to 4, keyboard potentiometer setting !

1. Under monitoring status, Through **potentiometer** adjust the frequency, the resolution ratio potentiometer is 0.05Hz.
2. Range of set frequency can be set with the following parameters:

Parameter item	Description
F12 max. frequency	Inverter output maximum frequency allowed Setting range: 10.00~320.00Hz
A45 keyboard potentiometer setting X1	Keyboard potentiometer setting the start value Setting range: 0~100%
A46 keyboard potentiometer setting X2	Keyboard potentiometer setting the end value Setting range: 0~100%
A47 keyboard potentiometer setting value	Display the value of potentiometer setting, range: A45~A46 Also can set directly, Setting range: A45~A46
A48 keyboard potentiometer setting X1 correspond to Y1	Keyboard potentiometer setting the starting point for the corresponding value Setting range: -100%~+100%
A49 keyboard potentiometer setting X2 correspond to Y2	Keyboard potentiometer settings corresponding to the value of the end Setting range: -100%~+100%
S00 setting frequency	Displays the current size of the set frequency, through the potentiometer setting Setting range: F12*A48~ F12*A49

Example:

F12=50.00Hz, A45=0%, A46=100%, A47 Shows the value of potentiometer settings 0%~100%, Numerical size can be adjusted by potentiometer.

- (1) when A48=0%, A49=+100%, **S00 Set Fre.** range 0.00Hz~50.00Hz.
- (2) when A48=0%, A49=+50%, **S00 Set Fre.** range 0.00Hz~25.00Hz.
- (3) when A48=-100%, A49=+100%, **S00 Set Fre.** range -50.00Hz~50.00Hz.

Note: when the motor is in -50.00~0Hz realise reverse, another setting

F45 Ten bit motor forward inverse as

I Command priority: Analog given positive and negative values, on the F45 details refer to F45 Parameter Description

3-2-5. F02 the main set mode of set frequency is set to 1, AI1 external analog given.

1. Under monitoring status, Through external analog input terminal AI1 adjust the frequency, the resolution ratio is 0.01Hz.
2. Set the frequency range can be set with the following parameters:

Parameter Item	Description
F12 most frequency	Inverter speed adjustment's allowed maximum output frequency Sett - ing range: 10.00~320.00Hz
o00 AI1 input X1	Keyboard potentiometer setting the start value Setting range: 0~100%
o01 AI1 input X2	Keyboard potentiometer setting the end value Setting range: 0~100%
o06 AI1 input X1 correspond to Y1	Keyboard potentiometer setting the starting point for the corresponding value Setting range: -100%~+100%

o07 AI1 input X2 correspond to Y2	Keyboard potentiometer settings corresponding to the value of the end Setting range: -100%~+100%
S00 frequency setting	Display the frequency,Through out analog input terminal AI1 adjust the frequency Setting range: F12*o06~ F12*o07

Example:

F12=50.00Hz, o00=0%, o01=100%,

(1) When o06=0%, o07=+100%, **S00 Set Fre.** range 0.00Hz~50.00Hz.

(2) When o06=0%, o07=+50%, **S00 Set Fre.** range 0.00Hz~25.00Hz.

(3) When o06=-100%, o07=+100%, **S00 Set Fre.** range -50.00Hz~50.00Hz.

Note: When realize the motor reverse in -50.00~0Hz.



F45Ten bit motor forward reverse as

l Command priority: Analog given positive and negative values, on the F45 details see F45

Parameter Description

Section IV. Test Running

- Failure occurred when test running. Please take reference of fault diagnosis in 6-1 to get rid of the breakdown
- Inverter parameters have a strong adaptive ability, in general b11 = 1 calculation of electrical parameters with the name plate, on this basis, a little manual adjustment can get you high-performance vector control.
- Only when the motor completely without the load can set b11=3motor rotation measurements
- Before the electrical parameter measurement finished, inverter can have the ourput voltage any time, please ensure the safety.



Section V Parameter Function Table

Notice: ★ means that the factory setting value of the parameter is according to the power and model. The exact value is referred to the Parameter Function Table. Change limited mean that whether it can be modified while running.

5-1. Menu Group

Code	Description / LCD	Function Discription	Group ID	Refer to page
S	Monitor Function Group	Monitor frequency, current and other 16 monitor objects	0B	25
F	Basic Function Group	Frequency setting, control mode, acceleration time and deceleration time	00	26
A	User Function Group	Monitor, protection, communication setting	01	42
o	IO Function Group	Analog, digital input, output function	02	53
H	Multi-speed PLC Group	Multi-speed running, PLC running	03	72
U	V/F parameter Group	User defined V/F curve	04	80
P	PID Function Group	Internal PID parameter setting	05	81
E	Extend Function Group	Constant pressure water supply and other function setting	06	84
C	Speed ring function group	Current ring, speed running, PG parameter	07	90
b	Motor parameter group	Motor parameter setting	08	95
y	System Function Group	Parameter reset, fault query, product information, parameter protection	09	97

5-2. Monitor function: S00-S15 (0x0B00-0x0B0F)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
S00	Setting Frequency	current inverter real setting frequency	Hz	-	N
S01	Real Frequency	current inverter real output frequency	Hz	-	N
S02	Motor real Current	Valid value of motor actual current	A	-	N
S03	Percentage of Motor Current	The percentage of actual motor current and rated current	%	-	N
S04	DC Bus Voltage	Detection value of DC bus voltage	V	-	N
S05	The Output Voltage	The real output voltage	V	-	N
S06	Motor Real Speed	Motor real running speed	-	-	N
<p>Under running, the real speed of the motor = $60 \times \text{the real output frequency} \times \text{Gain Speed surveillance} / \text{pole of the motor}$.</p> <p>Example: the real output frequency 50.00Hz, Gain Speed surveillance A35=100.0%, the pole of the motor b03/b16=2, the real speed of the motor = 1500rpm.</p> <p>When stop, based Residual voltage test motor speed, renew speed 500ms.</p> <p>The real speed = $60 \times \text{residual frequency} \times \text{Gain Speed surveillance} / \text{the pole of the motor}$</p> <p>Max display of motor real speed 9999rpm.</p>					

Section V Parameter Function Table

S07	Total Running Time	The total running time for every time	hour	-	N
<p>When the output, the frequency inverter calculated the running time.</p> <p>Total running time can be cleared up automatically with A33 selecting reboot or continue accumulation after reboot</p> <p>Total running time of the units can be changed by parameter A34, you can choose hours or days as the unit</p>					
S08	IGBT Temperature °C	Test the temperature of IGBT in the frequency	°C	-	N
S09	PID Set Point	PID Adjust run-time values of the percentage of a given	%	-	N
S10	PID Feedback	PID Adjust run-time values of the percentage of feed back	%	-	N
S11	Motor Output Frequency	The percentage of actual output power of motor	%	-	N
<p>The output frequency of the motor = the actual frequency of the motor * A36 (the regulate of the motor frequency)</p> <p>Max display of the output frequency 2999.9</p>					
S12	Excitation Heft Set Value	Motor's set excitation heft percentage	%	-	N
S13	Excitation Heft Actual Value	Motor's actual excitation heft percentage	%	-	N
S14	Torque Heft Set Value	Motor set torque percentage	%	-	N
S15	Torque Heft Actual Value	Motor actual torque hefts percentage	%	-	N

5-3. Basic function Group: F00-F50 (0x0000-0x0032)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited	
F00	Control Mode	V/F control	0	-	0	N
		Sensorless vector control	1			
		Sensor feedback close loop vector control	2			
<p>Control mode choose, setting 0~2.</p> <p>0: V/F control It is not sensitive to motor parameters, can be used as power supply; for motor control, using the combination of vector control and V/F control strategies, appropriately adjusts motor parameters, obtain high-performance control effect; suitable for a inverter driving a motor occasions; suitable for a inverter driving multiple motors occasions; suitable for the inverter as a variable frequency power supplies.</p> <p>1: Sensorless vector control High-performance speed sensorless vector control; need to set the appropriate electrical parameters or the motor parameter tuning; truly achieved the decoupled AC motor, so that operational control of DC motors.</p> <p>2: Sensor feedback close loop vector control Suitable for high precision speed control occasions, need to install PG card and pulse encoder shaft in the motor or mechanical equipment.</p>						
F01	Keyboard Setting Frequency	Lower frequency~upper frequency	Hz	50.00	Y	


Section V Parameter Function Table

The keyboard for a given operating frequency, it can be any frequency between lower frequency and upper frequency . F02/F03 setting to 0, Involved in setting frequency calculation.						
F02	Frequency Main Set Mode	Keyboard setting frequency or RS485	0	-	0	Y
		AI1 the external analog setting	1			
		AI2 the external analog setting	2			
		AI3 the external analog setting	3			
		Keyboard potentiometer setting	4			
		Multi-segment digital voltage setting	5			
		Digital Pulse Setting	6			
The main mode of the frequency running frequency: 0 : keyboard setting frequency or RS485 change F01 keyboard setting frequency Multi-digital voltage terminal effective exchange, change F01 keyboard setting value 1 : AI1 the external analog setting Given the external analog 0~10V, -10V~+10V, 0~20mA. For detail please read the o group parameter. 2 : AI2 the external analog setting 3 : AI3 the external analog setting Given the external analog 0~10V, 0~20mA. For detail please read the o group parameter. 4 : Keyboard potentiometer setting Keyboard potentiometer setting, keyboard potentiometer for a given start and end values of the corresponding values can be positive role and negative effects. For detail please read the A group parameter. 5 : Multi-segment digital voltage setting o36~o46 IO input terminal function set to 11, 12, 13, switch H47~H54 Multi-digital voltage setting, 100% Corresponding to the maximum frequency . 6 : Digital pulse setting Digital pulse input frequency Corresponding to the setting frequency, For detail please read the o52 group parameter. Pulse input terminal and DI8 terminal reset, after using the digital pulse input, o43 set to 0, otherwise, the function settings will take effect, the pulse input on status of o58 can be checked, be limited to low-speed pulse. Through o36~o46 IO input terminal set to 14, 15, 16 be configured to switch the source						
F03	Auxiliary Setting Mode Of Frequency	Keyboard setting frequency or RS485	0	-	0	Y
		AI1 the external analog setting	1			
		AI2 the external analog setting	2			
		AI3 the external analog setting	3			
		Keyboard potentiometer setting	4			
		Multi-segment digital voltage setting	5			
		Digital Pulse Set	6			
		PID regulation mode	7			
Auxiliary setting mode of frequency set: 0 : keyboard frequency setting frequency or RS485, change F01 keyboard setting frequency						

Section V Parameter Function Table

After multi-digital voltage terminal effective switch, change F01 keyboard setting. 1 : AI1 the external analog setting Given the external analog 0~10V, -10V~+10V, 0~20mA. For detail please read the o group parameter. 2 : AI2 the external analog setting Given the external analog 0~10V, 0~20mA. For detail please read the o group parameter. 3 : AI3 the external analog setting Given the external analog 0~10V, 0~20mA. For detail please read the o group parameter. 4 : Keyboard potentiometer setting Keyboard potentiometer setting, keyboard potentiometer for a given start and end values of the corresponding values can be positive role and negative effects. For detail please read the A group parameter. 5 : Multi-segment digital voltage setting o36~o46 IO input terminal function set to 11, 12, 13, switch H47~H54 Multi-digital voltage setting, 100% Corresponding to the maximum frequency . 6 : Digital pulse set Digital pulse input frequency corresponding to set the frequency, For detail please read o52 parameter. Pulse input terminal and DI8 terminal resetting, After use digital pulse input, o43 set to 0, otherwise, the function settings will take effect, can check the pulse input status o58, be limited to low-speed pulse. 7 : PID regulation mode The completion of the main to the frequency of common analog feedback loop control. Speed control accuracy requirements applicable to the general occasions. The given value can be given through the keyboard can also be given through the analog. Analog feedback can represent the pressure, flow, temperature. Details see the P group of parameters. The completion of the main to the frequency of common analog feedback loop control. Speed control accuracy requirements applicable to the general occasions. For a given value can be given through the keyboard can also be given through the analog. Analog feedback can represent the pressure, flow, temperature. Details see the P group of parameters. Through o36~o46 IO input terminal, set to 17, 18, 19 be configured to switch the source for a given ratio.						
F04	The Relationship Between Main And Auxiliary Setting Frequency	The main setting individual control	0	-	0	Y
		The auxiliary setting individual control	1			
		main + auxiliary	2			
		main -auxiliary	3			
		(main *auxiliary)/maximum frequency	4			
		Maximum {main, auxiliary}	5			
		Minimum {main, auxiliary}	6			
Main given and auxiliary given set frequency relations: Main given value and auxiliary given value can be added up, subtracted, multiplied, maximum, minimum calculation. O group parameters can be adjusted to coordinate the main given and auxiliary given proportion, to meet the requirements of the system fine-tuning and bias.						

Section V Parameter Function Table



Section V Parameter Function Table

control is invalid

4 : The proportion linkage control
 Select this function, the slave unit would execute the command from the proportion linkage host unit.
 Select this function, can also use keyboard, terminal, RS485 to control the proportion linkage slave unit to run.
 The proportion of linkage running,after stop the proportion linkage slave unit with the keyboard terminal, Rs485, the slave unit will not run the proportion liknge host unit's command, it needs once again to respond to host commands through the keyboard, terminal, RS485, or the proportion linkage host sends stop command so that slave unit could respond to run commands.

F06	V/F Boost Mode	1 bit	Beeline V/Fcurve	0	-	0000	N
			Power of 1.2 V/Fcurve	1			
			Power of 1.7 power V/Fcurve	2			
			Power of 2 powerV/Fcurve	3			
			Define mode V/Fcurve	4			
		10 bit	Close Automatic torque boost	0			
			Automatic torqueboost	1			
		100 bit	VF mode 0 Speed No Output	0			
			VF mode keep 0 speed	1			

1 Bit: V/F promote curve
 0 Line V/F curve: Suitable for ordinary constant torque load
 1 Power of 1.2 V/F curve: Appropriate torque down V/F curve, Suitable for liquid loads
 2 Power of 1.7 V/F curve: Appropriate torque down V/F curve, Suitable for liquid loads
 3 Power of 2 V/F curve: Torque down V/F curve, It is suitable for fans, pumps, centrifugal load
 4 Define mode V/Fcurve: Can be customized appropriate curve according to the actual situation .

10 bit: Auto-torque boost mode
 0 Close Automatic torque boost
 1 Open automatic torque boost

parameters which affect automatic torque enhance :
 Actual value torque component S15
 b06/b19 stator resistance
 F07 torque enhance value
 Automatic torque enhance value = actual value of torque component * stator resistance *torque enhance value.

100 bit: VF mode 0 speed maintain function
 0 VF mode 0 Speed No Output: Output frequency is less than 0.5Hz, stop PWM output to reduce the switching loss.
 1 VF mode keep 0 speed: the output frequency is 0Hz, in accordance with the DC braking current of starting F26, keep 0 speed.

F07	Torque boost Value	0.0~30.0%	%	0.0	Y
F08	Torque Boost Cut-off	0.00~Maximum frequency	Hz	15.00	Y

Section V Parameter Function Table

	Frequency				
<p>Torque increase is mainly used to improve the low-frequency torque characteristics under sensorless -V / F control mode. Torque boost is too low, weak low speed motor Torque boost is too high, motor over-excitation operation, large inverter output current, and low efficiency. The setting frequency of the inverter is lower than the frequency of the torque rising, the torque rising will be valid; over than the setting frequency the torque rising will be invalid.</p>					
down the torque curve torque boost		Constant torque curve torque boost			
F09	Accelerate Time	0.0~3200.0	s	10.0	Y
F10	Decelerate Time	0.0~3200.0	s	10.0	Y
<p>F09 Accelerate time: accelerate time from 0Hz to maximum frequency. F10 Decelerate time: decelerate time from maximum frequency to 0Hz.</p>					
F11	Percentage Of Output Voltage	50~110	%	100	Y
<p>The percentage of the actual output voltage and the rated output voltage. Used to adjust the output voltage, output voltage = inverter rated output voltage * percentage of output voltage.</p>					
F12	Maximum Frequency	10.00~320.00	Hz	50.00	N
<p>Inverter output maximum frequency allowed is also the setting basis of acceleration / deceleration time. This parameter setting, you should consider characteristics of the motor speed and capacity.</p>					
F13	Lower Frequency	0.00~Upper frequency	Hz	0.00	N
F14	Upper Frequency	Lower frequency~Upper frequency	Hz	50.00	N
<p>F13 Lower frequency: the lower limit of the output frequency. F14 Upper frequency: the upper limit of output frequency. When the frequency setting command is higher than the upper frequency, the operating frequency will be the upper frequency; when the frequency setting command below the lower frequency, the operating frequency is lower frequency. Start the motor that in the status of stopping, the inverter outputs</p>					

Section V Parameter Function Table

<p>accelerate starting from 0Hz, accordance with the step 1 acceleration time towards the upper or the setting frequency to accelerate. when motor Stop, the operating frequency decelerate according to deceleration time down to 0Hz.</p>					
F15	Basic Frequency	5.00~Maximum frequency	Hz	50.00	N
<p>Corresponding to different fundamental frequency of the motor select this function. The basic V / F characteristic curve is as below.</p>					
F16	Carrier Frequency	1.0~16.0	kHz	★	Y
<p>This function is chiefly used to improve the possible noise and vibration during the operation of frequency converter. When carrier frequency is higher, the output current has better wave, the torque is great at lower frequency and the motor produces light noise. So it is very suitable for use in the applications where great torque is output at low frequency quietly. But in these applications, the damage to the switches of main components and the heat generated by the inverter are great, the efficiency is decreased and the output capacity is reduced. At the same time, more serious radio interference is resulted and special attention must be paid for application where very low EMI is needed, and filter option can be used if necessary. Another problem for application of high carrier frequency is the increase of capacitance-leakage current. The protector for leakage current may invalidate function, and over current is also possibly caused.</p> <p>When low carrier frequency is applied, the case is almost contrary to the above-mentioned one. Different motor has different reflection to the carrier frequency. The best carrier frequency is gained after regulation according to actual conditions. The higher the motor capacity is, the lower the carrier frequency should be selected.</p> <p>The company reserves the right to limit maximum carrier frequency as following: The relation between carrier frequency and Motor Noise, Electric disturbance, Switch dissipation is expressed as following:</p>					
		Carrier Frequency	Motor Noise	Electric disturbance	Switch dissipation
		1.0KHz	Big	Small	Small
		8.0KHz	↓	↓	↓

Section V Parameter Function Table


	16.0KHz	Small	Big	Big			
The relationship of the carrier frequency and power :							
	Power(kW)	0.4-18.5	22-30	37-55	75-110	132-200	220 以上
	Carrier Frequency (Hz)	8.0K	7.0K	4.0K	3.6K	3.0K	2.5K
Note: Carrier frequency is bigger, the temperatuer of the machine is higher.							
F17	Carrier Frequency Adjustment Range	0.0~4.0			kHz	0.0	Y
F18	Carrier Frequency Adjustment Mode	1 bit	No automatic adjustment	0	-	00	Y
			automatic adjustment Mode	1			
		10 bit	automatic adjustment, Fixed mode	0			
			automatic adjustment, random mode	1			
<p>F17 Carrier frequency adjustment range 0.0~4.0kHz, Actual Carrier frequency adjustment range 1.0~16.0kHz</p> <p>F18 Carrier frequency adjustment Mode</p> <p>1 Bit: Carrier frequency automatic adjustment mode 0: No automatic adjustment Carrier frequency according F16 to set . 1: automatic adjustment Mode The carrier frequency automatically adjusts the model 10 can select random mode and fixed pattern.</p> <p>10 Bit: Stochastic adjustment mode 0: automatic adjustment, Fixed mode Load current>80% Carrier frequency =F16-F17 Load current<60% Carrier frequency =F16+F17 1: automatic adjustment, random mode Load current >80% Carrier frequency = (F16-F17)-F16 Load current <60% Carrier frequency = F16-(F16+F17)</p>							
F19	Waveform Generation Mode	Asynchronous space-vector PWM	0	-	0	N	
		Stepless & subsection synchronous space vector PWM	1				
		two-phase optimization space vector PWM	2				
<p>PWM wave produce mode</p> <p>0: Asynchronous space-vector PWM</p> <p>1: Stepless & subsection synchronous space vector PWM</p> <p>2: two-phase optimization space vector PWM</p>							
F20	S Curve Start Time At The Acceleration Step	0.0~50.0			%	0.0	Y
F21	S Curve Stop Time At The Acceleration Atep	0.0~50.0			%	0.0	Y
F22	S Curve Start Time At The Deceleration Step	0.0~50.0			%	0.0	Y

Section V

Section V Parameter Function Table

F23	S Curve Stop Time At The Deceleration Step	0.0~50.0	%	0.0	Y	
<p>1 indicat that the slope of the output frequency from 0 to the max. 2 indicat that the slope of the output frequency at constant segment. 3 indicat that the slope of the output frequency is reduced to 0 from the max. Such as setting the S curve acceleration and deceleration, acceleration and deceleration time from 0Hz to the maximum frequency is calculated as follows: Plus acceleration S characteristic time = F09 * F20 Constant extra acceleration S characteristic time = F09-(F09 * F20 + F09 * F21) Minus acceleration S characteristic time = F09 * F21 Full acceleration time = F09 Acceleration time Velocity S addition and subtraction characteristic time = F10 * F22 Constant deceleration S characteristics time = F10-(F10 * F22 + F10 * F23) And reduction rate of S characteristic time = F10 * F23 All deceleration time = F10 deceleration time</p>						
<p style="text-align: center;">S curve acceleration&deceleration</p>						
F24	V/F Control Slip Compensation	slip compensation invalid	0	-	0	N
		slip compensation valid	1			
<p>Valid only under V/F control mode. 0 : Slip compensation function is invalid. 1 : Slip compensation function is valid. Slip compensation value adjusted by the following parameters to ensure stable speed under load fluctuations and heavy load, C09 Low Slip Gain C10 Low Slip switching frequency C11 High-Speed Slip Gain Slip C12 high-speed switching frequency</p>						
F25	Minimum Running Frequency	0.00~maximum frequency	Hz	0.00	N	

Section V Parameter Function Table




The set frequency lower than the minimum running frequency, the converter will stop, that is, when the set frequency is less than the minimum running frequency, are determined that the set frequency is 0. Minimum running frequency" and "lower frequency" relationship is as follows.

F26	DC Braking Current When Starting	0~135	%	100	Y
F27	Braking Time When Starting	0.0~60.0	s	0.0	Y

When frequency inverter starting, the first injection of DC current, the current size is determined by starting to set when the DC braking current and braking time, braking time from the start to set.

Value is based on inverter rated current as the benchmark, that is inverter rated current corresponds to 100%. During setting process, be sure to gradually increase, until adequate braking torque, and can not exceed the motor rated current.




F28	Stop When The DC Braking Current	0~135	%	100	Y
F29	Stop And Braking Wait Time	0.0~60.0	s	0.0	Y
F30	Brake Time Stop	0.0~60.0	s	0.0	Y
F31	Stop And Brake Starting Frequency	0.00~most frequency	Hz	0.00	Y


Inverter slowing down to stop braking start frequency, stop the output PWM waveform to begin injection of DC current, the current size by the shutdown of DC braking current setting, braking time, braking time set by the downtime.

Value is based on inverter rated current as the benchmark, that is inverter rated current corresponds to 100%. Setting process, be sure to gradually increase from a small, until adequate braking torque, and can not exceed the motor rated current.


Section V Parameter Function Table



Stop braking (RUN → STOP)



stop braking (forward and reverse rotate)



stop braking (run state)

F32	Stop Setting Mode	Deceleration stop	0	-	0	N
		Free stop	1			

When the frequency inverter receives the "stop" command, it will set the parameters accordingly to this parameter to set the motor stop mode.

0 : deceleration to stop

Mode converter according to parameters set by the deceleration time to set the deceleration mode to slow down to the lowest frequencies to stop.

1 : Free stop mode


Inverter receive "stop" command immediately stop output, according to the load inertia, motor free-run to stop.

F33	Jog Acceleration Time	0.0~3200.0	s	1.0	N
-----	-----------------------	------------	---	-----	---

Section V Parameter Function Table

F34	Jog Deceleration Time	0.0~3200.0		s	1.0	N	
F35	Jog Mode Setting	1 bit	Jog direction: forward	0	-	000	N
			Jog direction: reverse	1			
			Jog direction: direction determined by the main terminal	2			
		10 bit	Jog end mode: Stop Running	0			
			Jog end mode:reset to the former state before jog	1			
100 bit	Jog end and acceleration deceleration time: reset to the set acceleration and deceleration time before jog	0					
	Jog end and acceleration deceleration time:save the set acceleration and deceleration time before jog	1					

F36	Jog Frequency Setting	Lower frequency ~upper frequency	Hz	6.00	Y
-----	-----------------------	----------------------------------	----	------	---



Jog acceleration/deceleration time configuration defines the same section of acceleration / deceleration time.

The direction of jog is set by the unit bit of F35,when the Jog command does not contain the direction of jog, the direction of job will run as to the unit bit designated by F35. It is set to 2, the direction of jog is run by the terminal or current direction.

The running status after jogging is identified by F35.

Whether jog acceleration/deceleration time is maintained through the confirmation on hundred bit of F35 after jogging

F37	Skip Frequency1Limit	0.00~Maximum frequency	Hz	0.00	Y
F38	Skip Frequency1Upper	0.00~Maximum frequency	Hz	0.00	Y
F39	Skip Frequency2Limit	0.00~Maximum frequency	Hz	0.00	Y
F40	Skip Frequency2Upper	0.00~Maximum frequency	Hz	0.00	Y
F41	Skip Frequency3Limit	0.00~Maximum frequency	Hz	0.00	Y
F42	Skip Frequency3Upper	0.00~Maximum frequency	Hz	0.00	Y

During running, to skip resonance produced by the immanent resonance point in the machine sys -

Section V Parameter Function Table

tems, skip mode can do this.
At most three resonance points could be set to skip.

Upper skip frequency and lower skip frequency define skip frequency range.
In the acceleration and deceleration process, inverter output frequency can normally through skip frequency area.

F43	Preset Frequency	0.00~Max frequency	Hz	0.00	Y
F44	Preset Frequency Working Time	0.0~60.0	s	0.0	Y

After inverter startup, it firstly run with preset frequency, running time is preset frequency time,then it will run with given frequency. Jog run will not be effective by preset frequency.

F45	Motor Running Direction	1 bit	Direction command: forward command FWD let motor forward running	0	-	0100	N
			Direction command: forward command FWD let motor reverse running	1			
		10 bit	Command prior: terminal/keyboard	0			
			Prior command: Analog given positive and negative values	1			
100 bit	Reverse allow: reverse forbidden	0					
	Reverse allow: reverse allow	1					

- 1 : Bit: used to change the direction of motor running
- 0: Forward command FWD is to let motor forward running.
- 1: Forward command FWD is to let motor reverse running.
- 10 : Motor forward reverse running can be controlled by the keyboard potentiometer and analog input positive or negative value.
- 0: Prior command:terminal / keyboard, set frequency can be negative value, but running direction decided by terminal and keyboard command.
- 1: Prior command: positive or negative value of analog input, setting frequency positive value let motor forward running, seting negative value let motor reverse running.
- 100:motor reverse allow. For some producing equipment, the reverse may lead to damage to the

Section V Parameter Function Table

<p>equipment, so this feature can be used to prevent motor reverse, Inverter default forbidden reverse. When the motor running direction opposes to equipment required direction, you can exchange the wiring of any two inverter output terminals to let equipment forward running direction is consistent with motor running. 0: reverse forbidden 1: reverse allow</p>							
F46	Pass 0 Stopping Time	0.0~60.0s	s	0	N		
<p>Setting this parameter to achieve the motor forward to reverse (or from reverse running to forward), the waiting time of motor speed being zero</p>							
F47	Frequency Multiple Setting	*1 *10	0 1	-	0	N	
<p>0: Set frequency display accuracy 0.01Hz With this accuracy, F12 Maximum frequency setting range 10.00~320.00Hz. 1: Set frequency display accuracy 0.1Hz with this accuracy, F12 Maximum frequency setting range 100.0~800.0Hz. After setting this parameter, there must be reset F12 maximum frequency.</p>							
F48	Acceleration And Deceleration Configuration Word	1 bit	N adjustment of acceleration time	0	-	0000	N
			AI1 adjustment of the external analog giving	1			
			AI2 adjustment of the external analog giving	2			
			AI3 adjustment of the external analog giving	3			
			Adjustment of keyboard potentiometer giving	4			
		10 bit	N adjustment of deceleration time	0			
			AI1 adjustment of the external analog giving	1			
			AI2 adjustment of the external analog giving	2			
			AI3 adjustment of the external analog giving	3			
			Adjustment of keyboard potentiometer giving	4			

Section V Parameter Function Table

	100 bit	Adjustment of Multi steps digital voltage giving	5				
		Acceleration time:*s	0				
		Acceleration time:*min	1				
		Acceleration time:*h	2				
	1000 bit	Acceleration time:*day	3				
		Deceleration time:*s	0				
		Deceleration time:*min	1				
		Deceleration time:*h	2				
Deceleration time:*day							3

1 bit: Acceleration time adjustment mode		
0	No Adjustment Of Acceleration Time	No adjustment
1	AI1 Adjustment Of The External Analog Giving	Actual Acc. time=Acc. time*AI1 giving percentage
2	AI2 Adjustment Of The External Analog Giving	Actual Acc. time = Acc. time*AI2 giving percentage
3	AI3 Adjustment Of The External Analog Giving	Actual Acc. time = Acc. time*AI3 giving percentage
4	Adjustment Of Keyboard Potentiometer Giving	Actual Acc.time = Acc. time*keyboard potentiometer giving percentage
5	Adjustment Of Multi Steps Digital Voltage Giving	Actual Acc.time=Acc.time*Multi steps digital voltage giving percentage

10 bit: Deceleration time adjustment mode		
0	No Adjustment Of Acceleration Time	No adjustment
1	AI1 Adjustment Of The External Analog Giving	Actual Acc.time =Dec. time*AI1 giving percentage
2	AI2 Adjustment Of The External Analog Giving	Actual Acc.time = Dec. time *AI2 giving percentage
3	AI3 Adjustment Of The External Analog Giving	Actual Acc.time = Dec. time *AI3 giving percentage
4	Adjustment Of Keyboard Potentiometer Giving	Actual Acc.time = Dec. time*keyboard potentiometer giving percentage
5	Adjustment Of Multi Steps Digital Voltage	Actual Acc.time=Dec.time*Multi steps digital voltage giving percentage

100, 1000 bit: The unit of Acc. and Dec time when program running on 0 step speed		
Acc. and Dec. time	1000 bit 100 bit	Range(e.g. F09, F10=3200.0)
*s	0	3200.0s
*Min	1	3200.0 Min
*H	2	3200.0 h
*Day	3	3200.0 Day

Section V Parameter Function Table

F49	Running Configuration Word	1 bit	Running direction: forward	0	-	0000	N
			Running direction: reverse	1			
		10 bit	Running time: *S	0			
			Running time: *Min	1			
			Running time: *H	2			
			Running time: *Day	3			

Unit adjustment of actual running time.It is only valid on program running.

1 bit: Program running on multi-speed running period, Set bit to running direction of "0" step speed.

Running direction	Setting value
Forward	0
Reverse	1

When running control mode F05=0/1/2, control direction of "0" step speed.

When running control mode F05=3, Setting the value and terminal FWD / REV jointly decide the direction of 0 step speed, FWD priority.

FWD=1running direction	REV=1running direction	Setting value
FWD	REV	0
REW	FWD	1

10 bit: unit of time running when on "0" step speed.


Running time	10 bit	range(e.g. H18~H25=3200.0)
*S	0	3200.0s
*Min	1	3200.0Min
*H	2	3200.0H
*Day	3	3200.0 Day

F50	Energy Saving Running Percentage	30~100	%	100	N
-----	----------------------------------	--------	---	-----	---

This parameter describes the minimum output voltage percentage of energy-saving operation. In the constant speed operation, the inverter can be automatically calculated the best output voltage by the load conditions. In the process of acceleration and deceleration is not to make such calculations.

Power-saving function is by lowering the output voltage and improve power factor to achieve the purpose of saving energy, this parameter determines the minimum value of reducing of output voltage; This parameter is set to 100%, then energy-saving function will take off.

When energy-saving function in effect, Actual output voltage value of inverter= The inverter rated output voltage*The percentage of output voltage*output voltage percentage of energy saving operation.



Section V Parameter Function Table

5-4. User Function Group:A00-A55(0x0100-0x0137)

Code	Description / LCD	Setting Range		Unit	Factory Setting	Change Limited
A00	Monitor 1	Parameter group N:	Parameter group N:	-	0B00	Y
A01	Monitor 2	X1000/X100	X10/ bit	-	0B01	Y
A02	Monitor 3	00~0B	0~63(0x00~0x3F)	-	0B02	Y

Code	Keyboard display	Parameter group N	Function spec	Parameter N(16 Hexadecimal Input)
S	Monitor Function Group	0B	S	0~16 (0x00~0x10)
F	Basic Function Group	00	F	0~60 (0x00~0x3C)
A	User Function Group	01	A	0~56 (0x00~0x38)
o	IO Function Group	02	o	0~61 (0x00~0x3D)
H	Multi-step Speed PLC Group	03	H	0~56 (0x00~0x38)
U	V/F Curve Group	04	U	0~16 (0x00~0x10)
P	PID Function Group	05	P	0~13 (0x00~0x0D)
E	Extend Function Group	06	E	0~14 (0x00~0x0E)
C	Speed Loop Parameter Group	07	C	0~32 (0x00~0x20)
b	Motor Parameter Group	08	b	0~23 (0x00~0x17)
y	System Function Group	09	y	0~18 (0x00~0x12)

That parameter N. should be 16 hex input.

Monitor1 will be valid when first power on, and which decide keyboard display content.

Such as:monitor 1 S01 actual frequency, A00=0x0B01.

Monitor 2 o57 DI1~4 terminal status, A01=0x0239.

Monitor 3 H55 multi-steps speed status, A02=0x0337.


A03	Over /Less Voltage Stall Protection	N	0	-	1	Y
		Y	1			
A04	Overvoltage Stall Protection Voltage	110%~140%(Standard bus voltage)		%	120	Y

0 : This function invalid

1 : This function valid

When the inverter deceleration, as the motor load inertia, motor will produce feedback voltage to inverter inside, which will increase DC bus voltage and surpass max voltage. When you choose Over /less voltage stall protection and it is valid, Inverter detects DC side voltage, if the voltage is too high, the inverter to stop deceleration (the output frequency remains unchanged), until the DC side voltage is below the set value, the inverter will re-implement the deceleration

With braking models and external braking resistor, this function should be set to "0".



Section V Parameter Function Table

A05	Auto Stabilize Voltage	Invalid	0	-	0	Y
		Valid	1			
		Valid, useless for deceleration	2			
<p>CPU automatically detect the inverter DC bus voltage and to make real-time optimized processing, when the grid voltage fluctuate, the output voltage fluctuation is very small, the V / F curve characteristic has always been close to setting state of rated input voltage..</p> <p>0 : function inalid. 1 : function Valid. 2 : function Valid, but useless for deceleration.</p>						
A06	Dynamic Braking option	Invalid	0	-	0	Y
		Security Type	1			
		General Type	2			
A07	Hysteresis voltage	0~10%	%	2	Y	
A08	Dynamic Braking Voltage	110%~140%(Standard bus voltage)	%	130	Y	
<p>0 : Invalid 1 : Security Type Only in the inverter deceleration process, and detected high-voltage DC bus exceeds a predetermined value, the dynamic braking will be implemented 2 : general Type under any state, when the inverter detected high-voltage DC bus exceeds a predetermined value, the dynamic braking will be implemented. When the inverter is running on emergency deceleration state or load great fluctuation, it may appear over-voltage or over-current. This phenomenon is relatively prone to happen when the motor load inertia is heavy. When inverter The inverter internal DC bus detected voltage exceeds a certain value, the output brake signal through an external braking resistor implement energy-braking function. Users can select inverter models with a braking function to apply this feature.</p>						
A09	Less Voltage Level	60%~75%(Standard DC bus voltage)	%	70	Y	
<p>The definition of allowed the lower limit voltage of normal working inverter DC side .For some low power occasions, inverter less voltage value can be appropriately put down in order to ensure the inverter normal working.. Under normal condition, keeping default setting.</p>						
A10	Power-down Tracking Options	N	0	-	0	Y
		Power-off tracking mode	1			
		Startup tracking mode	2			
A11	Power-down tTracking Time	0.0~20.0	s	0.0	Y	

Section V Parameter Function Table

<p>This parameter is used to select the inverter tracking mode.</p> <p>0 : N speed tracking means to start tracking from 0 Hz. 1 : power-down tracking When the inverter instantaneous power off and re-start, the motor will continue running with current speed and direction. If the power off time is longer than A11 set time, the inverter will not re-start power on again. 2 : Startup tracking means that when power on, inverter will first inspect motor direction and speed, and then driving motor with current speed and direction. Set startup tracking function, power off tracking function is still valid.</p>						
A12	Power Down Frequency Drop Point	65~100%(standard DC bus voltage)	%	75	Y	
A13	Power Down Frequency Drop Time	0.1~3200.0	s	5.0	Y	
<p>Correctly setting this parameter can let inverter does not less voltage stop in case of instantaneous power off. When the DC bus voltage drop to frequency drop point A12 set, inverter will decelerate according to deceleration time A13 set and stop outputting power to load. Meanwhile, inverter will use load feedback energy to compensate DC bus voltage dropping and keep inverter working in short time. Power down frequency drop time actually is deceleration time of frequency dropping after power off. If this value set is too large, the load feedback energy is small, then inverter can not compensate for voltage dropping in DC. if this value set is too small and there is large energy feedback from load, the excessive energy compensation may cause inverter over-voltage fault. Set A12 100% to cancel power off frequency dropping function.</p>						
A14	Current Limit	N	0	-	0	Y
		Y	1			
A15	Limit Fall Time	0.1~3200.0	s	10.0	Y	
A16	Limit Deceleration Protection Point	10~250	%	★	Y	
A17	Limit Fix-speed Protection Point	10~250	%	★	Y	

Section V Parameter Function Table

Series	Current limitaiton%	Corresponding parameter
F	120	A17
	130	A16
G	150	A17
	170	A16
M、T、Z	170	A17
	190	A16
H	250	A17
	270	A16

Current limitation function can effectively restrain over-current caused by motor load fluctuation in the process of acceleration and deceleration or constant speed operation.

This function will be good effect for V/F control mode.

Under protection of current lost- speed state, the motor speed will drop. so it is not adapted by systme which is not allowed to automatically drop speed.

In operation process, when the motor current surpass value A16 set, motor will decelerate according to deceleration time A15 set until current below value A16 set.

In operation process, when the motor surpass value A17 set, motor will run with this speed until current below value A17 set.

Deceleration current limitation is prior of constant speed limitation.

A18	Output Phase Lose Protection	N protection of phase lost	0	-	0	Y
		Warning and constant running	1			
		Warning and deceleration	2			
		Warning and free stopping	3			

A19	Grade Of Phase Lose Protection	10~100	%	30	Y
-----	--------------------------------	--------	---	----	---

When ratio of unbalance 3phase output surpass A19 Grade of phase lose protection, the inverter output phase lose protection i will action, and the system display fault PH-O.

Output frequency less than 2.00Hz, there is N output phase lose protection.

Phase lost protection grade=max current difference between phases, which will be according to load condition.

A20	Over Torque Inspected Action	N torque inspection	0	-	0	Y
		Warning and running	1			
		Warning and decelerating stop	2			
		Warning and free stopping	3			

A21	Over Torque Grade	10~250	%	★	Y
-----	-------------------	--------	---	---	---

A22	Over Torque Inspection Time	0.0~60.0	s	0.1	Y
-----	-----------------------------	----------	---	-----	---

Motor output current surpass value A21 set, Over torque inspection will be force and the system will show OL2 fault.

Series	Over torque inspection class	Parameter
F	130	A21
G	170	A21
M、T、Z	190	A21

Section V Parameter Function Table

	H	270	A21			
A23	Electronic Thermal Relay Protection Selection	N	0	-	1	Y
		Y	1			
A24	Electronic Thermal Protection Grade	120~250	%	★	Y	

This function is to protect motor overheating when motor does not use thermal relay. Inverter using some parameters to calculate motor temperature rise, at the same time to determine whether the use of current caused motor overheat. When you choose electronic thermal protection function, the drive output is shutdown after overheating detected also shows information of protection.

0 : No selecting this function

1 : Select this function.

Series	electronic Thermal Protection Level	Parameters
F	120	A24
G	150	A24
M、T、Z	170	A24
H	250	A24

A24 set the electronic thermal protection level. When the current is the rated motor current multiplies the parameter, the drive in 1 minute protects, thermal protection within one minute that means the actual current is A24 times of the rated current.

A25	Fault Reset Times	0~10	-	0	Y
-----	-------------------	------	---	---	---

In the inverter operation process, Over Current expressed by OC、Over Voltage by OU, inverter can automatically recover and run with state of preceding fault. Recovering times will be according to this parameter. It can set 10 times at most. When this parameter is set "0", inverter will not automatically recover after meeting fault. But if relay in DC main circuit meet fault "MCC" or less vottage "LU" fault, inverter will automatically recover without limitation.

Restarting from fault and normally running over 36s, inverter will automatically recover fault reset times preset.

Restarting from fault and normally running over 36s, inverter will automatically recover to display monitor parameter.

After 10 s of meeting fault, inverter will not recover fault reset function.

A26	Fault Reset Time	0.5~20.0	s	1.0	Y
-----	------------------	----------	---	-----	---

Setting interval of fault reset time. When inverter met fault and stopped outputting, and when it inspected without fault time is longer than fault reset time, Inverter will automatically implement fault reset.


A27	Fan Startup Temperature	0.0~60.0	℃	0.0	Y
-----	-------------------------	----------	---	-----	---

Set the fan start temperature. When the actual temperature of theS08is higher than the set temperature

Section V Parameter Function Table

the fan starts. To avoid the the fan frequently starts and stops , the fan stop temperature = A27 fan start temperature -1.0 □.						
A28	This Inverter Communication Address	1~128	-	8	Y	
<p>This Inverter communication address: it is the only code to differentiate from other inverters. Setting range "1~127" is slave inverter address, that can receive command and send out this inverter state. Seeing attachment 1 for detailed specification.</p> <p>The proportion of linkage function: The proportion of linkage host inverter: This inverter communication address=128, Communication interface A is set as host inverter communication interface for proportion of linkage.</p> <p>Communication interface B can be treated as keyboard interface or "PC" Host Computer Interface. The proportion of linkage slave inverter: This inverter communication address =1~127, Communication interface A and B both can be set as communication interface of slave inverter for the proportion of linkage. Seeing appendix 2 for detailed specification.</p>						
A29	Baud Rate	Baud rate is 1200	0	-	4	Y
		Baud rate is 2400	1			
		Baud rate is 4800	2			
		Baud rate is 9600	3			
		Baud rate is 19200	4			
		Baud rate is 38400	5			
<p>The baud rate of communication port A can be set accordingly. The baud rate of communication port B is fixed 19200bps.</p>						
A30	Communication Format	8, N, 1 for RTU	0	-	0	Y
		8, N, 2 for RTU	1			
		8, E, 1 for RTU	2			
		8, O, 1 for RTU	3			
		8, E, 2 for RTU	4			
		8, O, 2 for RTU	5			
Seeing attachment for detailed specification.						
A31	Communications Troubleshooting	N warning for communication fault	0	-	0	Y
		Warning and running	1			
		Warning and decelerating stop	2			
		Warning and free stopping	3			
A32	Delay Inspection Time	0: N inspection	s	10	Y	
		1~250: late inspection				
<p>When communication time between interface A or B surpassed A32 delayt inspection time, the system will warn according to A31 setting. After power on, interface without communication will not implement warning.</p>						

Section V Parameter Function Table

A33	Total Running Time Setting	Auto clear to zero after power on	0	-	1	Y
		Continue to accumulate running time after power on	1			
<p>To set whether the time of inverter running accumulating or not. 0: Auto clear to 0 after power on. 1: Continue to accumulate running time after power on.</p>						
A34	Unit Of Total Running Time	hour	0	-	0	Y
		Day	1			
<p>The set for unit of accumulation running time, only for display of running time. 0: unit /hour display range 0~3200.0 hour. 1: unit/day display range 0~3200.0 day.</p>						
A35	Motor Output Speed Adjustment	0.1~1000.0	%	100.0	Y	
<p>Using for displaying adjustment of motor actual running speed.SeeingA00~A02 monitor options: 6: motor actual running speed. Setting 100%, corresponding display unit : rpm. The max speed of displaying after adjustment is 9999.</p>						
A36	Adjustment Of Motor Output Power	0.1~1000.0	%	100.0	Y	
<p>Used for displaying motor output power of adjustment. Seeing A00~A02 monitor options: 11 :motor output power. Setting 100%, corresponding display unit:%. The max output power of displaying after adjustment is 2999.9.</p>						
A37	Keyboard Lock Function Options	0~OFF	-	OFF	Y	
<p>Key SET+ESC in Keyboard can activate and cancel keyboard lock function. To lock which key will be decided by corresponding parameter :</p> 						
		Set 0~10 bit	Keyboard locked state			
		0	0	Unlock FWD key		
			1	Lock FWD key		
		1	0	Unlock STOP key		
			1	Lock STOP key		
		2	0	Unlock PRG key		
			1	Lock PRG key		
		3	0	unlock SET key		
			1	Lock SET key		
		4	0	Unlock ESC key		
			1	Lock ESC key		

Section V Parameter Function Table

	5	0	Unlock MF1 key									
		1	Lock MF1 key									
		6	0				Unlock MF2 key					
			1				Lock MF2 key					
		7	0				Unlock potentiometer					
			1				Lock potentiometer					
A38	UP/DN Control	1 bit	Power down to save	0	-	0000	Y					
			Power down to clear saving	1								
		10 bit	saving after stopping	0								
			Stop command to clear saving	1								
			Cleared at the end of stopping	2								
		100 bit	One-direction adjustment	0								
			Double-direction adjustment	1								
		1000 bit	Invalide adjustment	0								
			Valide adjustment	1								
		<p>1 bit: UP/DN control saving state after power down 0: power down to save 1: power down to clear</p> <p>10 bit: UP/DN control saving after stopping 0: Keeping afer stopping 1: Stop command to clear saving 2: Cleared at the end of stopping</p> <p>100 bit: UP/DN control direction of adjustment. 0: one direction adjustment, it is one direction adjustment within 0~max frequency range. 1: double direction adjusment, it is FEW and REW adjustment within 0~max frequency range.</p> <p>1000 bit: UP/DN control validity of adjustment. 0: UP/DN invalid ajsument 1 : UP/DN valid adjustment</p>										
		A39	UP/DN Time	1 bit				UP fix speed	0	-	0000	N
								UP fix times	1			
10 bit	DN fix speed			0								
	DN fix times			1								
100 bit	UP N adjustmentof speed ratio			0								
	A11 adjustment of the external analog giving			1								
	A12 adjustment of the external analog giving			2								
	A13 adjustment of the external analog giving			3								

Section V Parameter Function Table

		1000 bit	adjustment of Potentiometer giving	4																																							
			Adjustment of multi -steps digital voltage	5																																							
			DN N adjustmentof speed ratio	0																																							
			A11 adjustment of the external analog giving	1																																							
			A12 adjustment of the external analog giving	2																																							
			A13 adjustment of the external analog giving	3																																							
			Adjustment of Potentiometer giving	4																																							
Adjustment of multi -steps digital voltage	5																																										
<p>1 bit: UP acceleration mode 0: fix speed acceleration, according to A41 fix speed: To increase frequency every 200ms. 1: fix times acceleration, according to fix times: To increase frequency every triggering.</p> <p>10 bit: DN deceleration mode 0: fix speed deceleration, according to A42 fix speed: To reduce frequency every 200ms. 1: fix times deceleration, according to A42 fix times: To reduce frequency every triggering.</p> <p>100 bit: UP adjustment mode of adjusting speed ratio</p> <table border="1"> <tbody> <tr> <td>0</td> <td>UP N Adjustment Of Speed Ratio</td> <td>N adjustment</td> </tr> <tr> <td>1</td> <td>A11 Adjustment Of The External Analog Giving</td> <td>Actual UP adjustment ratio= percentage given by A41*A11</td> </tr> <tr> <td>2</td> <td>A12 Adjustment Of The External Analog Giving</td> <td>Actua UP adjustment ratio= percentage given by A41*A12</td> </tr> <tr> <td>3</td> <td>A13 Adjustment Of The External Analog Giving</td> <td>Actual UP adjustment ratio= percentage given by A41*A13</td> </tr> <tr> <td>4</td> <td>Adjustment Of Potentiometer Giving</td> <td>Actual UP adjustment ratio= percentage given by A41* potentiometer</td> </tr> <tr> <td>5</td> <td>Adjustment Of Multi-steps Digital Voltage</td> <td>Actual UP adjustment ratio=percentage given by A41* multi-steps digital voltage</td> </tr> </tbody> </table> <p>1000 bit: DN adjustment mode of adjusting speed ratio</p> <table border="1"> <tbody> <tr> <td>0</td> <td>N Adjustment Of Acceleration Time</td> <td>N adjustment</td> </tr> <tr> <td>1</td> <td>A11 Adjustment Of The External Analog Giving</td> <td>Actual DN adjustment ratio =percentage given by A42*A11</td> </tr> <tr> <td>2</td> <td>A12 Adjustment Of The External Analog Giving</td> <td>Actual DN adjustment ratio =percentage given by A42*A12</td> </tr> <tr> <td>3</td> <td>A13 Adjustment Of The External Analog Giving</td> <td>Actual DN adjustment ratio=percentage given by A42*A13.</td> </tr> <tr> <td>4</td> <td>Adjustment Of Potentiometer Giving</td> <td>Actual DN adjustment ratio=percentage given by A42*potentiometer</td> </tr> <tr> <td>5</td> <td>Adjustment Of Multi-steps Digital Voltage</td> <td>Actual DN adjustment ratio=percentage given by A42*multi-steps digital vltge.</td> </tr> </tbody> </table>								0	UP N Adjustment Of Speed Ratio	N adjustment	1	A11 Adjustment Of The External Analog Giving	Actual UP adjustment ratio= percentage given by A41*A11	2	A12 Adjustment Of The External Analog Giving	Actua UP adjustment ratio= percentage given by A41*A12	3	A13 Adjustment Of The External Analog Giving	Actual UP adjustment ratio= percentage given by A41*A13	4	Adjustment Of Potentiometer Giving	Actual UP adjustment ratio= percentage given by A41* potentiometer	5	Adjustment Of Multi-steps Digital Voltage	Actual UP adjustment ratio=percentage given by A41* multi-steps digital voltage	0	N Adjustment Of Acceleration Time	N adjustment	1	A11 Adjustment Of The External Analog Giving	Actual DN adjustment ratio =percentage given by A42*A11	2	A12 Adjustment Of The External Analog Giving	Actual DN adjustment ratio =percentage given by A42*A12	3	A13 Adjustment Of The External Analog Giving	Actual DN adjustment ratio=percentage given by A42*A13.	4	Adjustment Of Potentiometer Giving	Actual DN adjustment ratio=percentage given by A42*potentiometer	5	Adjustment Of Multi-steps Digital Voltage	Actual DN adjustment ratio=percentage given by A42*multi-steps digital vltge.
0	UP N Adjustment Of Speed Ratio	N adjustment																																									
1	A11 Adjustment Of The External Analog Giving	Actual UP adjustment ratio= percentage given by A41*A11																																									
2	A12 Adjustment Of The External Analog Giving	Actua UP adjustment ratio= percentage given by A41*A12																																									
3	A13 Adjustment Of The External Analog Giving	Actual UP adjustment ratio= percentage given by A41*A13																																									
4	Adjustment Of Potentiometer Giving	Actual UP adjustment ratio= percentage given by A41* potentiometer																																									
5	Adjustment Of Multi-steps Digital Voltage	Actual UP adjustment ratio=percentage given by A41* multi-steps digital voltage																																									
0	N Adjustment Of Acceleration Time	N adjustment																																									
1	A11 Adjustment Of The External Analog Giving	Actual DN adjustment ratio =percentage given by A42*A11																																									
2	A12 Adjustment Of The External Analog Giving	Actual DN adjustment ratio =percentage given by A42*A12																																									
3	A13 Adjustment Of The External Analog Giving	Actual DN adjustment ratio=percentage given by A42*A13.																																									
4	Adjustment Of Potentiometer Giving	Actual DN adjustment ratio=percentage given by A42*potentiometer																																									
5	Adjustment Of Multi-steps Digital Voltage	Actual DN adjustment ratio=percentage given by A42*multi-steps digital vltge.																																									


Section V Parameter Function Table

A40	UP/DN Adjustment Value	-300.00~300.00	-	0.00	N	
Frequency after adjustment = set frequency + UP/DN adjustment value.						
A41	UP Adjustment Ratio	0.01~20.00	Hz	0.01	Y	
Fix speed: To increase frequency every 200ms. Fix times: To increase frequency every triggering.						
A42	DN Adjustment Ratio	0.01~20.00	Hz	0.01	Y	
Fix speed: To reduce frequency every 200ms. Fix times: To reduce frequency every triggering.						
A43 A44	The Definition Of Multifunction Keys MF1 And MF2	MF is defined as adding function key	0	-	0 1	Y Y
		MF is defined as reducing function key	1			
		MF is defined as free stopping key	2			
		MF is defined as FWD running key	3			
		MF is defined as REV running key	4			
		MF is defined as forward JOG function key.	5			
		MF is defined as reverse JOG function key.	6			
		MF is defined as JOG function key.	7			
		MF is defined as UP function key	8			
		MF is defined as Down function key.	9			
		UP / DN adjusted value reset	10			
keyboard potentiometer setting value reset	11					
The user defined keyboard can define MF key functions.						
0 : MF is defined as adding function key: Under monitor menu, adding function key MF can adding revise frequency F01 set. Under parameter choosing menu, adding function key MF can adjust parameter choice. Under parameter revising menu, adding function key MF can adjust parameter value.						
1 : MF is defined as reducing function key: Under monitor menu, reducing function key MF can reducing revise frequency F01 set Under parameter choosing menu, reducing function key MF can adjust parameter choice. Under parameter revising menu, reducing function key MF can adjust parameter value.						
2 : MF is defined as free stopping key: MF key is valid under monitor menu and select parameter menu, inverter will be free stopping. After free stop, no start command, 1 S later, allow running again..						
3 : MF is defined as FWD running key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be forward running.						
4 : MF is defined as REV running key:						

Section V Parameter Function Table

Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be reverse running.							
5 : MF is defined as forward JOG function key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be forward JOG running.							
6 : MF is defined as reverse JOG function key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be reverse JOG running.							
7 : MF is defined as JOG function key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be JOG running. Running direction decided by F35 bit setting and terminal state.							
8 : MF is defined as UP function key: Pressing MF is always valid, inverter will be UP control, control parameter decided by A38~A42.							
9 : MF is defined as Down function key: Pressing MF is always valid, inverter will be DOWN control, control parameter decided by A38~A42.							
10 : MF is defined as the UP / DN adjusted value reset A40 UP / DN adjusted value reset, level-triggered.							
11 : MF is defined as the setting value of potentiometer on the keyboard A47 keyboard potentiometer setting is reset, level-triggered							
A45	Keyboard Potentiometer X1	0~100.0	%	0.0	Y		
The start point of value keyboard potentiometer set.							
A46	Keyboard Potentiometer X2	0~100.0	%	100.0	Y		
The end point of value keyboard potentiometer set.							
A47	The Value Of Keyboard Potentiometer Set	0.0~100.00	%	-	Y		
Displaying value potentiometer set, which can be revised by potentiometer under monitor menu. Value potentiometer set can be regarded as analog of frequency giving, set value = max frequency * keyboard potentiometer set value. Potentionmeter set value can be regarded as value of PID giving, value of PID giving = keyboard potentiometer set value.							
A48	Keyboard Potentiometer X1 Corresponding Value Y1	-100.0~100.0	%	0.00	Y		
A49	Keyboard Potentiometer X2 Corresponding Value Y2	-100.0~100.0	%	100.00	Y		
A50	Keyboard	1 bit	Saving after power	0	-	0000	Y

Section V Parameter Function Table


	Potentiometer Control	down	Cleared after power down	1				
				0				
		10 bit	Saving after stoppoing	Clear saving after stopping command				0
								1
								2
		100 bit	Reserved					
1000 bit	Reserved							
<p>1 bit: Saving state of potentiometer after power down. 0: Saving after power down. 1: Clearing saving after power down. 10 bit: keeping potentiometer set after stopping. 0: keeping after stopping 1: To clear saving after stop command. 2: To clear saving at end of stopping.</p>								
A51	Temperature Adjustment Of Motor	0.0~200.0	%	100.0	N			
Being used to revise displaying of A54 motor temperature.								
A52	Over-heat Temperature Of Motor	0.0~300.0	□	120.0	N			
A53	Reaction For Motor Over-heat	N reaction for motor over-heat	0	-	0	Y		
		Warning and runing	1					
		Warning and deceleration stopping	2					
		Warning and free stopping	3					
When the displaying value of motor temperature A5 surpassed value A52, inverter will warn and react according to reaction for motor over-heat A53 set.								
A54	Display Of Motor Temperature	-50.0~300.0	°C	-	N			
<p>Shows the motor temperature or temperature at other point. Control card PT100 plug should plug into the optional PT100 thermocouple devices Three lines PT100</p>								
								
A55	Proportion Of Linkage Ratio	0.10~10.00	-	1.00	Y			
<p>In application of proportion of linkage, A55 setting is multiply ratio of that when slave inverter received setting frequency command from host inverter. Setting this inverter as one slave inverter of system for proportion of linkage. Frequency Keyboard F01 set = proportion of linkage ratio* frequency S00 set by host inverter</p>								

5-5. IO function group:o00-o68(0x0200-0x0244)


Section V Parameter Function Table

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
o00	AI1 Input X1	0~100.0	%	0.0	Y
o01	AI1 Input X2	0~100.0	%	100.0	Y
o02	AI2 Input X1	0~100.0	%	0.0	Y
o03	AI2 Input X2	0~100.0	%	100.0	Y
o04	AI3 Input X1	0~100.0	%	0.0	Y
o05	AI3 Input X2	0~100.0	%	100.0	Y
o06	AI1 Input X1 Corresponding Value Y1	-100.0~100.0	%	0.0	Y
o07	AI1 Input X2 Corresponding Value Y2	-100.0~100.0	%	100.0	Y
o08	AI2 Input X1 Corresponding Value Y1	-100.0~100.0	%	0.0	Y
o09	AI2 Input X2 Corresponding Value Y2	-100.0~100.0	%	100.0	Y
o10	AI3 Input X1 Corresponding Value Y1	-100.0~100.0	%	0.0	Y
o11	AI3 Input X2 Corresponding Value Y2	-100.0~100.0	%	100.0	Y

Under the situation Max frequency = 50.00hz:



X1=0%, Y1=0% potentiometer 0V corresponding set frequency: $f = \text{Max frequency} * Y1 = 0.00\text{Hz}$
 X2=100%, Y2=100% potentiometer 10V corresponding set frequency: $f = \text{Max frequency} * Y2 = 50.00\text{Hz}$



X1=20%, Y1=0% potentiometer 2V corresponding set frequency: $f = \text{Max frequency} * Y1 = 0.00\text{Hz}$
 X2=50%, Y2=50% potentiometer 5V corresponding set frequency: $f = \text{Max frequency} * Y2 = 25.00\text{Hz}$

Section V Parameter Function Table

AI1, AI2, AI3

$X1=0\%$, $Y1=20\%$ potentiometer 0V corresponding set value: $f=Max\ frequency*Y1=10.00Hz$
 $X2=50\%$, $Y2=50\%$ potentiometer 5V corresponding set value: $f=Max\ frequency*Y2=25.00Hz$

AI1, AI2, AI3

$X1=0\%$, $Y1=-100\%$ potentiometer 0V corresponding set frequency: $f=Max\ frequency*Y1=-50.00Hz$
 $X2=100\%$, $Y2=100\%$ potentiometer 10V correspond set frequency: $f=maximum\ frequency*Y2=50.00Hz$

Skipping thread of AI1, AI2, AI3 respectively are JP3/JP5, JP6, JP7, seeing the following detailed specification:

JP3
 1 -10V~+10V DC
 2
 3 0~+10V DC (default)

JP5 Disconnesso 0~+10V DC (default) In corto 0~20mA DC
 JP6 Disconnesso 0~+10V DC Shorted 0~20mA DC (Default)
 JP7 Disconnesso 0~+10V DC Shorted 0~20mA DC (Default)

o12	AI1 Input Filter Time	0.00~2.00	s	0.10	Y
o13	AI2 Input Filter Time	0.00~2.00	s	0.10	Y
o14	AI3 Input Filter Time	0.00~2.00	s	0.10	Y

Filter time constant of analog signal input, that is 0.00~2.00s. If time parameter is set too long, the changement of setting frequency will be stable, but responding speed will be slow; If time parameter is set too short, the changement of setting frequency will not be stable, but responding speed will be quick.

o15 o16	DA1 Output Terminal DA2 Output Terminal	N reaction	0	-	-	Y
		Setting frequency	1			
		Actual frequency	2			
		Actual current	3			
		Output voltage	4			
		DC bus voltage	5			
		IGBT temperature	6			

Section V Parameter Function Table

		Output power	7			
		Output RPM	8			
		Actual value of torque	9			

o17	DA1 Adjustment Of Lower Limit Output	0.0~100.0	%	0.0	Y
o18	DA1 Adjustment Of Upper Limit Output	0.0~100.0	%	100.0	Y
o19	DA2 Adjustment Of Lower Limit Output	0.0~100.0	%	0.0	Y
o20	DA2 Adjustment Of Upper Limit Output	0.0~100.0	%	100.0	Y

Output Content	Setting Value	Giving Output Singla Range
N Reaction	0	N output
Setting Frequency	1	0~Max frequency
Actual Frequency	2	0~Max frequency
Actual Current	3	0~200%, corresponding parameter: S03 percentage of output curent
Output Voltage	4	0~200%, corresponding parameter: b02、 b15 rate voltage of motor
DC Bus Voltage	5	0~1000VDC, DC voltage
IGBT Temperature	6	0~100.0℃
Output Power	7	0~200%
Output RPM	8	0~Max RPM
Actual Value Of Torque	9	0~200% torque

the corresponded output frequency

0Hz



10.0% 20.0% 50.0% 100.0% Voltage/Current
 0V/0mA 10V/20mA

DA1 DA2

This parameter is used for setting upper/lower limitation of DA1/DA2 output signal.

Such as:
 If DA1 output 1~5V voltage, setting parameter as: o17=10.0%, o18=50.0%
 If DA2 output 4~20mA current, setting parameter as: o19=20.0%, o20=100.0%
 DA1, DA2 Skipping thread:

Section V Parameter Function Table

<p>JP1 2-3 shorted (Default)  DA1V 0-10V DC 1-2 shorted DA1C 0-20mA DC</p>		<p>JP2 2-3 shorted (Default)  DA2V 0-10V DC 1-2 shorted DA2C 0-20mA DC</p>				
<p>Caution: Every terminal has choice of voltage output and current output, the default setting is voltage output. When the voltage output is needed, please connect JP1/JP2 and DA1V/DA2V(seeing the panel); When the current output is needed, please connect JP1/JP2 and DA1C/DA2C.</p>						
		N function	0			
		Fault warning	1			
		Over current inspection	2			
		Over load inspection	3			
		Over voltage inspection	4			
		Less voltage inspection	5			
		Low load inspection	6			
		Over heat inspection	7			
		Running state with command	8			
		Abnormal PID feedback signal	9			
		Motor state of REW running	10			
		Arrival of setting the frequency	11			
		Arrival of Upper frequency	12			
		Arrival of Lower frequency	13			
		Arrival of FDT setting frequency 1	14	-	0	Y
o21	O1 Output Signal Option1	Arrival of FDT setting frequency 2	15	-	0	Y
o22	Option 2	FDT frequency level inspection	16	-	1	Y
o23	O3 Output Signal Option 3	Arrival of preset counter value	17	-	8	Y
o24	O4 Output Signal Option 4	Arrival of upper limit counter	18			
		Program running one period completed	19			
		Speed tricking mode inspection	20			
		N command running state	21			
		REV running from inverter command	22			
		Deceleration running	23			
		Acceleration running	24			
		Arrival of high pressure	25			
		Arrival of low pressure	26			
		Arrival of inverter rate current	27			
		Arrival of motor rate current	28			
		Arrival of input frequency lower limitation	29			

Section V Parameter Function Table

		Arrival of current upper limitation	30			
		Arrival of current lower limitation	31			
		Time to reach limit time 1	32			
		Time to reach limit time 2	33			
		Inverter ready to run	34			
Setting Value	Output Content	Specification Explanation				
0	N Function	Setting "0", N output reaction, but inverter can be controlled by theoretical terminal.				
1	Fault Warning	Inverter at fault or after fault with unconfirmed status.				
2	Over Current Inspecton	Inverter met fault of over current				
3	Over Load Inspecton	Inverter met fault of over load of heat protection				
4	Over Voltage Inspecton	Inverter met fault of over voltage				
5	Less Voltage Inspecton	Inverter met fault of less vltage				
6	Lower Load Inspection	Inverter met fault of lower load				
7	Over Heat Inspecton	Inverter met fault of over heat.				
8	Running State Of Command	Inverter is under running state of command				
9	Abnormal PID Feedback Signal	PID feedback signal is abnormal				
10	Motor State Of REW Running	Motor is reverse running				
11	Arrival Of Setting Frequency	Arrive at set frequency				
12	Arrival Of Upper Frequency	Arrive at upper frequency				
13	Arrival of lower frequency	Arrive at lower frequency				
14	Arrival Of FDT Set Frequency1	Arrive at frequency 1 FDT set				
15	Arrival Of FDT Set Frequency2	Arrive at frequency 2 FDT set				
16	Inspection Level Of FDT Frequency	FDT frequency levels to meet the inspection conditions,o29~o31				
17	Arrival Of Preset Counting Value	Present counting value arrives at preset counting value				
18	Arrival Of Counting Value Upper Limitation	Present counting value arrives at upper limitation of counting value.				
19	Program Running One Period Completion	Program runs one period to complete.				
20	Inspection In Speed Trick Mode	Inverter is under speed trick state, the valid time is A11				
21	N Command Running State	Inverter is under N command running state				
22	REW Command Of Inverter	Inverter is under reverse running command				
23	Deceleration Running	Inverter is under deceleration running				
24	Acceleration Running	Inverter is under acceleration running				
25	Arrival Of High Pressure	Arrival at hight pressure				
26	Arrival Of Low Pressure	Arrival at low pressure				

Section V Parameter Function Table

27	Arrival Of Inverter Rate Current	Arrival at inverter rate current
28	Arrival Of Motor Rate Current	Arrival at motor rate current
29	Arrival Of Input Frequency Lower Limitation	Present set frequency is less than frequency lower limitation
30	Arrival Of Current Upper Limitation	Arrive at current of upper limitation
31	Arrival Of Current Lower Limitation	Arrive at current of lower limitation
32	Time to reach limit time 1	Timing action mode refer to o65 configuration
33	Time to reach limit time 2	Timing action mode refer to o66 configuration
34	Inverter ready to run	The end of initialization when the drive power on , running command is acceptable.

o25	Output Signal Delay 1	0~32.000	s	0	Y
o26	Output Signal Delay 2	0~32.000	s	0	Y
o27	Output Signal Delay 3	0~32.000	s	0	Y
o28	Output Signal Delay 4	0~32.000	s	0	Y
o25~o28 defines o21~o24 output signal reaction delay time, unit is S. Output signal cut off action without delay.					
o29	FDT Set Frequency 1	o30~Max frequency	Hz	0.00	Y
o30	FDT Set Frequency 2	0~o29	Hz	0.00	Y
o31	FDT Inspection Range	0.00~5.00	Hz	0.00	Y

When the choice of output signal(o21~o24)is set as14, inverter output frequency arrives at or surpass FDT set frequency 1, the corresponding signal output terminal will react; When inverter output frequency is below of frequency 1 FDT set, the corresponding signal output terminal will not react.

When the output signal options(o21~o24)is set as 15, inverter output frequency reaches or surpass FDT set frequency 2, the corresponding signal output terminal will react;When inverter output frequency is below of frequency 3 FDT set, the corresponding signal output terminal will not react.

When the output signal options (o21~o24)is set as16, inverter will firstly inspect FDT set frequency 1, then inverter output frequency arrives at or surpass FDT set frequency 1, the corresponding signal output terminal will react;After terminal reaction, inverter will inspect FDT set frequency 2, When inverter output frequency is below of frequency 2 FDT set, the corresponding signal output terminal will not react.


o31 frequency inspection range

This parameter is used to define inspection range. When the difference of actual frequency and inspected frequency has surpassed inspection range, terminal will output react.


e.g.: FDT set frequency 1 as 35Hz, FDT set frequency 2 as 30Hz,

Frequency inspection range is 0, the signal output terminal will react as below:

Section V Parameter Function Table



o32	Arrival Of Current Upper Limitation	o33~200%	%	120	Y
o33	Arrival Of Current Lower Limitation	o34~o32	%	20	Y
o34	Current Inspection Range	0~o33	%	3	Y



When the output signal options (o21~o24)is set as 30, and inverter output current reach or surpass "o32+o34", the corresponding output signal terminal will react. When the inverter output current is less than o32-o34, The corresponding output signal terminal will not react.

When the output signal options (o21~o24)is set as 31, and inverter output frequency reach or less than o33-o34, the corresponding output signal terminal will react;When the inverter output current is more than o33+o34, The corresponding output signal terminal will not react.

o34 is used to define current inspection range. When the difference of actual current and inspected current has surpassed inspection range, The output terminal will react.

o35	Terminal Control Mode	bit	Two-wire running control 1	0	-	0000	N
			Two-wire running control 2	1			
			Three-wire running control 1	2			

Section V Parameter Function Table

		Three-wire running control 2	3			
		One-shot operation control 1	4			
		One-shot operation control 2	5			
	10 bit	Terminal command is invalid after power on running	0			
		Terminal command is valid after power on running	1			

Setting terminal running mode by this parameter.


1 Bit set terminal running mode:

The polarity of electrical level is 047 default setting polarity. Low electrical level or falling edge is valid, and the terminal is leakage-source driving mode.

X can be used to express high or low electrical level, rising or falling edge.


Running Control Mode	Keyboard Running Control	Prior Running	Prior Direction
Edge Trigger	Valid	Same	Same
E-level Trigger	Invalid	Prior running	Prior FWD

0: Two wire running control 1



F05=1 or F05=4		F05=3		Command
FWD	REV	FWD	REV	
Falling edge	X	Low E Level	X	FWD running
X	Falling edge	High E-level	Low E-level	REV running
Rising edge	Rising edge	High E-level	High E-level	STOP running


1: Two wire running control 2



F05=1 or F05=4		F05=3		Command
FWD	REV	FWD	REV	
Falling edge	Falling edge	Low e-level	Low e-level	FWD running
Falling edge	Rising edge	Low e-level	High e-level	REV running
Rising edge	X	High e-level	X	STOP running


Section V Parameter Function Table

2: Three wire running control 1




F05=1 ; F05=3; F05=4			Command
FWD	REV	STOP	
Falling edge	Low e-level	Low e-level	FWD running
Falling edge	High e-level	Low e-level	REV running
X	X	High e-level	STOP running

3: Three wire running control 2




F05=1 ; F05=3; F05=4			Command
FWD	REV	STOP	
Falling edge	X	Low e-level	FWD running
X	Falling edge	Low e-level	REV running
X	X	High e-level	STOP running

4: One-shot operation control 1







F05=1; F05=4; F05=3		Command	Current state
FWD	REV		
	X	FWD running	STOP running
Keep		REV running	STOP running
	X	STOP running	FWD running
Keep		REV running	FWD running
	X	FWD running	REV running
Keep		STOP running	REV running

5: One-shot operation control 2



Section V Parameter Function Table

F05=1; F05=4; F05=3		Command	Current state
FWD	REV		
	Low e-level	FWD running	STOP running
	High e-level	REV running	STOP running
	X	STOP running	FWD running
	X	STOP running	REV running

10 bit: Set the terminal status when power on
0: Terminal run command invalid when Power on.
Terminal run command invalid when power on., Only run 3S later after power on and set terminals invalid.
1: Terminal run command valid when Power on.
Terminal status is effective when power on, inverter will run immediately, in some cases such status will not be allowable.

o36 o37 o38 o39 o40 o41 o42 o43 o44 o45 o46	(DI1) Input Terminal Function Selection (DI2) Input Terminal Function Selection (DI3) Input Terminal Function Selection (DI4) Input Terminal Function Selection (DI5) Input Terminal Function Selection (DI6) Input Terminal Function Selection (DI7) Input Terminal Function Selection (DI8) Input Terminal Function Selection (AI1) Input Terminal Function Selection (AI2) Input Terminal Function Selection (AI3) Input Terminal Function Selection	No function	0			
		Forward running FWD	1			
		Reverse running REV	2			
		3-line mode running STOP	3			
		Multi-segment command 1	4			
		Multi-segment command 2	5			
		Multi-segment command 3	6			
		Multi-segment command	7			
		Multi-segment speed command 1	8			
		Multi-segment speed command	9	-	0	Y
		Multi-segment speed command 3	10	-	0	Y
		Multi-segment digital voltage 1	11	-	0	Y
		Multi-segment digital voltage 2	12	-	0	Y
		Multi-segment digital voltage 3	13	-	0	Y
		The main set mode 1 of set frequency	14	-	0	Y
		The main set mode 2 of set frequency	15	-	0	Y
		The main set mode 3 of set frequency	16	-	0	Y
		The auxiliary setting mode 1 of frequency set	17			
		The auxiliary setting mode 2 of frequency set	18			
		The auxiliary setting mode 3 of frequency set	19			
		MSS time running 1	20			
		MSS time running 2	21			
MSS time running 3	22					

Section V Parameter Function Table

		Operation control mode shift 1	23			
		Operation control mode shift 2	24			
		Operation control mode shift 3	25			
		Forward torque limit shift 1	26			
		Forward torque limit shift 2	27			
		Forward torque limit shift 3	28			
		Reverse torque limit shift 1	29			
		Reverse torque limit shift 2	30			
		Reverse torque limit shift 3	31			
		Torque speed shift	32			
		fault reset command	33			
		FWD JOG command	34			
		REV JOG command	35			
		JOG order (as F35setting)	36			
		Acceleration and deceleration prohibition command	37			
		Motor 1、 2 shift	38			
		Free stop	39			
		Up command	40			
		Down command	41			
		Automation program running fuction cancel	42			
		Automation program running stop	43			
		Program running start mode	44			
		Program running stop mode	45			
		Pulse counter clearance	46			
		Pulse counter input	47			
		Counter loading	48			
		Upper counter loading	49			
		External default signal input (level)	50			
		1 pump soft-start	51			
		1 pump stop	52			
		2 pump soft-start	53			
		2 pump stop	54			
		3 pump soft-start	55			
		3 pump stop	56			
		4 pump soft-start	57			
		4 pump stop	58			

Section V Parameter Function Table

	handrotate command	59			
	Timing Water Supply change to zero	60			
	Extruder acceleration and deceleration direction	61			
	Extruder acceleration and deceleration allowable	62			
	Limit time 1 input	63			
	Limit time 2 input	64			
	Program switching to the next segment	65			
	UP/DN adjusted value reset	66			
	Keyboard potentiometer set value reset	67			
	External default signal input (edge)	68			

Setting Value	Output Detail	Specification Explanation
0	No- function	N- function
1	Forward command FWD	Forward command FWD, Can be set to edge triggered or level-triggered
2	Reverse command REV	Reverse command REV, Can be set to edge triggered or level-triggered
3	Three line running STOP	o35 setting 3 line running, STOP function
4	Multi-speed command 1	Synthes is of 16 multi-speed settings. See H parameter Group
5	Multi-speed command 2	
6	Multi-speed command 3	
7	Multi-speed command 4	
8	multi-acceleration command 1	Synthes is of 8 acceleration settings. See H parameter Group
9	multi-acceleration command 2	
10	multi-acceleration command 3	
11	multi-segment digital voltage 1	Synthes is of 8 digital voltage settings. See H parameter Group
12	multi-segment digital voltage 2	
13	multi-segment digital voltage 3	
14	The main set mode 1 of set frequency	Synthesized frequency given to the way the main switch. See F parameter group
15	The main set mode 2 of set frequency	
16	The main set mode 3 of set frequency	
17	The auxiliary setting mode 1 of frequency set 1	

Section V Parameter Function Table

18	The auxiliary setting mode 2 of frequency set	See F parameter set
19	The auxiliary setting mode 3 of frequency set	
20	MSS timing running 1	Synthes is of segment 8 run time setting. See H parameter set.
21	MSS timing running 2	
22	MSS timing running 3	
23	Operation control mode shift 1	Synthes is of operation mode switching. Read F05 parameter
24	Operation control mode shift 2	
25	Operation control mode shift 3	
26	Forward torque limit shift 1	Synthes is of reverse torque limit switch. See C parameter set C15 Group
27	Forward torque limit shift 2	
28	Forward torque limit shift 3	
29	Reverse torque limit shift 1	Synthes is of reverse torque limit switch. See C parameter set C16 Group
30	Reverse torque limit shift 2	
31	Reverse torque limit shift 3	
32	Torque speed shift	Vector control mode, speed control mode and torque control mode switching. Disconnected status: Speed Control Closed Status: torque control Detail C parameter set C18
33	Fault reset command	Edge-triggered, the fault occurred on the current failure to confirm or not confirm
34	FWD JOG command	JOG forward running command
35	REV JOG command	JOG reverse running command
36	JOG command(as F35 setting)	JOG running command, direction, set a direction in accordance with F35.
37	Acceleration and deceleration forbid command	To maintain the current state to prohibit the acceleration and deceleration movements.
38	Motor 1、2 shift	Motor 1、2 change Invalid status : Motor 1 Valid status : Motor 2
39	Free stop	Free stop: After free stop, no start command, after 1s, allows running again
40	Up command	Up order, detail A38~A42
41	Down command	Down order, detail A38~A42
42	Auto-run feature programs canceled	Cancel program running function
43	Automatic procedures to suspend operation	program running pause
44	program running start mode	program running start mode
45	program running stop mode	program running stop mode

Section V Parameter Function Table

46	pulse count clearance	Edge-triggered,frequency inverter pulse counter o53Clearance			
47	pulse count input	Edge-triggered, set the pulse counter input terminal			
48	before count loading	Edge-triggered, pulse-load preset counter o53counts to o54			
49	upper count loading	Edge-triggered pulse counter counts o5 maximum load o53			
50	External default signal input (level)	External default signal input(level), level trigger , the system will alarm E_Set after valid			
51	1 pump soft-start	Electric level spring, control 1 pump soft-start or stop. soft-start control must use 2 terminal control, stop priority.			
52	1 pump stop	Need to set E01 load model 9, E12 1pump is soft-start control pump.			
53	2 pump soft-start	Electric level spring, control 2 pump soft-start or stop. soft-start control must use 2 terminal control,stop priority.			
54	2 pump stop	Need to set E01 load model 9, E12 2pump is soft-start control pump.			
55	3pump soft-start	Electric level spring, control 3 pump soft-start or stop. soft-start control must use 2 terminal control, stop priority.			
56	3 pump stop	Need to set E01 load model 9 , E12 3pump is soft-start control pump.			
57	4 pump start	Electric level spring, control 4 pump soft-start or stop. Soft-start control must use two terminal control, stop has the priority.			
58	4 pump stop	Need setting E01 load style 9, E12 4 pump is soft - start control pump.			
59	Hand change order	electric level spring, automation multi-pump constant water changed			
60	the period of time water supply change to zero	electric level spring the period of time water supply change to zero			
61	Extruder acceleration and deceleration direction	Dlx input terminal function selection, read o36- 046			
62	Extruder acceleration and deceleration allowable	Dlx input terminal function selection, read o36-046.			
63	Limit time 1 input	Dlx input timeing - limit time 1, refer to o65, o67.			
64	Limit time 2 input	Dlx input timeing - limit time 2, refer to o66, o68			
65	Program switching to the next segment	Program running controlled, single trigger switch to the next segment			
66	UP/DN adjusted value reset	A40 UP/DN adjusted value reset, level trigger.			
67	Keyboard potentiometer set value reset	A47keyboard potentiometer setting value reset level trigger.			
68	External default signal input (edge)	External default signal input, edge trigger (falling edge),the system will alarm E-Set after valid			
o47	Polarity of input and output terminals	0000~F7FF	-	0000	Y
This parameter used to select every IO terminal is valid in which polarity and terminal running command is valid or not when power on.					

Section V Parameter Function Table

0~10 bit	Input Terminal Polarity	12~15 bit	Output Terminal Polarity				
0	Low level valid(closed)	0	Lo w level valid(closed)				
	Falling edge valid, rising edge invalid						
1	High level valid(disconnected)	1	High level valid(cut off)				
	Rising edge valid, falling edge invalid						
o48	Input Terminal Teponse Time 0	0.001~30.000	s	0.005	Y		
o49	Input Terminal Reponse Time 1	0.001~30.000	s	0.005	Y		
o48,o49define Input terminal reponse time,through o50select the reponse time according theterminal.							
o50	Input Terminal Reponse Time Selection	0~07FF	-	0	Y		
o48, o49 define Input terminal reponse time, through o50 select the reponse time according theterminal. The delay time of the input terminal is valid to the close and cut off action! Set the parameter choose Input terminal reponse time according every terminal.							
Setting 0~10		the polarity of input terminal					
0		o48 input terminal reponse time 0					
1		o49 input terminal reponse time 1					
o51	Counter Collocation	1 bit	Circle counter operating	0	-	0	Y
			Single cycle counter running	1			
		10 bit	Arrive at upper counter value and reload	0			
			Arrive at upper	1			

Section V Parameter Function Table

			counter value and clear savings			
		100 bit	Power on to reload	0		
			power on to clear savings	1		
			power on to keep previous count status	2		
		1000 bit	Count period	0		
			Output signal valid time 20ms	1		
			Output signal valid time 100ms	2		
			Output signal valid time 500ms	3		
<p>1 bit: Control count mode</p> <p>0: Circulate count, Arrive at upper counter value, output the arrival pulse(output terminal setting)</p> <p>1: single circulate count, after arrive at upper counter value, output the arrival pulse, stop running.</p> <p>10 bit : Operating after circulate mode reach upper limit count</p> <p>0: Reload</p> <p>1: Clear up</p> <p>100 bit: Define the status of the counter after power on</p> <p>0: Reload after power on</p> <p>1: Clear up after power on</p> <p>2: Keep the status of the previous count</p> <p>1000 bit: Define o21~o24 is set to reach the preset count or counts to reach the maximum output signal delay time</p> <p>0: Count period, when reach this digital, keep this status valid, direct the change of the count.</p> <p>1: the valid time of the output signal 10ms, when reach this count, fixed keep the output status valid 10ms.</p> <p>2: the valid time of the output signal 100ms, when reach this count, fixed keep the output status valid 100ms.</p> <p>3: the valid time of the output signal 500ms, when reach this count, fixed keep the output status valid 500ms.</p>						
o52	Maximum Pulse Input Frequency	0.1~50.0	kHz	20.0	Y	
<p>This parameter define the most pulse input frequency of analog setting frequency .</p> <p>Input high signal frequency, only through multi-function input terminal Di8 as the pulse input terminal.</p> <p>input pulse setting frequency according the the most input upper limit.</p> <p>input pulse setting frequency, most input pulse frequency o52 according the most output frequency F12.</p> <p>Pulse input frequency f_{pulse} corresponding setting frequency f_{set} formula: $f_{set} = f_{pulse} / o52 * F12$.</p> <p>Pulse input analog setting, input most pulse frequency o52 according 100.0%.</p> <p>Pulse input frequency f_{pulse} corresponding analog p_{set} formula: $p_{set} = f_{pulse} / o52 * 100.0\%$.</p>						
o53	Current Counter Status	0~9999	-	0	Y	
o54	Preset Counter Setting	0~ o55	-	0	Y	
o55	Upper Limit Counter Setting	o54~9999	-	9999	Y	

Section V Parameter Function Table

<p>the thousand of O51 set t</p>											
<p>When the pulse signal of the input terminal satisfy with the preset condition, Yi terminal output the corresponding indication.</p> <p>1 、 Selection of Input terminal DiX (X=1~8)</p> <p>Input terminal is set to “pulse count input”, and set o54、 o55.</p> <p>Input terminal is set to “pulse counter clear”, after terminal works, counter is cleared.</p> <p>Input terminal is set to “upload of pulse count value”, after terminal works, counter uploads preset count value.</p> <p>Input terminal is set to “upload of upper count value”, after terminal works, counter uploads the upper count value.</p> <p>2 、 Selection of Output Terminal o21~o24</p> <p>o21 set the arrival of preset count, the effective time of output signal after reaching up count value is set by o51.</p> <p>o22 set the arrival of up count value, the effective time of output signal after arriving at the upper count value is set by o51.</p> <p>Frequency range of counting pulse signal: 0~100Hz.</p>											
o56	Virtual Terminal Effective Selection	0000~F7FF	-	0000	Y						
<p>This parameter is used to select a terminal whether each virtual terminal functionality is valid.</p> <table border="1"> <tr> <th>Setting 0~10</th> <th>Virtual terminal valid choose</th> </tr> <tr> <td>0</td> <td>Actual input terminal valid</td> </tr> <tr> <td>1</td> <td>Virtual input terminal valid</td> </tr> </table>						Setting 0~10	Virtual terminal valid choose	0	Actual input terminal valid	1	Virtual input terminal valid
Setting 0~10	Virtual terminal valid choose										
0	Actual input terminal valid										
1	Virtual input terminal valid										
o57	DI1~4 Terminal Status	0000~1111	-	-	Y						
o58	DI5~8 Terminal Status	0000~1111	-	-	Y						
o59	AI1~3 Terminal Status	000~111	-	-	Y						
o60	O1~4 Terminal Status	0000~1111	-	-	Y						
<p>Make the actual terminal can only be effective check terminal state.</p> <p>Make the Virtual terminal can only be effective through register check terminal state.</p>											
o61	PL1 Pulse Output	No action	0	-	0	Y					
o62	PL2 Pulse Output	Set frequency	1	-	0	Y					
		Actual frequency	2	-	0	Y					
		Actual current	3	-	0	Y					

Section V Parameter Function Table

		Output voltage	4																																				
		DC bus voltage	5																																				
		IGBT temperature	6																																				
		Output power	7																																				
		Output rpm	8																																				
		Actual torque	9																																				
o63	SPA pulse output ratio	1~1000	-	1	Y																																		
o64	SPB pulse output ratio	1~1000	-	1	Y																																		
<p>SPA, SPB provide two isolated pulse output signal can be analogical multiple analog output signals.</p> <p>SPA, SPB provide high speed pulse output function. Set by o61~o64 and set functions valid when inverter power on again.</p> <p>SPA corresponding output signal 1, this function selected, o21 DO1 output action is invalid. SPB corresponding output signal 2, this function selected, o22 DO2 output action is invalid. Pulse output ratio = 1, output signal range 0 ~ 50hz. Maximum pulse output frequency 50 Khz, minimum frequency 1hz. for example SPA pulse output options = 2 Actual frequency ; SPA pulse output options = 10 The actual output pulse frequency = actual frequency / maximum frequency * 50hzx10. SPA pulse output options =3 Actual current SPB pulse output ratio=20 The actual output pulse frequency = actual current percentage 200*50hz*20</p> <table border="1"> <thead> <tr> <th>Output</th> <th>Set Value</th> <th>Output Signal Range Definition</th> </tr> </thead> <tbody> <tr> <td>No action</td> <td>0</td> <td>No output</td> </tr> <tr> <td>Set frequency</td> <td>1</td> <td>0~Max frequency</td> </tr> <tr> <td>Actual frequency</td> <td>2</td> <td>0~Max frequency</td> </tr> <tr> <td>Actual current</td> <td>3</td> <td>0~200%, corresponding parameter: S03 output current percentage</td> </tr> <tr> <td>Output voltage</td> <td>4</td> <td>0~200%, correlation parameter: b02、b15 motor rated voltage</td> </tr> <tr> <td>Bus voltage</td> <td>5</td> <td>0~1000V DC voltage</td> </tr> <tr> <td>IGBT temperature</td> <td>6</td> <td>0~100.0℃</td> </tr> <tr> <td>Output power</td> <td>7</td> <td>0~200%</td> </tr> <tr> <td>Output torque</td> <td>8</td> <td>0~Max torque</td> </tr> <tr> <td>Actual torque value</td> <td>9</td> <td>0~200% torque</td> </tr> </tbody> </table>							Output	Set Value	Output Signal Range Definition	No action	0	No output	Set frequency	1	0~Max frequency	Actual frequency	2	0~Max frequency	Actual current	3	0~200%, corresponding parameter: S03 output current percentage	Output voltage	4	0~200%, correlation parameter: b02、b15 motor rated voltage	Bus voltage	5	0~1000V DC voltage	IGBT temperature	6	0~100.0℃	Output power	7	0~200%	Output torque	8	0~Max torque	Actual torque value	9	0~200% torque
Output	Set Value	Output Signal Range Definition																																					
No action	0	No output																																					
Set frequency	1	0~Max frequency																																					
Actual frequency	2	0~Max frequency																																					
Actual current	3	0~200%, corresponding parameter: S03 output current percentage																																					
Output voltage	4	0~200%, correlation parameter: b02、b15 motor rated voltage																																					
Bus voltage	5	0~1000V DC voltage																																					
IGBT temperature	6	0~100.0℃																																					
Output power	7	0~200%																																					
Output torque	8	0~Max torque																																					
Actual torque value	9	0~200% torque																																					
o65	Limit time 1	1 Bit	Boot time	0	-	0000	Y																																
o66	Limit time 2 configuration	1 Bit	Running timing	1	-	0000	Y																																

Section V Parameter Function Table

	Limit time 2 configuration	10Bit	Reserved	-			
		100Bit	Reserved	-			
		1000Bit	Reserved	-			
<p>1 Bit: Timing mode 0 Boot time , timing of runnig and breaking 1 Running timing , only timing of running</p> <p>10 Bit: Reserved 100 Bit: Reserved 1000 Bit: Reserved</p>							
o67	Limit Time 1	0.0~3200.0		s	2.0	Y	
o68	Limit Time 2	0.0~3200.0		s	2.0	Y	
<p>Set timeing of limit time 1 , Time limit 2 Actual limit time on the basis of the set time multiplied by a run time multiple, such time multiple set by the ten bit of F49, refer to F49 instructions.</p>							
5-6. Multi-speed PLC Group:H00-H55(0x0300-0x0337)							
Code	Description / LCD	Setting Range		Unit	Factory Setting	Change Limited	
H00	Multi-speed Collocation	1 bit	Program running function cancel	0	-	0000	Y
			Program running function	1			
		10 bit	Direction decided by H40~H46	0			
			Direction decided by Terminal and keyboard	1			
		100 bit	Deceleration and acceleration time decided by H26~H39	0			
			Time of acceleration and deceleration isdecided by terminal	1			
		1000 bit	Running time decided by H18~H25	0			
			Running time decided by terminal	1			
<p>1 bit: Program running functions intelligent To use the program to run PLC functionality requires setting the bit to 1. Multi-segment speed run only need to set the corresponding multi-stage o36 ~ o46-speed switching can be used without the need to set this parameter. 0: Program running functions cancel 1: Program running function intelligent</p> <p>10 bit: Define program runs or direction settings of multi-segment speed running 0: the direction decided by the H40 ~ H46 1: The directiondecided by the keyboard or terminal</p>							


Section V Parameter Function Table

<p>100 bit: Define program runs or acceleration and deceleration time settings of multi-segment speed running 0: deceleration time decided by the H26 ~ H39 1: The acceleration and deceleration time determined by terminal 1000 bit: Set running time of defined program running 0: running-time decided by the H18 ~ H25 1: Running time decided by terminal</p>							
H01	Program Running Configuration	1 bit	sequence control	0	-	0710	Y
			terminal control	1			
		10 bit	Program running start segment	0~15			
			Program running end segment	0~15			
		1000 bit	Output signal valid time 8ms	0			
			Output signal valid time 20ms	1			
Output signal valid time 100ms	2						
Output signal valid time 500ms	3						
<p>1 bit: program run control mode. 0: sequential control Run automatically according to the start segment, end segment and program running time of program running. You can use o36 ~ o46 switchover next function, switchover to the next program running. 1: Terminal control Use multi segment control terminal o36 ~ o46 multi segment instruction 1, 2, 3, 4, Control program segment, running time arrives, Running based on the 0 paragraph speed. After Multi - Stage speed control terminal switchover, reevaluate running time Do not use of multi - stage speed control terminal o36 ~ o46 multi - speed instruction, You can use o36 ~ o46 switchover next function. The terminal control for single trigger, triggered once, program running to next paragraph, running time recalculated. Running time of arrival, Running based on the 0 paragraph speed. 10 bit: defining the start running of the Program 100 bit: Defines the end of the program period 1000 bit: Define effective time of the program output signal</p>							
H02	Program Running Mode	1 bit	single-cycle	0	-	0000	Y
			Continuous Cycle	1			
			One-cycle command running	2			
		10 bit	The zero speed running when pause	0			
			Fixed-speed running when the suspension	1			
		100 bit	Stop with the parameters set when stop	0			
Stop with the settings	1						


Section V Parameter Function Table

		of start up						
		1000 bit	Running at the speed when start up segment	0				
			Running at the speed before the machine stopped	1				
<p>1 bit: Running cycle 0: single cycle 1: continuous cycle 2: Single cycle, running according to H01 speed of the end, stop after accepted the stopped orders. The program runs three styles as following: Eg1: The program is run single - cycle modes</p>								
<p>E: program run Continuous cycle modes</p>								
<p>Eg3: Program is running in single cycle, According to Paragraph seventh of Speed mode</p>								
<p>10 bit: Running condition when pause 0: speed run when pause 1: fixed Segment Speed operation when pause 100 bit: Running Segment when stop 0: Set stopping according to the parameters of stop segment. 1: Set down to the initial segment</p>								


1000 bit: start Running Segment
 0: Set down to the speed running
 1: Running at the speed before the machine stopped.
 100 bit=0 Set stopping according to the parameters of stop segment
 1000 bit=0 running at Start Segment



Eg: 100 bit=0 Set stopping according to the parameters of stop segment
 1000 bit=1 Running at the speed before the machine stopped.



Eg: 100 bit=1 Set down to the initial segment
 1000 bit=1 Running at the speed before the machine stopped.



Note : at1' : at the time of segment 1 acceleration time ; dt1' : at the time of segment 1 deceleration time ; at3' : at the time of segment 3 acceleration time ; dt3' : at the time of segment 3 deceleration time

H03	1 Segment Speed Setting 1X	Lower frequency ~ upper frequency	Hz	3.00	Y
H04	2 Segment Speed Setting 2X	Lower frequency ~ upper frequency	Hz	6.00	Y
H05	3 Segment Speed Setting 3X	Lower frequency ~ upper frequency	Hz	9.00	Y
H06	4 Segment Speed Setting 4X	Lower frequency ~ upper frequency	Hz	12.00	Y
H07	5 Segment Speed Setting 5X	Lower frequency ~ upper frequency	Hz	15.00	Y
H08	6 Segment Speed Setting 6X	Lower frequency ~ upper frequency	Hz	18.00	Y
H09	7 Segment Speed	Lower frequency ~ upper frequency	Hz	21.00	Y

	Setting 7X				
H10	8 Segment Speed Setting 8X	Lower frequency ~ upper frequency	Hz	24.00	Y
H11	9 Segment Speed Setting 9X	Lower frequency ~ upper frequency	Hz	27.00	Y
H12	10 Segment Speed Setting 10X	Lower frequency ~ upper frequency	Hz	30.00	Y
H13	11 Segment Speed Setting 11X	Lower frequency ~ upper frequency	Hz	33.00	Y
H14	12 Segment Speed Setting 12X	Lower frequency ~ upper frequency	Hz	36.00	Y
H15	13 Segment Speed Setting 13X	Lower frequency ~ upper frequency	Hz	39.00	Y
H16	14 Segment Speed Setting 14X	Lower frequency ~ upper frequency	Hz	42.00	Y
H17	15 Segment Speed Setting 15X	Lower frequency ~ upper frequency	Hz	45.00	Y

Set the frequency of program running and the running frequency of 7-segment speed respectively. short-circuit the multi-terminal command 1, 2, 3, 4 with COM combinatorially to realized the 16-segment speed/acceleration speed.

0Xspeed is the regular running mode, setting source can be adjusted by F02, F03 and other parameters, running time is controlled by the H18.

Terminal multi-segment speed is defined as follows (shorted with COM it is ON, disconnected then it is OFF):

Speed Terminal	0X	1X	2X	3X	4X	5X	6X	7X
Multiterminal-speed Command 1	OFF	ON	OFF	ON	OFF	ON	OFF	ON
Multiterminal-speed Command 2	OFF	OFF	ON	ON	OFF	OFF	ON	ON
Multiterminal-speed Command 3	OFF	OFF	OFF	OFF	ON	ON	ON	ON
Multiterminal-speed Command 4	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Speed Terminal	8X	9X	10X	11X	12X	13X	14X	15X
Multiterminal-speed Command 1	OFF	ON	OFF	ON	OFF	ON	OFF	ON
Multiterminal-speed Command 2	OFF	OFF	ON	ON	OFF	OFF	ON	ON
Multiterminal-speed Command 3	OFF	OFF	OFF	OFF	ON	ON	ON	ON
Multiterminal-speed Command 4	ON	ON	ON	ON	ON	ON	ON	ON

Acceleration and deceleration time and the direction of running

		0X-7X	8X-15X
H00 10 bit	0	0X -7X Direction controlled by parameter	8X-15X Direction controlled by keyboard and terminal
	1	0X -7X Direction controlled by keyboard and terminal	
H00 100 bit	0	0X -7X deceleration and acceleration time controlled by parameter	8X-15X deceleration and acceleration time controlled by keyboard and terminal
	1	0X -7X deceleration and acceleration time controlled by terminal	

Section V Parameter Function Table

H00 1000 bit	0	0X-7Xrunning time controlled by parameter	8X-15Xrunning time controlled by terminal		
	1	0X-7Xrunning time controlled by terminal			
H18	0 Segment Running Time T0	0.0~3200.0	s	2.0	Y
H19	1 Segment Running Time T1	0.0~3200.0	s	2.0	Y
H20	2 Segment Running Time T2	0.0~3200.0	s	2.0	Y
H21	3 Segment Running Time T3	0.0~3200.0	s	2.0	Y
H22	4 Segment Running Time T4	0.0~3200.0	s	2.0	Y
H23	5 Segment Running Time T5	0.0~3200.0	s	2.0	Y
H24	6 Segment Running Time T6	0.0~3200.0	s	2.0	Y
H25	7 Segment Running Time T7	0.0~3200.0	s	2.0	Y
Actual running time equals to the set multi-segment running time multiples a time which is times of speed running time, and such actual running time decided by the tens digit of H40~H46. Please refer to H40~H46.					
H26	1 Segment Acceleration Time at1	0.0~3200.0	s	10.0	Y
H27	1 Segment Deceleration Time dt1	0.0~3200.0	s	10.0	Y
H28	2 Segment Acceleration Time at2	0.0~3200.0	s	10.0	Y
H29	2 Segment Deceleration Time dt2	0.0~3200.0	s	10.0	Y
H30	3 Segment Acceleration Time at3	0.0~3200.0	s	10.0	Y
H31	3 Segment Deceleration Time dt3	0.0~3200.0	s	10.0	Y
H32	4 Segment Acceleration Time at4	0.0~3200.0	s	10.0	Y
H33	4 Segment Deceleration Time dt4	0.0~3200.0	s	10.0	Y
H34	5 Segment Acceleration Time at5	0.0~3200.0	s	10.0	Y
H35	5 Segment Deceleration Time dt5	0.0~3200.0	s	10.0	Y
H36	6 Segment Acceleration Time at6	0.0~3200.0	s	10.0	Y
H37	6 Segment Deceleration Time dt6	0.0~3200.0	s	10.0	Y
H38	7 Segment Acceleration Time at7	0.0~3200.0	s	10.0	Y

Section V Parameter Function Table

H39	7 Segment Deceleration Time dt7	0.0~3200.0	s	10.0	Y											
Set the Acc/Dec time of 7 steps respectively. They determine the time needed to reach the speed, respectively depending on the acceleration time for acceleration or on the deceleration time for deceleration, but the time is not the actual time needed. Actual acc/dec time equals to the set acc/dec time multiples a time multiple which is decided by the hundreds and thousands digit of H40~H46. Please refer to H40~H46.																
Definite acceleration and deceleration time for multi-step speed:																
Definition of multi-step speed acceleration/deceleration time																
Remark: at1: 1 segment acceleration time;at2: 2 segment acceleration time;dt2: 2 segment deceleration time;dt3: 3 segment deceleration time.																
H40 H41 H42 H43 H44 H45 H46	1 Segment Speed Configuration Word 2 Segment Speed Configuration Word 3 Segment Speed Configuration Word 4 Segment Speed Configuration Word 5 Segment Speed Configuration Word 6 Segment Speed Configuration Word 7 Segment Speed Configuration Word	1 bit	Running direction: forward	0	-	0000	Y									
			Running direction: reverse	1												
		10 bit	Running time: *seconds	0				-	0000	Y						
			Running time: *munites	1												
			Running time: *hours	2												
		100 bit	Running time: *days	3							-	0000	Y			
			Acceleration time: *seconds	0												
			Acceleration time: *munites	1												
			Acceleration time: *hours	2												
		1000 bit	Acceleration time: *days	3										-	0000	Y
			Deceleration time: *seconds	0												
			Deceleration time: *munites	1												
Deceleration time: *hours	2															
Deceleration time: *days	3															

1 bit: Under multi-segment program running, the "1 bit" parameter decides the direction of each segment

speed.

Running Direction	Setting Value
forward	0
reverse	1

When running control mode F05 = 0/1/2, these parameters decide the direction of each segment speed.

When running control mode F05 = 3, the setting value and terminal FWD/REV decide the direction of each segment speed together. FWD is prior.

FWD=1 Running direction	REW =1 Running direction	Setting Value
forward	reverse	0
reverse	forward	1

10 bit: Unit of multi-segment speed program running time.

Running Time	10 bit	Range(e.g.H18~H25=3200.0)
*seconds	0	3200.0 seconds
*minutes	1	3200.0 minutes
*hours	2	3200.0 hours
*days	3	3200.0 days

100 bit, 1000 bit : Unit of acc/deceleration time of multi-segment speed program running

Acceleration / Deceleration time	1000 bit, 100bit	Range(e.g.H26~H39=3200.0)
*seconds	0	3200.0 seconds
*minutes	1	3200.0 minutes
*hours	2	3200.0 hours
*days	3	3200.0 days

H47	0 Segment Digital Voltage Giving	-100.0~100.0	%	0.0	Y
H48	1 Segment Digital Voltage Giving	-100.0~100.0	%	10.0	Y
H49	2 Segment Digital Voltage Giving	-100.0~100.0	%	20.0	Y
H50	3 Segment Digital Voltage Giving	-100.0~100.0	%	30.0	Y
H51	4 Segment Digital Voltage Giving	-100.0~100.0	%	40.0	Y
H52	5 Segment Digital Voltage Giving	-100.0~100.0	%	50.0	Y
H53	6 Segment Digital Voltage Giving	-100.0~100.0	%	60.0	Y
H54	7 Segment Digital Voltage Giving	-100.0~100.0	%	70.0	Y

Digital voltage set function can analogy give frequency, select by F02, F03; analogy give PID set or feedback, select by P02, P03; it can be shifted by the input terminal o36~o46.

H55	Multi-speed Status	1 bit	Current speed step	0~0xF	-	-	N
		10 bit	Current acceleration segment	0~0x7			
		100 bit	Current running time segment	0~0x7			
		1000 bit	Current digit voltage segment	0~0x7			

1 bit: Current speed segment
0~16 segment, In hex, can be shifted t by o36~o46
10 bit: Current acceleration segment
0~7 segment, in hex, can be shifted by o36~o46
100 bit: Current running time segment
0~7 segment, in hex, can be shifted by o36~o46, valid when program running
1000 bit: Current digital voltage segment
0~7 segment, in hex, can by shifted by terminal o36~o46

5-7. V/Fcurve Group:U00-U15(0x0400-0x040F)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
U00	V/ Setting Frequency1	0.00~U02	Hz	5.00	N
User-defined the first frequency value of V / F curve, corresponding to V1 					
U01	V/F Setting Voltage 1	0~U03	%	10	N
User-defined the first voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency inverter, corresponding to F1.					
U02	V/F Setting Frequency 2	U00~U04	Hz	10.00	N
User-defined the second frequency value of V / F curve, corresponding to V2.					
U03	V/F Setting Voltage 2	U01~U05	%	20	N
User-defined the second voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F2.					
U04	V/F Setting Frequency 3	U02~U06	Hz	15.00	N
User-defined the third frequency value of V / F curve, corresponding to V3.					
U05	V/F Setting Voltage 3	U03~U07	%	30	N
User-defined the third voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F3.					
U06	V/F Setting Frequency 4	U04~U08	Hz	20.00	N

Section V Parameter Function Table

User-defined the fourth frequency value of V / F curve, corresponding to V4.					
U07	V/F Setting Voltage 4	U05~U09	%	40	N
User-defined the fourth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F4.					
U08	V/F Setting Frequency 5	U06~U10	Hz	25.00	N
User-defined the fifth frequency value of V / F curve, corresponding to V5.					
U09	V/F Setting Voltage 5	U07~U11	%	50	N
User-defined the fifth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F5.					
U10	V/F Setting Frequency 6	U08~U12	Hz	30.00	N
User-defined the sixth frequency value of V / F curve, corresponding to V6.					
U11	V/F Setting Voltage 6	U09~U13	%	60	N
User-defined the sixth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F6.					
U12	V/F Setting Frequency 7	U10~U14	Hz	35.00	N
User-defined the seventh frequency value of V / F curve, corresponding to V7.					
U13	V/F Setting Voltage 7	U11~U15	%	70	N
User-defined the seventh voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F7.					
U14	V/F Setting Frequency 8	U12~most frequency	Hz	40.00	N
User-defined the eighth frequency value of V / F curve, corresponding to V8.					
U15	V/F Setting Voltage 8	U13~100	%	80	N
User-defined the eighth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F8.					

5-8. PID parameter:P00-P12(0x0500-0x050C)

Code	Description / LCD	Setting Range		Unit	Factory Setting	Change Limited					
P00	PID Configuration	1 bit	Unidirectional regulation	0	-	0000	N				
			Bidirectional regulation	1							
		10 bit	Negative effect	0							
			Positive effect	1							
		100 bit	PID fault, N action	0							
			Warning & Continuous running	1							
			Warning & Decelerating stop	2							
			Warning & Free stop	3							
		1000 bit	-	-							
			-	-							
		When the inverter receives running command, it can control output frequency automatically in the PID regulation mode after comparing the setting signal and feedback signal from terminal. The process									

Section V Parameter Function Table

is explained as following:



(Δ = setting signal - feedback signal)
VFR-080 / VFR-081 PID regulation

0: negative action, when $\Delta > 0$ is positive, frequency rises and when $\Delta < 0$ is negative, frequency falls.
1: positive action, when $\Delta > 0$ is positive, frequency falls and when $\Delta < 0$ is negative, frequency rises.

PID abnormality treatment:
1: Warning & Continuous running: continue running g after abnormality feedback signal.
2: Warning & Decelerating stop: decelerate and stop after abnormality feedback signal.
3: Warning & Free stop: free stop after abnormality feedback signal .

P01	PID Output Limit	0~100	%	100	Y	
The parameter defines the limited range of the output when using PID control.						
P02	Feedback Signal Selection	Set frequency by keyboard or RS485	0	-	1	Y
		AI1 external analogy giving	1			
		AI2 external analogy giving	2			
		AI3 external analogy giving	3			
		Keyboard potentiometer giving	4			
		muti-step digital voltage giving	5			
Digital pulse set	6					
PID feedback signal selection, can select keyboard/RS485, potentiometer, digital voltage, digital pulse for feedback signal.						
P03	Setting Signal Selection	Set frequency by keyboard or RS485	0	-	2	Y
		AI1 external analogy giving	1			
		AI2 external analogy giving	2			
		AI3 external analogy giving	3			
		Keyboard potentiometer giving	4			
		Multi-step digital voltage giving	5			
Digital pulse set	6					
PID giving signal selection, can select keyboard/RS485, potentiometer, digital voltage, digital pulse for giving signal.						
P04	Keyboard Set Signal	0.0~100.0	%	50.0	Y	
When P03 is 0, the setting pressure set by the keyboard. 0.0~100.0% is 0 to the maximum pressure respectively.						
P05	PID integral time	0.002~10.000	s	0.250	Y	
0.002~10.000s The PID integral time determines the integral regulation speed,the regulation acts on the difference between PID feedback and setting value by PID regulator. When the difference between PID feedback and setting value is 100% , integral regulator PID						

Section V Parameter Function Table

<p>regulator output=(P01*F12*12.5%)Hz.(single direction PID regulation, ignores proportion and differential effect).</p> <p>If the value is great, the control is stable but response is slow; if the value is little, the system response is rapid but perhaps surge occurs.</p> 					
P06	PID Differential Time	0.000~10.000	s	0.000	Y
<p>0.000~1.000s</p> <p>The parameter determines the regulation intensity, the regulation acts on the change ratio of the difference between PID feedback and setting value by PID regulator.</p> <p>When the change ratio of the difference between PID feedback and setting value is 100% in the differential time, PID regulator regulates output to (P01*F12*12.5%)Hz (single direction PID regulation, ignores proportion and integral effect).</p> <p>If the value is great, the greater the intensity is, the system surge is to occur more easily</p>					
P07	PID Proportion Gain	0~1000.0	%	100.0	Y
<p>0~100.0%</p> <p>The PID Proportion Gain defines regulation intensity of PID regulator, the larger the P is, the more the intensity is.</p> <p>When proportion gain is 100%, and the difference between PID feedback and getting value is 100%, PID regulator's output is (P01*F12*12.5%)Hz (single direction PID regulation, ignores differential and integral effect).</p> <p>Proportion gain is the parameter decides PID regulator's response extent.</p> <p>If the gain is great, the response is rapid, but if too great, the surge will occur; the gain is little, the response will lag.</p> 					
P08	PID Sampling Period	0.002~10.000	s	0.010	Y
<p>Set Sampling period of feedback signal.</p> <p>When set this parameter small, the system response speed to the giving and feedback deviation is slow, but control is stable.</p> <p>When set this parameter low, the system response speed to the giving and feedback deviation is slow, but easy to cause vibration</p>					
P09	Deviation Limit	0.0~20.0	%	5.0	Y
<p>Deviation limit effects system control accuracy and stability.</p> <p>When the deviation of feedback signal and giving signal < deviation limit, PID N regulation, keep</p>					

Section V Parameter Function Table

<p>output stable.</p> <p>When the deviation of feedback signal and giving signal > deviation limit, PID regulates according to deviation, update output</p>					
P10	PID Fault Detect Time	0.0~3200.0	s	0.0	N
P11	PID Fault Detected Value	0.0~100.0	%	10.0	N
<p>Set P10 to 0.0 for N fault inspection.</p> <p>When PID feedback signal < P11 set PID fault inspection value, last P10 set time, regard it as PID regulation fault.</p>					
P12	PID Display Range	0.00~100.00	-	1.00	Y
<p>A09 PID set value = PID set value(%)*P12</p> <p>A10 PID feedback value = PID feedback value(%)*P12</p> <p>If PID feedback 10V corresponding 4.0Mpa pressure, if need A09, A10 to display actual value, only need to set P12 = 0.04.</p>					

5-9. Expanding parameters: E00-E23(0x0600-0x0617)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited	
E00	Load Type	General	0	-	0	N
		Pump	1			
		Fan	2			
		Injection machine	3			
		Textile machine	4			
		Hoist machine	5			
		Kowtow Machine	6			
		belt conveyor	7			
		Variable frequency power	8			
		Multi-pumps constant pressure water supply	9			
		Reserved	10			
		Reserved	11			
		Torque control	12			
		Voltage regulation power	13			
		Current regulation power	14			
Extruding machine	15					
Details, see Appendix IV.						
E01	Starting Pressure Deviation	0.0~100.0	%	10.0	Y	
E02	Starting Delay Time	0.0~3200.0	s	5.0	Y	
<p>Feedback pressure < given pressure - starting pressure deviation.</p> <p>Continuously exceed E02 start delay time, the inverter will restart under in the standby mode. This parameter is used to prevent the inverter frequent start-stop.</p>						
E03	Stop Frequency	0~50.00	Hz	5.00	N	
E04	Stop Delay Time	0.0~3200.0	s	5.0	Y	

If the set frequency is less than or equal to E03, stop frequency exceeding E04 stop delay time, the ac drive will change from running to the stop standby state.

The bigger E03 parameter setting, the easier for stop, E03 parameter is set to 0, **indicating the stop frequency and the start pressure control function is invalid.**


E01, E02, E03, E04 mix are used to control system operation and water supply systems in the energy-saving water pressure regulator.

For example:

Given pressure = 50%

Starting pressure deviation = 10%, starting pressure = given pressure - starting pressure deviation = 40%

Topping frequency = 5Hz



E05	High Pressure Arrival Value	0~100.0	%	90.0	Y
-----	-----------------------------	---------	---	------	---

When feedback pressure reach and exceed the high pressure reached value of this parameter, the I/O output terminal select 25, then it will output arrival signal.

E06	Low Pressure Arrival Value	0~100.0	%	10.0	Y
-----	----------------------------	---------	---	------	---

When feedback pressure less than the low pressure reached value of this parameter, the I/O output terminal select 26, then it will output arrival signal.

E07	Timing To Supply Water	1 bit	Timing water supply	invalid	0	-	0000	Y
				Valid	1			
		10 bit	Pressure giving	Set according to P03	0			
				Set according to H47~H54	1			
100 bit	Timing mode	Circle mode	0					
		Single circle	1					
1000 bit	Current timing step							

1 bit: Timing water supply
0 Timing water supply function is invalid

1 Timing water supply function is valid

10 bit: pressure giving

0 the pressure given during regular pressure water supply is set according PID given value selecting P03.

1 the pressure given during regular pressure water supply is set according the current corresponding H47~H54 digital voltage given.

100 bit: timing mode

0 cycle mode

Start to time from start running, after it reached the setting time, the inverter will automatically move to the next period of time set, after the end of a loop, it will automatically re-start from the first paragraph 0, then cycle to run.

1 single cycle

Start to time from start running, after it reached the setting time, the inverter will automatically move

to the next period of time set, after the end of a loop, the inverter will stop and wait for the next running command.

1000 bit: the current regular time

When the water supply time set 0, it means cancel the water supply time setting of this period.

Current time	Water supply time	Pressure given
0	H18	H47
1	H19	H48
2	H20	H49
3	H21	H50
4	H22	H51
5	H23	H52
6	H24	H53
7	H25	H54

E08	Timing Shift Alternation Time	0.0~3200.0	Hours	0.0	N
-----	-------------------------------	------------	-------	-----	---

Timing Shift Alternation Time control the alternation ways and time of pump.

When Timing Shift Alternation Time is set to 0.0 hour and cancel Timing Shift Alternation function.

When the Timing Shift Alternation Time between 0.1~3,200 , after corresponding time of the stable running, in accordance with the principle of first stop for the one first started to control switch of pump.

First stop for the first pump started: When reduce pumps control, stop the first pump which started first.

According to the principle of start first – stop first control, in order to ensure that every pump can have the chance to run to prevent some pumps rusted as a result of no use for long , such as the need to ensure that each operation of the pump can receive equal time, set Timing Shift Alternation Time.

Pump alternation order : E12 = 0x 0001

Starting State : No. 1 pump frequency, No. 2 pump frequency conversion and No. 3 pump stops ;

Rotation : No. 1 pump stops, No. 2 pump frequency, No. 3 pump frequency conversion ;

After the second rotation : No.1pump frequency conversion and No.2pump stops, No.3pump power frequency.

E09	Electromagnetic Switch Action Delay	0.000~10.000	s	0.500	Y
-----	-------------------------------------	--------------	---	-------	---

Electromagnetic switch action delay time when set up a pump (drive motor) to switch from variable frequency to industry frequency, or from industry frequency to variable frequency. This is to avoid inverter

Section V Parameter Function Table

output frequency meet with the AC power supply and occur short circuit caused because electromagnetic switch action too slow.								
E10	Pumps Shift Judging Time	0~9999	s	5	Y			
<p>Set when output frequency converter arrives to upper frequency, until the judgment time of increasing pumps (driving motor); or when output frequency converter arrives to lower frequency, until the judgment time reducing pumps (driving motor). Set the time long or short according to the speed of pressure change, without oscillating range, the shorter the better.</p> <p>Drives add or subtract pump control with E12 Water Supply Configuration Add pump order No. 1 pump → No. 2 pump → No. 3 pump → No. 4 pump. Reduce pump order No. 4 pump → No. 1 pump → No. 2 pump → No. 3 pump. If the current : No. 1 pump frequency, No. 2 pump frequency, No. 3 pump convert frequency after reduce pump: No. 1 pump frequency, No. 2 pump convert frequency, after add pump: 1 pump frequency, No. 2 pump frequency, No. 4 pump convert frequency after reduce pump :No. 1 pump frequency, No. 2 pump convert frequency, after reduce pump: No. 1 pump frequency, after add pump: No. 1 pump frequency, No. 3 pump convert frequency after add pump: No. 3 pump frequency No. 4 pump convert frequency after add pump: No. 1 pump frequency, No. 3 pump frequency No. 4 pump. frequency ,No. 2 pump converter frequency.</p>								
E11	Constant Pressure Water Supply Configuration	1 bit	Stop mode	all pumps slow down stop	0	-	0000	N
				Variable frequency pump stop	1			
				Free stop	2			
				Water supply Pump stop	3			
		10 bit	Pumps status when fault occurs	Keep current situation	0			
				All-pumps stop	1			
		100 bit	Alternation shift mode	Variable frequency to working frequency	0			
				Variable frequency to stop	1			
		1000 bit	Pump status keep	Keep status	0			
				Stop reset	1			
<p>1 bit : Stop mode 0 All slow down, all pumps in turn slowing down. 1 variable frequency pump stop:variable frequency pump stop running,variable frequency pump and soft start pump under frequency keep running.</p>								

Section V Parameter Function Table

<p>Stop power frequency pump,you need to use o36~o46parking command or keyboard input terminal free multi - function keys MF1, MF2 set to 2 : Free Parking function. 2 Free stop, all pumps free stop After free stop,E11 1000bit pump reset according to the order start and stop,but reorder according to E12 multi - pumps configuration. 3 Water supply pump stops,only those constant pressure water supplying pumps stop,soft start pump keep running under pump frequency. Stop soft - starting pump, you need to use stop command of the soft star pump for o36 ~ o46 input terminal or keyboard multi - function keys MF1, MF2 set to 2 : Free stop function.</p> <p>10 bit: Treatment under fault pump states 0 maintain the status quo, when inverter failure, stop the current variable frequency pump operation and other power - frequency operation of variable frequency pump and soft start pump maintain the status quo Fault occurs, if the following breakdown, select fault treatment according to failure action.</p>																																		
		<table border="1"> <tr> <td>12</td> <td>E.PId</td> <td colspan="2">regulating fault</td> </tr> <tr> <td>13</td> <td>E.OHt</td> <td colspan="2">Motor over heated fault</td> </tr> <tr> <td>14</td> <td>E.OL2</td> <td colspan="2">Motor over loading fault</td> </tr> <tr> <td>15</td> <td>E.PG</td> <td colspan="2">PG fault</td> </tr> <tr> <td>16</td> <td>E.PHo</td> <td colspan="2">Inverter output Phase lost</td> </tr> <tr> <td>17</td> <td>E.COA</td> <td colspan="2">RS485 communication A fault</td> </tr> <tr> <td>18</td> <td>E.CO b</td> <td colspan="2">RS485 communication B fault</td> </tr> </table>		12	E.PId	regulating fault		13	E.OHt	Motor over heated fault		14	E.OL2	Motor over loading fault		15	E.PG	PG fault		16	E.PHo	Inverter output Phase lost		17	E.COA	RS485 communication A fault		18	E.CO b	RS485 communication B fault				
12	E.PId	regulating fault																																
13	E.OHt	Motor over heated fault																																
14	E.OL2	Motor over loading fault																																
15	E.PG	PG fault																																
16	E.PHo	Inverter output Phase lost																																
17	E.COA	RS485 communication A fault																																
18	E.CO b	RS485 communication B fault																																
<p>The feature only applies to the fault under the mode allowing fault runs. The fault is not allowed to run, all stop. 1 All pump stop, when inverter failure, all pumps free stop.</p> <p>100 Bit: Soft start switching mode 0 Convert frequency to power frequency, frequency control of the pump current increases the speed to the frequency, the rotation of the pump start and stop switch control or soft start pump 1 Frequency conversion to stop, stopped the current frequency conversion control of pump and pump rotation switch or soft start pump start - stop control.</p> <p>1000 Bit : pumping States maintain 0 Maintaining state, After multi pumps constant pressure water supply stop, keep the current multipumps at the first start- first stop order. 1 Stopping reset , After multi pumps constant pressure water supply stop , E12 multipumps configuration reorder multi - pump at the stop order.</p>																																		
E12	Multi-pumps Configuration	1 bit	Pump 1 invalid	0	-	0001	N																											
			Pump 1 variable frequency to control pump	1																														
			Pump 1 soft starts to control pump	2																														
		10 bit	Pump 2 invalid	0																														
			Pump 2 variable frequency to control pump	1																														

Section V Parameter Function Table

			Pump 2 soft starts to control pump	2				
		100 bit	Pump 3 invalid	0				
			Pump 3 variable frequency to control pump	1				
			Pump 3 soft starts to control pump	2				
		1000 bit	Pump 4 invalid	0				
			Pump 4 variable frequency to control pump	1				
			Pump 4 soft starts to control pump	2				
Under Multi-pump control mode, set the control mode of each pump.								
E13	Multi-pumps Status	1 bit	Pump 1 stop	0	-	0000	N	
				Pump 1 run in variable frequency				1
				Pump 1 run in working frequency				2
		10 bit	Pump 2 stop	0				
				Pump 2 run in variable frequency				1
				Pump 2 run in working frequency				2
		100 bit	Pump 3 stop	0				
				Pump 3 run in variable frequency				1
				Pump 3 run in working frequency				2
		1000 bit	Pump 4 stop	0				
				Pump 4 run in variable frequency				1
				Pump 4 run in working frequency				2
Under Multi-pump control mode, displays the status of each pump.								
E14	Soft Starting Pump Control	1 bit	Pump 1 soft-no command	0	-	0000	Y	
				Pump 1 soft-stop				1
				Pump 1 soft-start				2
		10 bit	Pump 1 soft-no command	0				
				Pump 2 soft-stop				1
				Pump 2 soft-start				2
	100 bit	Pump 1 soft-no command	0					

Section V Parameter Function Table

			Pump 3 soft-stop	1			
		1000 bit	Pump 3 soft-start	2			
				Pump 1 soft-no command	0		
				Pump 4 soft-stop	1		
			Pump 4 soft-start	2			
Under Multi-pump control mode, set the control mode of each pump.							
E15	User Parameter 0	0~9999		-	0	Y	
E16	User Parameter 1	0~9999		-	0	Y	
E17	User Parameter 2	0~9999		-	0	Y	
E18	User Parameter 3	0~9999		-	0	Y	
E19	User Parameter 4	0~9999		-	0	Y	
E20	User parameter 5	0~9999		-	0	Y	
E21	User Parameter 6	0~9999		-	0	Y	
E22	User Parameter 7	0~9999		-	0	Y	
E23	User Parameter 8	0~9999		-	0	Y	

※Please check appendix 4 for the detailed expanding parameter instruction.

5-10. Speed-loop parameter [SPD]:C00-C31(0x0700-0x071F)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
C00	Filter Time Of Speed-loop	2~200	ms	10	Y
It defines the filter time of the speed-loop. The range is 0.01~100s. If the value is too great, the control is stable but response is slow; if the value is too little, the system response is rapid but perhaps is unstable. So it is necessary to consider the stability and the response speed at the same time when setting the value.					
C01	Speed-loop Low Speed Ti	0.01~100.00	s	0.25	Y
It defines the integral time of the speed-loop low speed. The range is 0.01~100.00s. If the integral time is too great, response is slow and the control of external disturbing signal become bad; if the time is too little, response is rapid, but perhaps brings the surge.					
C02	Speed-loop Low Speed Td	0.000~1.000	s	0.000	Y
It defines the differential time of the speed-loop low speed segment and the range is 0.000~1.000s. If the time is great enough, the surge which is caused by P action when difference occurring can attenuate quickly. But too great, the surge will happen contrary. When the time is little, the attenuation function is little too.					
C03	Speed-loop Low Speed P	0~150	%	100	Y
It defines the proportion gain of speed loop low speed segment. And the range is 0~1000%. If the gain is great, the response is rapid, but too great, surge perhaps occurs; if the gain is too little, response is slower.					
C04	Speed-loop Low Speed Shift Frequency	0.0~C08	Hz	7.00	Y

Section V Parameter Function Table

It defines low-speed loop switching frequency, the parameter and switching frequency at high-speed optimize Speed-loop PID parameter.								
C05	Speed Loop High Speed Ti	0.01~100.00	s	0.50	Y			
It defines integration time of High-speed section of the speed loop.Range is 0.01~100.00s.integration time too large and unresponsive, external interference control variation becomes weak ; integration time is small the reaction speed, oscillation occurs when it is too small.								
C06	Speed Loop High Speed Td	0.000~1.000	s	0.000	Y			
It defines the differential time of the speed-loop high speed segment and the range is 0.000~1.000s. If the time is great enough, the surge which is caused by P action when difference occurring can attenuate quickly. But too great, the surge will happen contrary. When the time is little, the attenuation function is little too.								
C07	Speed Loop High Speed P	0~150	%	75	Y			
It defines the proportion gain of speed loop high-speed section, range from 0~1000%. Gain is large, response speed, but too large gain will occur vibration; if the gain is small, the reaction lag.								
C08	Speed Loop And High-speed Switching Frequency	C04~max frequency	Hz	30.00	Y			
It defines Integral time of speed loop high speed , the parameter and switching frequency at low - speed optimize the speed-loop PID parameter.								
C09	Low-speed Slip Gain	0~200	%	100	Y			
Low-speed segment slip compensation gain								
C10	Low Speed Slip Switching Frequency	0~C12	Hz	5.00	Y			
Low speed segment slip compensation switching frequency								
C11	High Speed Slip Gain	0~200	%	100	Y			
High speed segment slip compensation gain								
C12	High Speed Slip Switching Frequency	C10~ max frequency	Hz	30.00	Y			
High speed segment slip compensation switching frequency								
C13	Upper Froward Torque	0.0~300.0	%	250.0	Y			
The parameter is a ratio , setting value is 100%. Responding to motor rated output torque. Set forward torque mode through C15. In speed control mode, it's upper forward torque. In torque control mode, it's forward torque setting value.								
C14	Upper Reverse Torque	0.0~300.0	%	250.0	Y			
The parameter is a ratio , setting value is 100%. Set reverse torque mode through C16. In speed control mode, it's upper reverse torque. In torque control mode, it's reverse torque setting value.								
C15	Forward Torque setting mode	1 bit	Setting mode	Set by keyboard or RS485	0	-	0000	Y
				AI1 external analogy	1			

Section V Parameter Function Table

				giving									
				AI2 external analogy giving	2								
				AI3 external analogy giving	3								
				Keypad potentiometer giving	4								
				Multi-step digital voltage giving	5								
				Digital pulse set	6								
		10 bit	direction	Direction uncontrolled	0								
				Direction controlled	1								
C16	Reverse Torque setting mode	1 bit	Setting mode	Set by keyboard or RS485	0	-	0000	Y					
				AI1 external analogy	1								
				AI2 external analogy giving	2								
				AI3 external analogy giving	3								
				Keypad potentiometer giving	4								
				Multi-step digital voltage giving	5								
		Digital pulse set	6										
				10 bit	direction				Direction uncontrolled	0			
									Direction controlled	1			
		C17	Torque Set Gain	0.0~300.0	%				200.0	Y			
		C15 1 bit: Setting mode C16 1 bit: Setting mode											
			0	Set by keyboard or RS485	Responding to C13/C14								
			1	AI1 external analog setting	As per AI1 external analog setting								
			2	AI2 external analog setting	As per AI2 external analog setting								
	3	AI3 external analog setting	As per AI3 external analog setting										
	4	Keyboard potentiometer setting	As per keyboard potentiometer setting										
	5	Multi segment digital voltage setting	As per multi segment digital voltage setting										

Section V Parameter Function Table

6	Digital Pulse Setting	As per digital pulse setting						
<p>While the unit digital of C15,C16 is 1—6, the torque up-limit of C13,C14 is for checking.</p> <p>C15 10 bit: Direction Control C16 10 bit: Direction Control 0: No control Direction Direction is controlled by terminal or keyboard 1:Control Direction Setting value of forward torque > setting value of reverse torque, forward direction. Setting value of forward torque < setting value of reverse torque, reverse direction.</p> <p>C13 upper forward torque =setting value percentage * C17 torque given gain. C14 upper reverse torque =setting value percentage * C17 torque given gain. Such as: C15 forward torque setting way=4 keyboard potentiometer setting. C16 reverse torque setting way=4 keyboard potentiometer setting. Forward/reverse both can control direction, C15=0x14, C16=0x14. Potentiometer corresponding setting value A48=-100%, A49=100% Keyboard potentiometer set A47=100%, C17=200.0% C13 forward torque up-limit=100%*200.0%=200.0%, control direction forward 200% torque Keyboard potentiometer set A47=100%, C17=200.0% C14 reverse torque up-limit=100%*200.0%=200.0%, control direction reverse 200% torque</p>								
C18	Speed /Torque Control Shift	Speed control	0	-	0	Y		
		Torque control	1					
F00 control method is to s select senseless vector control or sensor feedback close loop vector control can change speed or torque control through input terminal. After setting IP terminal change, keyboard set invalid, only for query.								
C19	Upper speed Setting mode	1 bit	Separate setting mode	keyboard or RS485 setting	0	-	0000	Y
				AI1 external analog setting	1			
				AI2 external analog setting	2			
				AI3 external analog setting	3			
				Keyboard potentiometer setting	4			
				Multi-segment digital voltage setting	5			
				Digital Pulse Setting	6			
		10 bit	Selection	C19 Unit bit setting	0			
		S00 Setting Frequency	1					
C20	Reverse Speed Limit	0.00~ Maximum frequency		-	50.00	Y		

Section V Parameter Function Table

While torque control, setting upper speed. C19 1 bit: Separate setting mode						
0	keyboard or RS485 setting	As per C20 setting				
1	AI1 external analog setting	As per AI1 external analog setting				
2	AI2 external analog setting	As per AI2 external analog setting				
3	AI3 external analog setting	As per AI3 external analog setting				
4	Keyboard potentiometer setting	As per keyboard potentiometer setting				
5	Multi-step digital voltage setting	As per Multi-step digital voltage setting				
6	Digital Pulse Setting	As per Digital Pulse Setting				
<p>While the unit digital of C19 is 1—6, the speed up-limit of C20 is for checking.</p> <p>C19 10 bit: Select Speed Up-limit Setting Ways 0: separate setting, as per the selection of C19 Units digital. 1:setting frequency is according to S00,and affected by the following parameters. F02 frequency main setting ways/F03 frequency secondary setting ways/F04 frequency setting main and secondary.</p>						
C21	Torque Acceleration Time	0.0~200.0	s	1.0	Y	
C22	Torque Deceleration Time	0.0~200.0	s	1.0	Y	
C21, C22 torque acceleration time, turning moment deceleration torque control mode and effective. Torque acceleration time, torque accelerated from 0 to 300 hours. Torque speed, torque, from 300 down to 0.						
C23	Low Speed Excitation	0~100	%	30	Y	
Under low speed, compensate excitation quantity, increase torque feature, in case of meeting the requirement, try to make it lower, could reduce the motor heating up caused by magnetic path full.						
C24	Current Loop Ti	0~9999	ms	500	Y	
Define the current loop integral time. When integral time is too long, response is inactive; the ability to control external jamming becomes weak. When integral time is short, response is fast, if too short, vibration will occur.						
C25	Current Loop P	0~1000	%	100	Y	
Define current loop proportion gain, When select big gain, response fast, but too big will occur vibration. when select low gain, response lag.						
C26	PG Electronic Gear A	1~5000	-	1	Y	
C27	PG Electronic Gear B	1~5000	-	1	Y	
When encoder and motor is in different shaft, can calculate current motor speed according to encoder and gear ratio. Electronic gear A for denominator, B for molecule.						
C28	PG Pulse	300~9999	-	2500	N	
PG pulse quantity used, set value is the pulse quantity when motor rotates for a circle.						
C29	Action When PG Break	N PG break protection	0	-	3	Y
		Warning and keeping running	1			

Section V Parameter Function Table

		Warning and deceleration stop.	2			
		Warning and free stop.	3			
Set the brake method when detect PG break. 0 : N PG break protection 1 : Warning and keeping running. 2 : Warning and deceleration stop. 3 : Warning and free stop.						
C30	PG Rotating Direction	When motor forward, phase A leads	0	-	0	Y
		When motor forward, phase A leads	1			
<p>phase A is forward phase B is forward</p> <p>Encoder rotating direction, refer to the motor forward direction 0 : When motor forward, phase A leads, set C27= 0 1 : When motor forward, phase B leads, set C27= 1 Note: above parameters are valid when with encoder(PG), need to layout PG card. If needed, please contact our company.</p>						
C31	PG Dropped Inspection Time	0.0~10.0	s	1.0	N	
PG feedback signal is 0, exceed C31 set time, system reports PG dropped fault. Set speed to 0, or sert C31 to 0, don't check PG dropped fault.						

5-11. Motor parameter [MOT]:b00-b22(0x0800-0x0816)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
b00	Motor 1 Rated Frequency	0.00~Maximum frequency	Hz	50.00	Y
b01	Motor 1 Rated Current	y09*(50%~100%)	A	★	Y
b02	Motor 1 Rated Voltage	100~1140	V	★	Y
b03	Motor 1 Pole-pairs	1~8	-	2	Y
b04	Motor 1 Rated Speed	500~5000	rpm	1480	Y
<p>b00~b04 are the motor's nameplate parameters which touch the precision.Set the parameters according to the motor's nameplate. b00 ~ b04 motor nameplate in parameters, it is necessary to re-calculate motor parameters by using b11. Excellent vector control performance requires exact motor parameters. Exact parameters are base on the correct setting of motor's rated parameters. To assure the control performance, please match the right motor as per the inverter's standard, motor rated currents limited between 30%~120% of inverter rated current. The rated current can be set, but can't be more than the rated current of the inverter. The parameter confirms the OL protection capability of the motor and energy-saving running. To prevent self-cooled motor form overheat when running in a low speed, and the motor capacity change when motor character change little, the user can correct the parameter to protect the motor.</p>					

Section V Parameter Function Table

The number of motor pole pairs, such as the four pole motor, the number of pole pairs is set to 2						
b05	Motor 1 N Load Current	0.0~b01	A	★	Y	
b06	Motor 1 Stator Resistance	0.000~30.000	ohm	★	Y	
b07	Motor 1 Rotor Resistance	0.000~30.000	ohm	★	Y	
b08	Motor 1 Stator Inductance	0.0~3200.0	mH	★	Y	
b09	Motor 1 Mutual Inductance	0.0~3200.0	mH	★	Y	
<p>b05~b09 can by input by motor actual parameters value, also can define motor parameter by b11 parameter measure function.and save automatically. If know the correct motor parameter, can input by hand When b11 is 1, 2, 3, the system calculates and measures automatically. b05~b09 is the motor's basic electric parameters, these parameters is essential to achieve vector control calculation.</p>						
b10	Motor Selection	Motor 1	0	-	0	N
		Motor 2	1			
<p>The system can select any group motor parameters. Motor parameter measurements modify and save to corresponding motor parameter area automatically.</p>						
b11	Motor Parameter Measurement	N measurement	0	-	0	N
		calculate by label data	1			
		inverter static measurement	2			
		inverter rotation measurement	3			
<p>Set whether the measurement of electrical parameters in order to b10 motors choose motor 1 as an example. 0 : N measurement 1 : Calculate by label data According to the motor nameplate parameters b00 ~ b04 , automatic calculation b05 ~ b09 and other electrical parameters,the advantage does not require power-on self - tuning,suitable for general - purpose Y series of four pole motor, the other type motor can be adjusted based on this parameter. 2 : Inverter static measurement 3 : If the motor parameters can not be measured without load,you can choose static frequency converter measurement. Make sure that motor in a static status ,after static measurement, it can be manually adjusted some parameters, optimal control. 4 : The b11 is set to 2, the inverter automatically start parameter determination. Keyboard figures area show "-RUN": waiting to run the command, start the measurement. Keyboard figures area show "CAL1", inverter without output. Keyboard figures area show "CAL2", inverter with output, static state. Keyboard figures area show "-END": measuring ends. Keyboard figures area show "E. CAL": the measurement process errors. Process can be measured through the STOP key to stop. 3 : Inverter rotation measurement Motor can be measured without load, can choose the rotation measurement. Measurements started, make sure the motor is static. Static measurement converter, the output DC voltage, pay attention to safety.</p>						

Section V Parameter Function Table

The b11 is set to 3, the inverter automatically start parameter determination.
 Keyboard figures show that the regional show "-RUN": waiting to run the command, start the measurement.
 Keyboard figures area show "CAL1", "CAL3": N output inverter.
 Keyboard figures area show "CAL2", inverter with output, under static state.
 Keyboard figures area show "CAL4", inverter with output, the motor forward in high-speed.
 Keyboard figures area show "-END": measuring the end.
 Keyboard figures area show "E. CAL": the measurement process errors.
 Process can be measured through the STOP key to stop.
 Set this parameter,the motor parameters will be determined dynamically.Be sure the motor is without load (N-load operation).
 Before setting,be sure to run well prepared,the motor will run in high speed during the measurement
 Measurement is completed, b11 return to 0. The measured parameters will select parameters on the base of b10 motor parameters which is automatically saved to the b05 ~ b09 or b18 ~ b22.
Note: Before auto-measure the motor parameter, must input motor rated parameter b00~b04or b13~17 correctly
 Please regulate accelerating and deceleration time or torque increasing parameter, if there is over-current or over voltage faults while auto- measurement.
 When automatic regulation, motor should be in stop status.

b12	Vector Control initial Inspection R1	Not inspection R1	0	-	0	N
		Inspection R1	1			
b13	Motor 2 Rated Frequency	0.00~Maxmum frequency		Hz	50.00	Y
b14	Motor 2 Rated Current	y09*(50%~100%)		A	★	Y
b15	Motor 2 Rated Voltage	100~1140		V	★	Y
b16	Motor 2 Pole Pairs	1~8		-	2	Y
b17	Motor 2 Rated Speed	500~5000		rpm	1480	Y
b18	Motor 2 N Load Current	0.0~b14		A	★	Y
b19	Motor 2 Stator Resistance	0.000~30.000		ohm	★	Y
b20	Motor 2 Rotator Resistance	0.000~30.000		ohm	★	Y
b21	Motor 2 Stator Inductance	0.0~3200.0		mH	★	Y
b22	Motor 2 Mutual Inductance	0.0~3200.0		mH	★	Y

The 2nd group motor parameters can be set by system. The definition is same with group 1.

5-12. System parameter [SYS]:y00-y17(0x0900-0x0911)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited	
y00	Reset System Parameter	No action	0	-	0	N
		Reset system parameter with keyboard storage1	1			
		Reset system parameter with keyboard storage 2	2			
		Reset system parameter with	3			

Section V Parameter Function Table

		keyboard storage 3				
		Reset system parameter with keyboard storage 4	4			
		Reset system parameter with factory set value	5			

0 : No action
 1 : Reset system parameter with keyboard storage 1
 2 : Reset system parameter with keyboard storage 2
 3 : Reset system parameter with keyboard storage 3
 4 : Reset system parameter with keyboard storage 4
 5 : Reset system parameter with factory set value
 When this parameter set valid, all the function parameter reset to factory setting. The parameters without factory setting will save the previous setting value.

y01	Parameter Upload To Keyboard	No action	0	-	0	N
		Reset system parameter with keyboard memory area1	1			
		Reset system parameter with keyboard memory area2	2			
		Reset system parameter with keyboard memory area3	3			
		Reset system parameter with keyboard memory area4	4			
		Clear up keyboard memory area 1, 2, 3, 4	5			

0 : No action;
 1 : Reset system parameter with keyboard memory area1;
 2 : Reset system parameter with keyboard memory area2;
 3 : Reset system parameter with keyboard memory area3;
 4 : Reset system parameter with keyboard memory area4;
 5 : Clear up keyboard memory area 1, 2, 3, 4

y02	Lastest Fault record	Lastest fault record number	mH	0	Y
y03	Fault Record 1	Press [PRG]and [▲/▼] key the frequency, crent and running status of fault time can be known.	-	0	Y
y04	Fault Record 2				
y05	Fault Record 3				
y06	Fault Record 4				
y07	Fault Record 5				

These parameters register fault which happen in the last several times, and can inquire about the value of monitor object at the time of fault by 'PRG' and "plus or minus" key.
 The monitor object of fault state:
 0: Fault type
 The fault code is expressed as following:

Serial number	LED display	Fault
0	E.OCP	System is disturbed or impacted by instant over current
1	Reserved	
2	E.OC3	Over current or over voltage signal from drive circuit.

Section V Parameter Function Table

3	Reversed	
4	E.OU	Over voltage
5	E.LU	Under voltage
6	E.OL	Over load
7	E.UL	Under load warm
8	E.PHI	Power input Phase loss
9	E.EEP	EEPROM error
10	E.ntC	Over heat
11	E.dAt	Time limit fault
12	E.Set	External fault
13	Reserved	
14	Reserved	
15	Reserved	
16	E.PID	PID regulate fault
17	E. OHt	Motor over heat fault
18	E.OL2	Motor over load fault
19	E.PG	PG fault
20	E.Pho	Inverter output phase-lost
21	E.COA	RS485 communication terminal A failure
22	E.Cob	RS485 communication terminal B failure
23	E.CAL	Parameter identification problems.

- 1: set frequency at the time of fault
The output frequency of the inverter at the time of fault
- 2: output frequency at the time of fault
The output frequency of the inverter at the time of fault
- 3: output current at the time of fault
The actual output current at the time of fault
- 4: output DC voltage at the time of fault
The actual output voltage at the time of fault
- 5: Running state at the time of fault
The running state at the time of fault
LEDdisplay is below:

the first LED tthhte		The second LED		The third LED		the fourth LED	
F	forward command	F	forward status	separator	A	accelerating	
R	Reverse command	R	Reverse status		D	decelerating	
S	Stop command	S	Stop status		E	running in a even speed	
					S	Stop status	

6: running time at the time of fault

Section V

Section V Parameter Function Table

The running time at the time of fault							
7: Inverter IGBT temperature at the time of fault							
Inverter IGBT temperature							
y08	Fault Record Reset	No action	0	-	0	Y	
		Reset	1				
0 : No action, the fault records retains							
1 : the fault records resets							
y09	Rated Output Current	0.1~1000.0		A	★	N	
Inverter rated output current.							
y10	Rated Input Voltage	100~1140		V	★	N	
The rated input voltage of the inverter. It would be set as per inverter input voltage level before leaving factory.							
y11	Product Series	80	0	3	-	★	N
		Family code	Product serial	Input oltage grade 1			
Product series (set according to family code/product serial/voltage grade)							
<div style="text-align: center;"> <p>80 0 3</p> </div>							
family code		series number		input voltage level			
80: 8000 serial		0: Flow load (F)		1: single phase 220V			
81: 8100 serial		1: General load (G)		2: three phase 220V			
		2: Middle load (M)		3: three phase 380V			
		3: Heavy load (H)		4: three phase 460V			
		6: TEXDRIVE (S)		5: three phase 575V			
		7: WINDLASS (T)		6: three phase 660V			
		8:JETDRIVE (Z)		9: three phase 1140V			
y12	Software Version	-		-	-	N	
<div style="text-align: center;"> <p>A 100</p> </div>							
		A: official version		version number			
		B: specialized version					
		C: beta version					
y13	Product Date-- Year	YYYY		-	-	N	
y14	Product Date -Month/Day	MMDD		-	-	N	
y15	User Decode Input	0~9999		Set range		Y	
		Record password wrongly input times		Display info			
In the state of locked parameter,LED displays the times of error input. There are three input limit,if input is wrong in continuous three times , the systems will prohibit input of the password . It can prevent testing password in an illegal way, and need restart the machine to input again.							
Once the input is right in any time during three times input limit, the parameter is unlocked.							
y16	User password key-in	0~9999		Set range		Y	
		No password or decode input is correct		code			
		Parameter lock-in		code			
The parameter sets the password , and the range is 0 ~ 9999 . After setting the password , parameter locks and keyboard displays "code"; if the password is unlocked or password input is right, the keyboard							

Section V Parameter Function Table

will display "deco". Set password to 0, reset user password set, after re-electrify status is decode.					
y17	Parameter Group Protection	Corresponding parameter group protection after set password Set to 0: change is not allowed Set to 1: change is allowed	-	0000	Y

Section V

Section VI. Fault Report & Solutions

6-1. Problems and solutions

Problems	Possible causes	Solutions
Keyboard can not control	Running control mode setting is wrong	Check F05
	Frequency setting is wrong	Check F03、F04
Potentiometer can't regulate speed	Control mode setting is wrong	Check F05
	Frequency setting is wrong	Check F03、F04
The motor Does not rotate	LED monitor display fault	Press RESET or terminal for fault reset, learn and fix the fault according to the fault info
	No voltage in terminals DC+1 and DC+2	Check the voltage at R, S or T and charging circuit.
	U, V or W terminals produce No output or abnormal output.	Check the control mode and frequency parameter. Check the terminal condition if it is operated by an external terminal.
	Re-start after powering down or free run	Remember the set operating state.
	Too much load on the motor	Check the load condition, and confirm the model selection is right
Over recurrent E.OC	Fault display E.OCP	System is disturbed or instant over current
	Fault display E.OC3	Motor over current, protect action when motor actual current is 3 times over than the motor rated current
	Over current during acceleration	Reset or adjust F09, F20, F21.
	Over current during deceleration	Reset or adjust F10, F22, F23.
	During starting, the low-frequency jitter over-current	Modify F06 setting
	Over current during operation	Check the load change and eliminate it.
	Over current during starting or operation sometime	Check if there is slight short circuit or grounding.
	Disturbance	Check the earthing wire, screened cable grounding and terminals.
Over load E.OL	Too much load	Lower the load.or enlarge b04, b14 in the allowable load range or enlarge A24 to raise the thermal protection level.
	Inappropriate parameter is set	Modify <u>b04</u> 、 <u>b14</u> in case of the motor over-load allowed
Over voltage E.OU	Power voltage exceeds the limit	Check voltage is right or not. Frequency inverter rated voltage setting is Y or N.
	Too fast deceleration	Modify F10.

Section VI

	The load has too much inertia	Reduce the load inertia, or raise the capacity of frequency converter, or add a braking resistor.
Low voltage E.LU	Too low power voltage	Checking voltage is normal or not. Frequency inverter rated voltage setting is Y or N.
	Power off transiently	Add options of capacitor boxes.
	The line has too small capacity or great rush current exists on the lines.	Make renovation on power supply system.
Over heat E.OHt	Too high ambient temperature	Improve ambient conditions
	Cooling fans do not work.	Check A27, reduce fan starting temperature(when there is fan control)
	The carrier frequency is too high	Check the setting value of function F16

Note:

- Switch off the power supply, and do not touch the PCBs and any parts inside in five minutes after the charging indicator light (! CHARGE) goes off. Ensure the capacitance has been discharged completely by measuring with the instrument before work inside. Otherwise, there is a danger of electric shock.
- Do not touch the PCB or IGBT and other internal parts unless actions have been taken to prevent the static electricity. If not, the components may be damaged.

Section VI.

Section VII Standard Specifications

7-1. Specification

7-1-1. VFR-080 Specification

Inverter type	Light Load F		Standard Load G		Medium Load M		Heavy Load H		Frame Size
	P _F kW	I _F A	P _G kW	I _G A	P _M kW	I _M A	P _H kW	I _H A	
3 phase voltage 380V 50/60Hz									
VFR-080-T4-...	15	32	11	25	7.5	16			80N2
VFR-080-T4-...	18.5	38	15	32	11	25	7.5	16	80N2
VFR-080-T4-...	22	45	18.5	38	15	32	11	25	80N3
VFR-080-T4-...	30	60	22	45	18.5	38	15	32	80N3
VFR-080-T4-...	37	75	30	60	22	45	18.5	38	80N4
VFR-080-T4-...	45	90	37	75	30	60	22	45	80N4
VFR-080-T4-...	55	110	45	90	37	75	30	60	80N5
VFR-080-T4-...	75	150	55	110	45	90	37	75	80N5
VFR-080-T4-...	93	170	75	150	55	110	45	90	80N6
VFR-080-T4-...	110	210	93	170	75	150	55	110	80N6
VFR-080-T4-...	132	250	110	210	93	170	75	150	80N7
VFR-080-T4-...	160	300	132	250	110	210	93	170	80N7
VFR-080-T4-...	187	340	160	300	132	250	110	210	80N8
VFR-080-T4-...	200	380	187	340	160	300	132	250	80N8
VFR-080-T4-...	220	415	200	380	187	340	160	300	80N9
VFR-080-T4-...	250	470	220	415	200	380	187	340	80N9
VFR-080-T4-...	280	520	250	470	220	415	200	380	80N9
VFR-080-T4-...	200	380	200	380	187	340	160	300	80NA
VFR-080-T4-...	220	415	220	415	200	380	187	340	80NA
VFR-080-T4-...	250	470	250	470	220	415	220	380	80NA
VFR-080-T4-...	315	600	280	520	250	470	220	415	80NB
VFR-080-T4-...	355	640	315	600	280	520	250	470	80NB
VFR-080-T4-...	400	690	355	640	315	600			80NB
VFR-080-T4-...	450	740	400	690					80NB

Section VII

7-1-2. VFR-081 Specification

Inverter type	Light Load F		Standard Load G		Medium Load M		Heavy Load H		Size
	P _F kW	I _F A	P _G kW	I _G A	P _Z kW	I _Z A	P _H kW	I _H A	
Single phase voltage 220V 50/60Hz									
VFR-081-M2-...	0.75	4	0.4	2.5					70N2
VFR-081-M2-...	1.5	7	0.7 5	4	0.4	2.5			70N2
VFR-081-M2-...			1.5	7	0.75	4	0.4	2.5	70N2
VFR-081-M2-...	2.2	10	2.2	10	1.5	7	0.75	4	70N3
VFR-081-M2-...	4	16	4	16	2.2	10	1.5	7	70N3
VFR-081-M2-...	5.5	20	5.5	20	4	16	2.2	10	70N4
3 phase voltage 220V 50/60Hz									
VFR-081-T2-...	0.75	4	0.4	2.5					70N2
VFR-081-T2-...	1.5	7	0.7 5	4	0.4	2.5			70N2
VFR-081-T2-...			1.5	7	0.75	4	0.4	2.5	70N2
VFR-081-T2-...	2.2	10	2.2	10	1.5	7	0.75	4	70N3
VFR-081-T2-...	4	16	4	16	2.2	10	1.5	7	70N3
VFR-081-T2-...	5.5	20	5.5	20	4	16	2.2	10	70N4
3 phase voltage 380V 50/60Hz									
VFR-081-T4-...	0.75	2.5	0.7 5	2.5	0.75	2.5	0.75	2.5	70N2
VFR-081-T4-...	1.5	3.7	1.5	3.7	1.5	3.7	1.5	3.7	70N2
VFR-081-T4-...	2.2	5	2.2	5	2.2	5	2.2	5	70N2
VFR-081-T4-...	4	8.5	4	8.5	4	8.5	4	8.5	70N3
VFR-081-T4-...	5.5	13	5.5	13	5.5	13			70N3
VFR-081-T4-...	7.5	16	7.5	16	7.5	16	5.5	13	70N4
VFR-081-T4-...	11	25							70N4

Section VII

7-1-3. Table of rated current for different specifications

Voltage	G/F/H/S/Z/T/M					
	220V 1Φ	220V (240V)	380V (415V)	460V (440V)	575V	660V
Power (kW)	Current (A)	Current (A)	Current (A)	Current (A)	Current (A)	Current (A)
0.4	2.5	2.5	-	-	-	-
0.75	4	4	2.5	2.5	-	-
1.5	7	7	3.7	3.7	-	-
2.2	10	10	5	5	-	-
4	16	16	8.5	8	-	-
5.5	-	20	13	11	-	-
7.5	-	30	16	15	-	-
11	-	42	25	22	17	15
15	-	55	32	27	22	18
18.5	-	70	38	34	26	22
22	-	80	45	40	33	28
30	-	110	60	55	41	35
37	-	130	75	65	52	45
45	-	160	90	80	62	52
55	-	200	110	100	76	63
75	-	260	150	130	104	86
93	-	320	170	147	117	98
110	-	380	210	180	145	121
132	-	420	250	216	173	150
160	-	550	300	259	207	175
187	-	600	340	300	230	198
200	-	660	380	328	263	218
220	-	720	415	358	287	240
250	-	-	470	400	325	270
280	-	-	520	449	360	330
315	-	-	600	516	415	345
355	-	-	640	570	430	370
400	-	-	690	650	520	430
450	-	-	740	700	600	490
500	-	-	860	800	650	540

7-2. Standard specification

Items		Specifications		
Power	Voltage and frequency	Single-phase 200~240V, 50/60Hz Three-phase 200~240V, 50/60Hz Three-phase 380~415V, 50/60Hz Three-phase 440~460V, 50/60Hz Three-phase 575V, 50/60Hz Three-phase 660V, 50/60Hz Three-phase 1140V, 50/60H		
	Allowable Fluctuation range	voltage: $\pm 15\%$ frequency: $\pm 5\%$		
Control	Control system	high performance vector control inverter based on 32 bit DSP		
	Output frequency	G/F/Z/S/T/M type: 0.00~800.0Hz, maximum frequency can be set between 10.00 and 800.0Hz H type: 0.00~2000.0Hz, maximum frequency can be set between 10.00 and 2000.0Hz		
	control method	V/Fcontrol	Sensorless vector control	Sensor close loop vector control
	Start torque	0.50Hz 180%	0.25Hz 180%	0.00Hz 180%
	speed adjustable range	1: 100	1: 200	1: 2000
	Speed stabilizing precision	$\pm 0.5\%$	$\pm 0.2\%$	$\pm 0.02\%$
	waveform produce methods	Asynchronous space vector PWM, N-class sub-synchronous space vector PWM, two-phase optimization of space vector PWM.		
	Auto torque boost function	Achieve low frequency (1Hz) and high output torque control under V.F control mode.		
	Accelerate /decelerate control	Sub-set S curve acceleration and deceleration mode, maximum acceleration and deceleration time is 3200 days		
	Long running time control	16 segments speed run, maximum running time is 3200 days		
	frequency setting accuracy	Digit: 0.01Hz(below 300Hz), 0.1Hz(above 300Hz); alalogue: 1% of maximum frequency		
	frequency accuracy	Speed control tolerance 0.01%(25°C \pm 10°C).		
	V/F curve mode	Linear, 1.2 times the power, 1.7 times the power, 2 times power, user-set 8 V / F Curve.		
	Over load capability	G / S type: 150% rated current -1 minute, rated current 200% -0.1 second; F: rated current 120% -1 minute 150% of rated current -0.1 second; Z / M / T type: rated current 180% -1 minute 250% rated current -0.1 second; H: rated current 250% -1 minute 300% rated current -0.1 second.		
	slip compensation	V / F control can automatically compensate for deterioration.		
Running	Running method	Keyboard/terminal/communication		
	Starting signal	Forward, reverse, jog (parameter control direction), forward jog, and reverse jog.		


	Emergency stop	Interrupt controller output.
	fault reset	When the protection function is active, you can automatically or manually reset the fault condition.
	Running status	Motor status display, stop, acceleration and deceleration, constant speed, the program running.
	DC brake	Built-in PID regulator brake current flow in the premise, however, to ensure adequate braking torque.
Protection	Inverter protection	Overvoltage protection, undervoltage protection, overcurrent protection, overload protection, over-temperature protection, over the loss of speed protection, over-voltage stall protection, phase protection (optional), external fault, communication error, PID feedback signal abnormalities, PG failure
	IGBT temperature display	Display current IGBT temperature
	Inverter fan control	The fan starting temperature can be set(optional)
	Instant power-down re-start	Less than 15 milliseconds: continuous operation. Greater than 15 milliseconds: Automatic detection of motor speed, instantaneous power-down re-start.
	Speed starting track method	automatically track motor speed when inverter starts
	Parameter protection function	Protect inverter parameters by setting the password and decoding
IO	8 way switch input	Can be customized into 68 kinds of functions, to achieve forward, reverse, forward jog, and reverse jog, emergency stop, reset, speed, acceleration speed, run-time switch, and pulse counting.
	3 way analog inputs	Can be defined as a switch input; To allow for maximum input range-10V ~ +10V, 0 ~ 20mA
	2 way analog output	Can achieve output range 0 ~ +10V, 0 ~ 20mA
	Virtual terminal function	Can be set to a virtual terminal, using communication or keyboard IO port, and with the IO port status display.
Keyboard	Frequency set	In 6 main ways + to 7 kinds of auxiliary to the way of the keyboard, three way analog input, pulse input, digital potentiometers.
	Keyboard cable	8-core cable, in line with EIA T568A, EIA T568B standards.
	Double keyboard port	Supports dual-keyboard, synchronous control, independently of each other.
	Double and multi function keys	MF1, MF2 can be customized as addition and subtraction, forward, reverse, forward jog, and reverse jog, emergency stop, rise and fall, and other 9 kinds of ways.
	4-parameter storages	Control panel can be realized four groups of inverter parameters of upload, download, with manufacturer password to reset factory setting.
	Running info	At most display 3 monitoring parameters. Select by A00, A01, A02
	Fault info	Store 5 groups error messages at most, you can check the type of failure time when failure occurs, set frequency, output frequency, output voltage, output current, running state, running time, IGBT temperature.
Commu-	Double RS485 port	Rs485 port and an optional keyboard completely isolated RS485

nication		communication module.
	CAN BUS	Can select can-bus module.
Speed	16-segment speed	At most 16 segments can be set (use multi-functional terminal to shift or program runs).
	8-segment running time	At most 8 segment running time can be set (multi-functional terminal can be used to shift)
	8 segment acceleration speed	At most 8 acceleration speed (can use the multi-functional terminal to switch).
	Seven-Segment Speed Configuration	At most 7 segment speed configuration can be set (multi-functional terminal can be used to switch).
PID	PID feedback signal	Six kinds of ways, keyboard, three way analog input, pulse input, digital potentiometers.
	PID giving signal	Six kinds of ways, keyboard, three way analog input, pulse input, digital potentiometers.
Motor	2 groups of motor parameters	With the motor parameters, parameter can be selected, parameter identification automatic storage.
	3 identification method	Name plate calculation, static measurement, rotation measurements.
	5 name plate parameters	Rated frequency, rated current, rated voltage, the number of pole pairs, rated speed.
	5 identification parameters	N-load current, stator resistance, rotor resistance, stator inductance, mutual inductance.
	Environment temperature	-10°C ~ 40°C, 40 ~ 50°C derating between the use is increased by 1 °C, rated output current decrease of 1%.
Environment	Store temperature	-40°C ~ +70°C
	Environment humidity	5~ 95 %, No condensation
	Height-vibration	0 ~ 2000 meters, 1000 meters above derating use, increased by 100 m, rated input decreased%
	Application location	Mounted vertically inside the control cabinet with good ventilation, do not allow the level, or other installation method. The cooling medium is air. Installed in the absence of direct sunlight, N dust, N corrosive and explosive gas, N oil mist, N steam, N drip environment
	Cooling method	Forced air cooling and natural air cooling.

7-3. Frame Size

7-3-1. VFR-080 family (3 phase voltage 380~415V, 50/60Hz)

1. 80N2~80N9



1) 80N2

Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	15~18.5	80N2	380	220	230	360	135	Ø10
G	11~15							
M	7.5~11							
H	7.5							

2) 80N3

Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	22~30	80N3	460	280	245	440	160	Ø10
G	18.5~22							
M	15~18.5							
H	11~15							

3) 80N4

Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	37~45	80N4	500	300	270	480	200	Ø10
G	30~37							

M	22~30							
H	18.5~22							

4) 80N5

Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	55~75	80N5	630	360	297	610	200	Ø10
G	45~55							
M	37~45							
H	30~37							

5) 80N6

Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	93~170	80N6	700	400	297	680	200	Ø10
G	75~93							
M	55~75							
H	45~55							

6) 80N7

Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	132~160	80N7	750	475	320	730	260	Ø10
G	110~132							
M	93~110							
H	75~93							



7) 80N8

Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	187~200	80N8	850	500	320	830	260	Ø10
G	160~187							
M	132~160							
H	110~132							

8) 80N9



Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	220~250~280	80N9	1000	600	380	940	370	Ø14
G	200~220~250							
M	187~200~220							
H	160~187~200							

2. 80NA



Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	200~220~250	80NA	1540	515	443	465	367	Ø13
G	200~220~250							
M	187~200~220							
H	160~187~220							

3. 80NB




Type	Power (kW)	Frame Size	Shape			Installation dimension		
			L	W	H	a	b	d
F	315~355~400~450	80NB	1700	850	492	640	260	Ø13
G	280~315~355~400							
M	250~280~315							
H	220~250							

7-3-2. VFR-081 Family


1. 70N2~70N4

1) 70N2




Power type	Type	Power (kW)
Single phase 220V	F	0.75~1.5
	G	0.4~1.5
	M	0.4~0.75
	H	0.4
3 phase 220V	F	0.75~1.5
	G	0.4~1.5
	M	0.4~0.75
3 phase 380V	F	0.75~1.5~2.2
	G	0.75~2.2
	M	0.75~2.2
	H	0.75~2.2

2) 70N3



Power type	Type	Power (kW)
Single phase 220V	F	2.2~4
	G	2.2~4
	M	1.5~2.2
3 phase 220V	H	0.75~1.5
	F	2.2~4
	G	2.2~4
3 phase 380V	M	1.5~2.2
	H	0.75~1.5
	F	4~5.5
3 phase 380V	G	4~5.5
	M	4~5.5
	H	4


3) 70N4




Power type	Type	Power (kW)
Single phase 220V	F	5.5
	G	5.5
	M	4
3 phase 220V	H	2.2
	F	5.5
	G	5.5
3 phase 380V	M	4
	H	2.2
	F	7.5~11
3 phase 380V	G	7.5
	M	7.5
	H	5.5

7-3-3. Keyboards size

VFR-08C-KBR:




VFR-08-HOL : keyboard holder



Section VII

VFR-08E-KBR:



Section VIII. Maintenance

8-1. Inspection and Maintenance

Under normal working conditions, in addition to daily inspection, the frequency converter should be subject to regular inspection (for example inspection for overhaul or as specified but at an interval of six months at most). Please refer to the following table in order to prevent faults.

Check time		Check point	Check item	Check to be done	Method	Criterion
D	R					
√		Display	LED and OLED display	If there is any abnormal display	Visual check	As per use state
√	√	Cooling system	Fan	If abnormal noise or vibration is produced.	Visual and audible check	No abnormal sound or vibration
√		Body	Surrounding conditions	Temperature, humidity, dust content, harmful gas, etc.	Check visually, by smelling and feeling	As per Section 2-1
√		Input/output terminal	Voltage	If input, output voltage is abnormal	Measure at R, S, T and U, V, W terminals	As per standard specifications
	√	Main circuit	Overall conditions	If the fastenings come loose, if any signs show overheat, discharging, or too high dust content, or the air piping is blocked	Check visually, tighten the fastenings, and clean the related parts	No abnormal conditions
			Electrolytic capacitance	If there is abnormal appearance	Check visually	No abnormal condition
			Current-conducting leads or blocks	If the parts come loose	Check visually	No abnormal condition
			Terminals	If the screws or bolts come loose	Tighten the loose screws or bolts	No abnormal condition

“D” means daily check and “R” means regularly check.

“√” means need daily check or regularly check

For inspection, do not disassemble or shake the parts without reason, and still less pull off the plug-in-parts at random. Otherwise, the unit will not operate normally, or can not enter the mode of fault display, or causes faults of components or even parts of the main switch components IGBT module is damaged.

If measuring is necessary, the user should note that much different results will be gained possibly if the measuring is performed with different instruments. It is recommended that the input voltage be measured with pointer-type voltmeter, output voltage with rectification voltmeter, input and output current with tong-test ammeter, and power with electrically-driven wattmeter.

8-2. Storage

The following actions must be taken if the frequency converter is not put into use immediately after delivery to the user and need to keep well for the time being or stored for a long time:

- Stored in a dry and adequately-ventilated place without dust and metal powder at the temperature specified in the specifications.
- If the frequency converter is not put into use after one year, a charge test should be made, so as to resume the performance of the filtering capacitor of main circuit in it. For charging, a voltage regulator should be used to slowly increase the input voltage of the frequency converter until it

reaches the rating, and the charge should last more than 1~2 hours. This test should be made at least once a year.


- Don't perform breakdown test at random, for this test will cause shorter life of the frequency converter. The insulation test must be performed after the insulation resistance is measured with a 500-volt megaohm and this value must not be less than 4MΩ.

8-3. Measuring and Judgment

- If the current is measured with the general instrument, imbalance will exist for the current at the input terminal. Generally, differing by not more than 10% is normal. If it differs by 30%, inform the factory to replace the rectification bridge, or check if the error of three-phase input voltage is above 5V.
- If the three-phase output voltage is measured with a general multi-meter, the reading is not accurate due to the interference of carrier frequency and only for reference.

Section IX. Options

The series may require peripheral equipments according to different usage conditions and requirement. See the wiring diagram below:



9-1. MCCB OR ELCB

MCCB or ELCB protects the inverter, but cannot control inverter to run or stop.

9-2. AC reactance


AC reactance is able to restrain the high harmonic wave of converter input current and improve converter's power factor. It's recommended that AC reactance will be used in the following conditions:

- The capacity of power source is ten times more than the capacity of converter.

Section IX Options

- SCR load or power factor compensated device with ON/OFF is connected with the same power supply.
- Unbalanced 3-phase voltage is bigger (more than 3%).

The common size of AC input reactance:



Unit Size :

Inverter standard		Size (mm)						Gross Weight (kg)
Voltage	Capacity (kW)	A	B	C	D	E	F	
200V 230V	0.75	155	125	95	7	89	60	3.0
	1.5	155	125	95	7	89	60	3.0
	2.2	155	125	95	7	89	60	3.0
	4	155	125	95	7	89	60	3.5
	5.5	155	125	100	7	89	60	3.5
	7.5	155	125	112	7	89	70	4.0
	11	155	125	112	7	89	70	6.0
	15	180	140	112	8	90	80	8.0
	18.5	180	140	112	8	90	90	8.0
	22	180	140	112	8	90	90	8.0
	30	230	175	122	10	160	90	12.0
	37	230	175	132	10	160	100	15.0
45	230	175	150	10	160	110	23.0	
55	230	175	160	10	160	120	23.0	
75	285	220	230	14	180	130	30.0	
380V 460V	0.75	155	125	95	7	89	60	3.0
	1.5	155	125	95	7	89	60	3.0
	2.2	155	125	95	7	89	60	3.0
	4	155	125	95	7	89	60	3.5
	5.5	155	125	100	7	89	60	3.5

	7.5	155	125	112	7	89	70	4.0
	11	155	125	112	7	89	70	6.0
	15	180	140	112	8	90	80	8.0
	18.5	180	140	112	8	90	90	8.0
	22	180	140	112	8	90	90	8.0
	30	230	175	122	10	160	90	12.0
	37	230	175	132	10	160	100	15.0
	45	230	175	150	10	160	110	23.0
	55	230	175	160	10	160	120	23.0
	75	285	220	230	14	180	130	30.0
	110	285	250	230	14	210	140	33.0
	160	360	260	230	14	210	140	40.0
	200	360	270	230	14	210	140	45.0
	250	400	330	240	14	240	140	55.0
	315	400	350	285	14	270	160	90.0

9-3. Noise filter

The filter is used to restrain the conduction of electrical magnetic wave interference noise produced by the converter. The common size of 3-phase EMI noise filter is shown as following: confirm the power supply is 3-phase three lines or 3-phase four lines or single phase. Earthling wire is as short as possible, try to place the filter near the converter.

Please choose EMI filter when the converter is used in residential area, commercial area... in order to prevent magnetic interference, and meet CE, UL, and CSA standard.

Note: If a filter is needed, please contact us.

9-4. Contactor

It can cut off the supply power in action if system protection function is enabled. But cannot control the motor start and stop.

9-5. Braking Unit & braking resistor

There is braking unit inside when using "B" type frequency converter, the maximum braking torque is 50%. Please choose braking resistor according to the following table:

Type	Converter power (kW)	Braking resistor (Ω)	Braking resistor Power (W)
220V	0.75	200	120
	1.5	100	300
	2.2	70	300
	4	40	500
	5.5	30	500
	7.5	20	780
	11	13.6	2000

	15	10	3000
	18	8	4000
	22	6.8	4500
380V	0.75	750	120
	1.5	400	300
	2.2	250	300
	4	150	500
	5.5	100	500
	7.5	75	780
	11	50	1000
	15	40	1500

Please choose INORÉA BRAKING UNIT if you need more braking torque. Please refer to braking units' catalogue.

There is no braking unit feature into large size frequency converters. Please choose INORÉA BRAKING UNIT if you need one.

9-6. Output EMI filter

The fittings can restrain the disturbance noise and lead leak current produced in the output side.

9-7. AC output reactor

When the line from inverter to motor is longer than 20 meters, it can restrain the over-current caused by the distributing current and the wireless disturbance of the inverter.

Section X Quality Assurance

The product quality assurance is in accordance with

We provide a 3-level inspection service to ensure product is fully compliant with specifications and Standards (Low voltage directive 2006/95/EC, Machinery directive 2006/42/EC, EMC directive 2004/108/EC, CE marking and RoHS compliance)

Warranty:

1. The product warranty period is two years from the date of shipment.
2. In the case of the following causes of failure, even in the warranty period repair fees will be charged:
 - Incorrect operation (depending on the use of manual) or unauthorized modification of the product.
 - The problems caused by using the inverters beyond its standard specifications requirement.
 - Damage caused by drop down or mishandling.
 - Inverters components aged or failure caused by improper environment.
 - Due to an earthquake, fire, wind and water disasters, lightning, abnormal voltage or other natural disasters and disasters, accompanied by the damage caused.
 - Damage during transport (Note: The mode of transport designated by the customer, the company's help on behalf of the procedures for handling the transfer of goods).
 - When manufacture's brand, trademark, serial number, nameplate cannot be recognized.
 - If buyer has not paid full money according to purchase agreement.
 - Installation, wiring, operation, maintenance cannot be stated clearly by user.
3. Concerning refund, replacement and repair services, a formal agreement need to be given by iNOR&A prior to product return.

Section X

Appendix I. RS485 Communication Protocol

I-1. Use introduce

This chapter introduces something about the install and handle of RS485 communication between inverter and PLC, PC, factory computer.

RS485 standard interface

- Can communicate with all computer
- Using multi-drop link system, can link more to 127 inverters
- Completely isolated, and noise shield
- The user would use all types of RS232-485 inverter, if only the inverter had "automatic RTS control" function inside.

I-2. Specification

Communication function

Items	Specification
Communication baud rate	38400/19200/9600/4800/2400/1200 bps is selectable.
Communication Protocol	Modbus protocol, RTU format
Interface methods	Asynchronism communication methods, semi-duplex, the previous high byte, low byte in the post, and low-effective-bit pre-emptive.
Data fumula	1 start bit, 8 data bits, 1 stop bit, invalid parity bit.
Slave address	Slave addresses can be set up 1~ 127 0 for broadcast address, host address 128 for the proportion of linkage, other addresses are reserved.
Communication port A	Isolated RS485 Communication Card, Terminals SG+, SG- RS232 communication card, terminals TX232, RX232 Shield SH, Default 19200bps.
Communication port B	RJ45, 8-core shielded cable, fixed 19200bps.


I-3. Communication connection

I-3-1. Definition for Communication port A:


- RS485 communication module installation

Appendix I

8K-RS485_S connect to 8KLCB control board




8K-RS485_S connect to 8KSCB control board




- Link RS485 communication cables to inverter control terminals (SG+), (SG-).
- When using RS232-485 transform, connect Inverter “SG+” to RS485 “T+”, Inverter “SG-” to RS485 “T-”.
- After Confirming connection again, turn on inverter power.
- If connection is right, set communication parameters as following:
- A29 baud rate 0: 1200, 1: 2400, 2: 4800, 3: 9600, 4: 19200, 5: 38400

- A28 current inverter communication address 1~127 (If there are more than 1 inverters, don't use the same number);
- When using RS485 running control methods, set F04=0/1/2, choice RS485 running control method



I-3-2. Definition for Communication port B:

Communication port B pins	1	2	3	4	5	6	7	8
Communication B port signal	GND	+5V	485+	485-	485+	485-	+5V	GND
EIA/TIA T568A	White green	green	White orange	blue	white Blue	orange	White Brown	brown
EIA/TIA T568B	White Orange	Orange	White Green	Blue	White Blue	green	White Brown	brown




I-3-3. Data safety and reliability

- The number of inverter can be connected is no more than 127.
- Though the length of communication cable can add up to 1300m, considering the stability, the length limit within 800m.
- All the control signal cable use the shield cable, and is linked to the signal terminal “SH” of RS485.
- Data packet using CRC (vertical lengthy test) frame detection to ensure data reliability.
- Completely isolated RS485 communication module to ensure reliable communications, support hot-swappable, after modular access, you can enter the work.
- The system is tested in 6 kinds of baud rate: 0:1200, 1:2400, 2:4800, 3:9600, 4:19200, 5:38400
- However, if under deteriorating environmental conditions, lowering the baud rate can improve the communication quality.
- Interval time of sending from frame to frame is more than 50 bytes.

I-4. Communication Protocol

Communication architecture is inverter as a slave, the computer as a host.

MODBUS protocol defines a simple protocol data unit (PDU) which has nothing to do with a basic communication layer, Specific bus or network MODBUS protocol mapping can introduce some additional domain from application data unit (ADU).



The basic format description

I-4-1: Start of frame, End of frame
Interval ≥ 3.5 bytes,

I-4-2: Slave Address

From the machine's local address, through the A28 parameter settings, one network can only one local address uniquely identified.
Setting range 1 ~ 127.

00H = 0 ID address is broadcast mailing address, 128 ~ 255 reserved.

I-4-3: Function Code

Host send commands, slave response.

- Function Code Categories

0x03 = read inverter's multiple function codes, at most can read 16 registers(register pair of byte)

Host command

Frame start address	Slave address	Function code	Registers address	Register number	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

Slave response

Frame start address	Slave address	Function code	Read byte	Read content	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	1 byte	2 bytes * register number	2 bytes	Interval ≥ 3.5 bytes

Note: Read content = 2 bytes x register number

0x06 = write inverter 1 function code

Host command

Frame start address	Slave address	Function code	Registers address	Register data	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

Slave response

Frame start address	Slave address	Function code	Registers address	Register data	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 bytes	1 bytes	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

0x10 = Write multiple function in inverter, at most can be written in 16 registers(register pair of byte)

Host command

Frame start address	Slave address	Function code	Register address	Register number	Register content byte	Register content	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	1 byte	2 bytes * register number	2 bytes	Interval ≥ 3.5 bytes

Slave response

Frame start address	Slave address	Function code	Register address	Register number	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

0x01 = Read multiple switch status

Host Command

Frame start address	Slave address	Function code	address	Switch number	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

Slave response

Frame start address	Slave address	Function code	Read byte number	switch state	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	1 byte (data N)	N bytes	2 bytes	Interval ≥ 3.5 bytes

Note: read byte number N = output quantity / 8, if the remainder is not 0, read byte number is N = N + 1

0x05 = Write single switch status

Host Command

Frame start address	Slave address	Function code	Output address	Output value	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

Note: output value 0xFF00, switch ON; output value 0x0000, switch OFF. Other values are illegal, the switch does not work.

Slave response

Frame start address	Slave address	Function code	Output address	Output value	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

If slave response and get back to below function code, it means communications abnormal.

0xA0 =0x80+0x20= Invalid operation, setting under this state is invalid

0xA1 =0x80+0x21= function code is invalid

0xA2 =0x80+0x22= Fault record is empty

0xA3 =0x80+0x23= register address is invalid

0xA4 =0x80+0x24= slave is busy, EEPROM delay.

0xA5 =0x80+0x25= administrator restricted

0xA6 =0x80+0x26= set value is beyond limit.

0xA7 =0x80+0x27= CRC checksum error

0xA8 =0x80+0x28= frame format error

I-4-4: Register Address:

The register address includes two bytes, data setting is constituted by a two-byte.

Function code	Register Address high byte		Register Address low byte	
0x03read inverter multiple function.code parameter	Parameter group		Parameter serial number	
	F	0x00	0~63	
	A	0x01	0~63	
	o	0x02	0~71	
	H	0x03	0~55	
	U	0x04	0~15	
	P	0x05	0~15	
	E	0x06	0~23	
	C	0x07	0~47	
	b	0x08	0~23	
	y NOTE 1	0x09	0~23	
S	0x0B	0~15		
0x03.read inverter status	Status		Status number	
	R	0x10	0x00	Running status NOTE 2
			0x01	Reserved status 1
			0x02	Reserved status 2
0x03			Reserved status 3	
0x03read inverter.fault history record	Fault record		Fault status history record content	
	Fault history record 1 Fault history record 2 Fault history record 3 Fault history record 4 Fault history record 5	0x20 0x21 0x22 0x23 0x24	0x00	Fault type NOTE 4
			0x01	Set frequency
			0x02	Actual frequency
			0x03	Actual current
			0x04	DC voltage
			0x05	Running status NOTE 5
			0x06	Running time
0x07			IGBT temperature	
0x06.write inverter.single	Register Address high byte		Register Address low byte	
	Parameter group	High byte	Parameter serial number	

function.code parameter, only write RAM	F	0x00	0~63			
	A	0x01	0~63			
	o	0x02	0~71			
	H	0x03	0~55			
	U	0x04	0~15			
	P	0x05	0~15			
	E	0x06	0~23			
	C	0x07	0~47			
	b	0x08	0~23			
	y NOTE 1	0x09	0~23			
0x06.write inverter command	Command		Command number			
	R	0x10	0x00	Running command NOTE 3		
			0x01	Reserved command 1		
			0x02	Reserved command 2		
0x03			Reserved command 3			
Function parameter write EEPROM, register address high byte=original register address high byte+0x80						
0x06.write inverter.single function.code parameter	Register address high byte		Register address low byte			
	parameter		Parameter serial number			
	F	0x80	0~63			
	A	0x81	0~63			
	o	0x82	0~71			
	H	0x83	0~55			
	U	0x84	0~15			
	P	0x85	0~15			
	E	0x86	0~23			
	C	0x87	0~47			
0x10.write inverter multiple function code parameter	b	0x88	0~23			
	y NOTE 1	0x89	0~23			
	Register address high byte		Register address low byte			
	Switch classify	address	Parameter value			
0x01.read multiple switch status	Running status	0x00	0	Control method	0	V/F control
				1	SV control	
			1	reserved		
			2	Running status	0	stop
					1	run
			3	Direction status	0	reverse
					1	forward
			5,4	Speed up status	00	stop
					01	acceleration
					10	deceleration
11	uniform speed					
6	upper	0	Upper frequency			
0x05.Write single.switch status	Running status	0x00	0	stop		
			1	run		

	Input.terminal function	0x01	frequency	0	not arrive		
				1	Arrive		
			7	Lower frequency	0	lower frequency	
					1	Arrive	
			8	JOG running	0	No JOG running	
					1	JOG running	
			9	Reserved			
			10	Reserved			
			11	Reserved			
			12	Fault confirm	0	Confirmed fault	
					1	Unconfirmed fault	
			13	Direction status	0	No fault	
					1	alarming fault	
			14	JOG status	0	No fault	
					1	Deceleration stop fault	
	15	Fault status	0	No fault			
			1	Urgent stop fault			
	Input.terminal function	0x01	0	DI1 input	0	Invalid	
					1	Valid	
			1	DI2 input	0	Invalid	
					1	Valid	
			2	DI3 input	0	Invalid	
					1	Valid	
			3	DI4 input	0	Invalid	
					1	Valid	
			4	DI5 input	0	Invalid	
					1	Valid	
			5	DI6 input	0	Invalid	
1					Valid		
6			DI7 input	0	Invalid		
				1	Valid		
7			DI8 input	0	Invalid		
				1	Valid		
8			AI1 input	0	Invalid		
				1	Valid		
9			AI2 input	0	Invalid		
				1	Valid		
10	AI3 input	0	Invalid				
		1	Valid				

Output.terminal function	0x02	0	O1 input	0	Invalid		
				1	Valid		
		1	O2 input	0	Invalid		
				1	Valid		
		2	O3 input	0	Invalid		
				1	Valid		
		3	O4 input	0	Invalid		
				1	Valid		
		Fault type	0x03	0	E.OCP	System is disturbed or impacted by instant over current,over current signal from current inspected circuit or drive circuit	
						reserved	
				2	E.OC3	Inverter output current exceeded 3times the motor rated current	
						reserved	
	4			E.OU	Over voltage		
	5			E.LU	Under voltage		
	6			E.OL	Over load		
	7			E.UL	Under load warming		
	8			E.PHI	Phase loss		
	9			E.EEP	EEPROM error		
	10			E.nTC	Over heat		
	11			E.dAt	Time limit fault		
	12	E.Set	External fault				
	13	reserved					
	14	reserved					
	15	reserved					
16	E.PId	PID regulation fault					
17	E.OHt	Motor over heat fault					
18	E.OL2	Motor over load fault					
19	E.PG	PG error					
20	E.PHo	Inverter output phase loss					
21	E.COa	Rs485.communication port A fault					
22	E.COb	Rs485.communication port B fault					
23	E.CAL	Parameter identification fault					
Register address high byte		Register address low byte					
Switch classify		address	Parameter number				
Running status	0x00	0	Run command	0	stop		
				1	run		

			1	reserved		
			2	Direction command	0	reverse
					1	forward
			3	reserved		
			4	reserved		
			5	JOG command	0	reverse
					1	forward
			6	reserved		
			7	Free stop	0	reverse
					1	forward
			8	reserved		
			9	reserved		
			10	reserved		
			11	reserved		
			12	reserved		
13	reserved					
14	reserved					
15	reserved					
Input.terminal function	0x01	0	DI1 input	0	invalid	
				1	valid	
		1	DI2 input	0	invalid	
				1	valid	
		2	DI3 input	0	invalid	
				1	valid	
		3	DI4 input	0	invalid	
				1	valid	
		4	DI5 input	0	invalid	
				1	valid	
		5	DI6 input	0	invalid	
1	valid					
6	DI7 input	0	invalid			
		1	valid			
7	DI8 input	0	invalid			
		1	valid			
8	AI1 input	0	invalid			
		1	valid			
9	AI2 input	0	invalid			
		1	valid			
10	AI3 input	0	invalid			
		1	valid			
Output.terminal function	0x02	0	O1 output	0	invalid	
				1	valid	
		1	O2 output	0	invalid	

			2	O3 output	1	valid
					0	invalid
			3	O4 output	1	valid
					0	invalid

NOTE 1:

Function	0x03 reading operation		0x06/0x10 writing operation	
y00 reset the factory setting	Return 0		Only can write into 5	
y01 upload parameter onto keyboard	Return 0		Invalid operation	
y02 latest fault record	Valid operation		Invalid operation	
y03~y07 fault history record	Empty record	00H	Invalid operation	
	New record	01H		
	Confirmed record	02H		
y08reset fault record	Return 0		Valid operation	
y09 rated output current	Valid operation		Invalid operation	
y10 rated output voltage	Valid operation		Invalid operation	
y11 products series	80	0	3	Invalid operation
	Family serial	products series	Input voltage level	
	The number should be decimalization.			
y12 soft ware version	Valid operation		Invalid operation	
y13 product date –year	Valid operation		Invalid operation	
y14 product month–date	Valid operation		Invalid operation	
y15 user decode input	Valid operation		Invalid operation	
y16 user input password	Valid operation		Valid operation	
y17 parameter group protection	Valid operation		Valid operation	

NOTE 2: running status byte

BIT	15 BIT	14 BIT	13 BIT	12 BIT
meaning	0: No fault 1: urgent stopping fault	0: No fault 1: decelerating fault	0: No fault 1: alarming fault	0: confirmed fault 1: unconfirmed fault
bit	11 BIT	10 BIT、	9 BIT	8 BIT
meaning	reserved	reserved	reserved	0: No JOG 1: JOG running
bit	7 BIT	6 BIT	5 BIT 、 4 BIT	
meaning	0: lower frequency not arriving 1: arrive lower	0: upper frequency not arriving 1: arrive upper	00: stopping 10: decelerating	01: accelerating 11: running in a even speed

	frequency	frequency		
bit	3 BIT	2 BIT	1 BIT	0 BIT
meaning	0: running reverse 1: running forward	0: stopping 1: running	reserve	0: V/F control 1: SV control

NOTE 3: running command

bit	15 BIT	14 BIT	13 BIT	12 BIT
meaning	reserve	reserve	reserve	reserve
Bit	11 BIT	10 BIT	9 BIT	8 BIT
meaning	reserve	reserve	reserve	reserve
bit	7 BIT	6 BIT	5 BIT	4 BIT
meaning	0: No free-stop 1: free-stop command	reserve	0: JOG stopping 1: JOG running	reserve
bit	3 BIT	2 BIT	1 BIT	0 BIT
meaning	reserve	0: reverse command 1: forward command	reserve	0: stop command 1: run command

NOTE 4: fault style code

Serial number	LED display	Fault message
0	E.OCP	System is disturbed or impacted by instant over current, over current signal from current inspected circuit or drive circuit
1	reserve	
2	E.OC3	Inverter output current exceeded 3 times of motor rated current
3	reserve	
4	E.OU	Over voltage
5	E.LU	Under voltage
6	E.OL	Over load
7	E.UL	Under load warm
8	E.PHI	Input phase loss
9	E.EEP	EEPROM error
10	E.ntC	Over heat
11	E.dAt	Time limit fault
12	E.Set	External fault
13	reserve	
14	reserve	
15	reserve	
16	E.PId	PID regulation fault
17	E.OHt	Motor over heat fault

18	E.OL2	Motor over load fault
19	E.PG	PG error
20	E.PHo	Inverter output loss phase
21	E.COA	Rs485 communication port A fault
22	E.COOb	Rs485 communication port B fault
23	E.CAL	Parameter identification fault

NOTE 5: fault running status

LED first position			LED second position			LED third position			LED fourth position		
Bit15-Bit12			Bit11-Bit8			Bit7-Bit4			Bit3-Bit0		
F	0	Forward	F	0	Forward status	-	0	Separative sign	A	1	Accelerating
R	1	Reverse	R	1	Reverse status				D	2	Decelerating
S	2	Stop command	S	2	Stop status				E	3	running in a even
									S	0	stop

E.g. keyboard display FF-A (return data 0001), said when fault occurs the inverter state: forward command、forward state、accelerating running

I-4-5: CRC checkup sum

Data meaning: data frame CRC checkup sum, using 2 bytes.

Checkup sum = address + function code + data

Enclose: CRC computation program:

unsigned int cal_crc16 (unsigned char *data, unsigned int length)

```

{
unsigned int i,crc_result=0xffff;
while(length--)
{
crc_result^=*data++;
for(i=0;i<8;i++)
{
if(crc_result&0x01)
crc_result=(crc_result>>1)^0xa001;
else
crc_result=crc_result>>1;
}
}
}
crc_result=((crc_result&0xff)<<8)|(crc_result>>8);
return(crc_result);

```

I-5 Example of communication protocol:

Valid setup and communications under normal circumstances, the host command and slave responses are as follows:

0x03= read inverter multiple function code, at most can read 16 registers (register 2bytes)

Host command read inverter ,

Slave address	Function code	Register address	Register number	CRC checksum
0x08	0x03	0x0001	0x0002	0x9552

Slave response inverter to 50.00Hz, to 0 (keyboard set frequency or RS485)

Slave address	Function code	Read byte number	Read content	CRC checksum
0x08	0x03	0x04	0x1388,0x0000	0xE79D

Read byte number=2byte*register number

0x06=write inverter single function code

Host command set up inverter to 50.00Hz

Slave address	Function code	Register address	Register data	CRC checksum
0x08	0x06	0x0001	0x1388	0xD5C5

Slave response inverter to 50.00Hz

Slave address	Function code	Register address	Register data	CRC checksum
0x08	0x06	0x0001	0x1388	0xD5C5

0x10=write inverter multiple function code, at most can write 16 registers(register 2bytes)

Host command inverter to 50.00Hz, to 0 (keyboard set frequency or RS485)

Slave address	Function code	Register address	Register number	Register content byte number	Register content	CRC checksum
0x08	0x10	0x0001	0x0002	0x04	0x1388,0x0000	0x9851

Register content byte number=2 bytes * register number

Slave response

Slave address	Function code	Register address	Register number	CRC checksum
0x08	0x10	0x0001	0x0002	0x1091

0x01=read multiple switch status

Host command read inverter whether arrive lower frequency, or arrive upper frequency

Slave address	Function code	Starter to end address	Switch number	CRC checksum
0x08	0x01	0x0006	0x0002	0x5D53

Slave response inverter not arrive lower frequency nor upper frequency

Slave address	Function code	Read byte number	Switch state	CRC checksum
0x08	0x01	0x01	0x40	0x53E4

Host command read inverter fault

Slave address	Function code	Starter to end address	Switch number	CRC checksum
0x08	0x01	0x0300	0x0020	0x3D0F

Salve response inverter low voltage (E.LU switch address 0x0305)

Slave address	Function code	Read byte number	Switch state	CRC checksum
0x08	0x01	0x04	0x20,0x00,0x00,0x00	0x6911

Note : return byte : 4 bytes;

Return date in order: bit7-bit0, bit15-bit8, bit23-bit16, bit31-bit24

0x05=write single switch status

Host command control inverter running

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0xFF00	0x8CA3

Slave response

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0xFF00	0x8CA3

Host command control inverter stop

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0x0000	0xCD53

Slave response

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0x0000	0xCD53

Note: set switch to 1, output value is 0xFF00; set switch to 0,output value is 0x0000.

Appendix II Instruction of the Proportional Linkage Function

II-1. Proportional linkage function:

The proportion interaction host computer:

Communication address = 128,
 Communications port A is the communication port of host computer.
 Communication port B can be used as the keyboard interface, or a PC host computer interface.
 There is only one host inverter in one proportional linkage.
 The host inverter control the running state, the slave inverter follows the host's running state.

The proportion interaction slave computer:

Communication Address = 1 ~ 127,
 Both communication port A and communication port B can be the communication port of slave inverter.
 In the slave inverter follow the host running and it can realize forced stopping by terminal or keyboard if need.

For this function, the host computer should be set with the following parameters:

A28	Local communication address	128
-----	-----------------------------	-----

For this function, the slave computer should be set with the following parameters:

F01	Keyboard set the frequency / Rs485	Command from proportion linkage Host	
F02	Frequency main set mode	Keyboard setting frequency or RS485	0
		AI1 the external analog setting	1
		AI2 the external analog setting	2
		AI3 the external analog setting	3
		Keyboard potentiometer setting	4
		Multi-segment digital voltage set	5
		Digital Pulse Setting	6
F03	Auxiliary setting mode of frequency set	Keyboard setting frequency or RS485	0
		AI1 the external analog setting	1
		AI2 the external analog setting	2
		AI3 the external analog setting	3
		Keyboard potentiometer setting	4
		Multi-segment digital voltage setting	5
		Digital Pulse Set	6
F04	relationship between main and auxiliary frequencies	PID regulation mode	7
		The main setting individual control	0
		The auxiliary setting individual control	1
		main + auxiliary	2
		main -auxiliary	3

		(main *auxiliary)/maximum frequency	4
		Maximum {main, auxiliary}	5
		Minimum {main, auxiliary}	6
F05	Running control mode	Proportional linkage control	4
<p>Select this function, the slave inverter will follow the command of host inverter to run. After select this function, it can also use keyboard, terminal and RS485 to control the slave inverter's running. In the proportion of linkage during operation, if control by the keyboard, terminal,RS485 control, once the slave inverter stopped, the slave will N longer respond to the host command, if need the slave once again to respond to host commands, it should control through the keyboard, terminal and RS485, or after the host sends cease and desist commands then the slave will respond the command again to run.</p>			
A28	communication address	1~127	
A29	Baud rate	Same as host	
A30	Communication format	Same as host	
A55	Proportional linkage factor	0.10~10.00	

During the proportional of linkage, the running state of slave inverter is controlled by the host inverter.

Slave inverter F01 = proportional factor*the actual set frequency of host inverter of proportion linkage.

Slaver S00 actual set frequency = slave F01 + frequency give and secondary amend +ascend/descend adjusting.

II-2. Proportion linkage application Cases:

Features of proportional function:

- 1: the host inverter using the potentiometer to control the system speed and use the terminals to control the forward/reverse running.
- 2: the slave follows the host running, the proportional linkage factor is 1.00
- 3: after get the running speed command from host inverter, the slave will store this command into to F01.
- 4: the slave actual frequency is set through the keyboard or through terminal ascend/descend adjusting.
- 5: the slave actual frequency is set through potentiometer adjusting.
- 6: the slave actual frequency = F01 + slave potentiometer adjusting + A40

The proportional linkage host settings:


F02	Frequency main set mode	AI1 external analog setting
A28	Communication address	Host 128
A29	Baud rate	3: 9600bps
A30	Communication format	0
o36	DI1 input terminal function select	1:forward running
o37	DI2 input terminal function select	2:reverse running

The proportional linkage slave settings:

F02	Frequency main set	keyboard set the frequency or Rs485	0
F03	Auxiliary setting mode of	AI1 external analog setting	1

	frequency set		
F04	relationship between main and auxiliary frequencies	main+Auxiliary	2
F05	Running control mode	Proportional linkage control	4
A28	Communication address	1~127	
A29	Baud rate	Same as host inverter	
A30	Communication format	Same as host inverter	
o36	DI1 input terminal function select	39:free stopping	
o37	DI2 input terminal function select	40:Up command	
o38	DI3 input terminal function select	41:Down command	
A43	Multi-function key MF1	8:MF key is appointed to be Up command	
A44	Multi-function key MF2	9:MFkey is appointed to be Down command	

System wire connections:



Appendix III. RS485 PG Card Instruction

III-1. VFR-080 PG can use arrange

type	Encoder output method
1	+5V LINE DRIVER output
2	OPEN COLLECTOR output
3	Push-pull output type (complementary)
4	Voltage output type VOLTAGE

III-2. terminal function instruction


terminal	Terminal function
A+ A- , B+ B-	<p>PG signal input</p> <p>Encoder output method:</p> <p>1:+5V LINE DRIVER output; JP1/JP2 jump to LD; connect method: A->A+ , B->B+ A- ->A- , B- ->B-</p> <p>R16/R17/R18/R19 disconnect.</p> <p>2:OPEN COLLECTOR output; JP1/JP2 jump tp OC; Connect method: A->A+ , B->B+ R2/R4/R10/R11/R13/R15 disconnect</p> <p>3:Push-pull output type (complementary); JP1/JP2 jump tp OC; Connect method: A->A+ , B->B+ R2/R4/R10/R11/R13/R15 disconnect</p> <p>4:VOLTAGE output; JP1/JP2 jump to OC; Connect method: A->A+ , B->B+ R2/R4/R10/R11/R13/R15 disconnect</p> <p>the adjustment of resistance associated with the output voltage: V+ =5V, R16/R17/R28/R29=200Ω V+ =12V, R16/R17/R28/R29=1KΩ V+ =24V, R16/R17/R28/R29=2KΩ V+encoder power, through JP3 to select</p>
Aout,Bout	<p>PG signal output</p> <p>Voltage output, voltage level determined by the encoder power supply</p>
V+	<p>Encoder power, through JP3 to select:</p> <p>JP3 <input type="checkbox"/> +5V <input type="checkbox"/> Internal+5V <input type="checkbox"/> V+ <input type="checkbox"/> power supply <input type="checkbox"/> +12V</p>

	JP3 ○+5V ○V+ Internal+12V ○+12V power supply JP3 ○+5V External+5V ~ 24V ○V+ power supply ○+12V
PGND	encoder

Encoder PG pulses range 300~9999

Maximum pulses frequency receiver 1MHz, when PG pulses=2500, maximum speed=400Hz

III-3. terminal connection:



Appendix IV Converter Water Supply Controller Instruction

number	E00 function	Parameter setting	definition	Reference page
1	Special power supply	8	Inverter power	147
		13	Stable voltage power	147
		14	Constant current power	-
2	Constant pressure water supply	9	Pump constant pressure water supply	148
3	Extruding machine	15	Extruding machine	-

IV-1. Extend functions supplement

IV-1-1. E00=8: variable frequency power

P03 PID given signal selection, you can set through the keyboard, analog AI1, pulse and other means to set a given voltage.

Given voltage is calculated as follows:

Given voltage:220VAC

Given voltage setting = $220 \times 1.414 / 500 \times 100\% = 62.2\%$

Frequency Power specific parameters:

No.	name	scope	unit	meanings	Factory setting
E16	User parameter 1	0~9999	-	Voltage increasing time	0
E17	User parameter 2	0~9999	-	Voltage decreasing time	0
<p>In regulated power supply mode, the output and input voltage are both adjustable. The increasing time and decreasing time of output voltage is adjusted by F09 and F10. E16 is the voltage increasing time, the definition of the output voltage increasing time is from 9999 corresponds to 999.9 seconds. E17 is the voltage decreasing time, the definition of the output voltage decreasing time is from 9999 corresponds to 999.9 seconds. Voltage increasing/decreasing time just used to adjust the accelerate/decelerate time of output frequency when the inverter running. After the stopping command issued, the controller will stop the frequency output when the output frequency decelerate to 0hz.</p>					
E18	User parameter 3	0~9999	-	The max output voltage	0
<p>For safety and reliability to ensure that the output voltage to bear the load within the system, we need to define the maximum output voltage of the system. If the system highest withstand voltage 250VAC, then a maximum outout voltage= 250; E18=250。</p>					

IV-1-2. E00=13: Voltage regulation power

In this mode,connect AI2,AI3 to Hall,then measure the output voltage and use2Halls to do redundant work to ensure the output voltage will not exceed the Hall voltage limitation.

In this mode, the following parameters should be adjusted:

PID function group, P02 PID feedback signal selection.

AI2 is detected by analog and AI3 works as a redundant configuration to ensure the output voltage safe and reliable.

When Feedback voltage is 100%, the corresponding Hall voltage is 500VAC, Hall output voltage is 5V.

Set o03=50%, o05=50%.

P03 PID given signal selection, you can set through the keyboard, analog AI1, pulse and other means to set a given voltage.

Given voltage is calculates as follows:

When the given voltage =220VAC, given voltage setting = $220 \times 1.414 / 500 \times 100\% = 62.2\%$

Other PID parameters are adjusted according to the site.

Under PID regulated power supply mode, the voltage acceleration and deceleration time is controlled by PID parameters, it won't affect by voltage acceleration and deceleration time.

Voltage regulation power specific parameters:

No.	name	Range	unit	Description	Factory setting
E16	User parameter 1	0~9999	-	Voltage increasing time	0
E17	User parameter 2	0~9999	-	Voltage decreasing time	0
<p>In Voltage regulation power mode, the output and input voltage are both adjustable. The increasing time and decreasing time of output voltage is adjusted by F09 and F10. E16 is the voltage increasing time, the definition of the output voltage increasing time is from 9999 corresponds to 999.9 seconds. E17 is the voltage decreasing time, the definition of the output voltage decreasing time is from 9999 corresponds to 999.9 seconds. Voltage increasing/decreasing time just used to adjust the accelerate/decelerate time of output frequency when the inverter running. After the stopping command sent, the controller will stop the frequency output when the output frequency decelerate to 0 hz.</p>					
E18	User parameter 3	0~9999	-	Max output voltage	0
<p>For safety and reliability to ensure that the output voltage to bear the load within system,we need to define the maximum output voltage of the system. If the System highest withstand voltage 250VAC; Then E18=250VAC.</p>					

IV-1-3. Converter water supply controller instruction

IV-2-1. Constant water supply system parameters:

(1) loading types with constant water supply function:

Parameter	Keyboard display	setting	Meaning
E00	Load type	9	E12 set to be single pump, no need the constant pressure water supply interface board
			E12 set to multi-pump, need constant pressure water supply interface board,while realize 4-pumps constant pressure water supply function.

(2) PID adjusting in constant water supply system

Parameter	Keyboard Display	Setting	Meanings
F01	Keyboard set frequency	0	Keyboard set the frequency 0hz

F02	Frequency main set mode	0	Keyboard set frequency or RS485 set frequency.
F03	Frequency auxiliary set mode	7	PID adjusting mode
F04	main and auxiliary frequencies set	2	main+ auxiliary set mode
P00	PID configure	0000	single-way,the negative regulator, failure is not action
P02	Feedback signal select	1~3	External analog feedback signal given by the AI1 / AI2 / AI3
P03	Given signal select	0~6	Given signal can select the keyboard/Rs485,potentiometers, digital voltage, digital pulse, etc.
P05	PID integration time	★	Setting according the site.
P06	PID differential time	★	Setting according the site.
P07	PID proportional gain	★	Setting according the site.
P09	Deviation Limit	★	Setting according the site.
P12	PID Display Range	★	Setting according the site.

(3) Constant pressure water supply special parameters

Parameter	Keyboard Display	Setting	Meanings
E01	Starting pressure deviation	10%	Starting pressure deviation is 10%
E02	Starting time delay	2.0	Starting delay time is second.
E03	Stop frequency	15.00	stop at frequency 15HZ.
E04	stop time delay	2.0	Stop time is 2 second.
E05	High pressure arrival value	80%	feedback pressure reach and exceed the value of this parameter, the I / O output terminal select 25, then it will output arrival signal.
E06	Low pressure arrival	60%	when feedback pressure less than the low pressure reached value of this parameter, the I / O output terminal select 26, then it will output arrival signal.
E07	Timing to water supply	0000	Timing to water supply function invalid

(4) Multi-function constant pressure water supply pump specific parameters

Parameter	Keyboard Display	Setting	Meaning
E08	Timing shift alternation time	0.25	According to first start first stop principles to control pump rotation,rotation time of 0.25 hours
E09	electromagnetic switching action delay	0.500	When set up a station pump (drive motor) to switch from variable frequency industry frequency, or from industry frequency to variable frequency, and set its electromagnetic switching action delay time is 0.5 seconds.
E10	Pumps shift judging time	100	To set the determine time 100 seconds from inverter output frequency reaches the upper limit frequencies until increase pump (drive motor); or from inverter output frequency reaches the lower limit frequencies until decrease pump (drive motor).

E11	Constant Pressure Water Supply Configuration	0000	Decelerating stop: When the inverter failure, the rotation switching way is from variable frequency pump to industry frequency and the pump maintain the status.
E12	Multi-pump configuration	1111	N. 1 ~ 4 pumps are frequency controlled pump
E13	Multi-pumps status	★	Multi-pump control mode, displays the status of each pump
E14	Soft-start Pump Control	0000	Multi-pump control mode, set the control mode of each pump, currently set to Full Stop

(5) constant pressure water supply IO parameter:

Parameter	Keyboard Display	Setting	Meanings
o21~o24	Output signal select	25	High pressure arrival
o21~o24	Output signal select	26	Low pressure arrival
o36~o46	Input terminal function select	51	Pump 1 soft start
o36~o46	Input terminal function select	52	Pump 1 stop
o36~o46	Input terminal function select	53	Pump 2 soft starter
o36~o46	Input terminal function select	54	Pump 2 stop
o36~o46	Input terminal function select	55	Pump 3 soft starter
o36~o46	Input terminal function select	56	Pump 3 stop
o36~o46	Input terminal function select	57	Pump 4 soft state
o36~o46	Input terminal function select	58	Pump 4 stop
o36~o46	Input terminal function select	59	Manual shift command
o36~o46	Input terminal function select	60	Timing of water supply time-zero

IV-2-2. Application


It is special appendix for multiple pumps, which run with PI7000 family inverter to control the multiple pumps water supply system effectively.

IV-2-3. Operation and connection notice:


- ◇ If it is power frequency motor, probable thermal relay must be used to protect motor.
- ◇ AC contactor with machinery chain equipment should be used between the power frequency bypass and inverter output of aside the motor, lock logically on the electric control circuit to avoid the short circuit of the power frequency and inverter output which damage the inverter and equipments.
- ◇ The phase order of the power frequency to the motor should be the same with the phase order of the inverter output to avoid the motor reverse. Please confirm the phase order and operate.
- ◇ When wiring the control signal of the inverter, please leave it away with the driving line, and do not make them in the same wire, otherwise it will lead wrong action.
- ◇ Screen cable is used for Pressure set signal and pressure feedback signal.

IV-2-4. Dimension

- (1) Dimension of water supply control card



(2) Dimension of water supply controller




Size of fixing plate


Note: The fixing plate can be fixed by any mounting hole in the figure.

IV-2-5. IV-2-5. Frequency of water supply connection to the drive controller

Connection of water supply controller with inverter, the communication cable and power cable are connected as below:



IV-2-6. System diagram



Remarks: ZK air switch KM contactor
JR thermo-relay M motor

IV-2-7. Water supply control mode

When several pumps supply water meanwhile, because of the different time(daytime and night), different season(winter and summer), the variation of the water flow is great. To save energy and protect the equipment, please run pumps as many as you need and stop pumps as many as you do not need.

Inverter will confirm the number of the running pumps according to the requirement of the pressure close loop control. In the set range, only one pump is controlled by the inverter at the same time.

If the timing shift interval time is set 0.05~100.00, when the related running time is stable, inverter inverter will shift up the pumps according to stop first or open first to ensure each pump has the chance to run and avoid the pump rusted because of long time N use.

After the pumps run to the upper and lower, arrive the adding pumps or reducing pumps time, inverter will add or reduce the pumps according to stop first or open first to ensure each pump can run and avoid the pump rusted because of long time N use.

IV-2-8. Soft-start pump control mode

Set the soft start pump by E12 and through the input terminals o36 ~ o46, respectively controlled soft-start pump start and stop.


Soft-start pump terminal control, stop first.

Soft-start pump is not controlled by constant pressure water supply system.Soft-start pump can be used as sewage pumps and fire pumps.

IV-2-9. Application Guide

3 Pumps constant pressure water supply + sewage pump

- (1) pump configurations: variable frequency pump 3 units, 15kW,1 unit sewage pump,15kW.
- (2) The set pressure 0.8Mpa.
- (3) pressure gauge options: pressure transmitter, DC 4 ~ 20mA output, 1.6Mpa.
- (4) Inverter choice: VFR-080 015F3 and WSC_RS485 water supply board.
- (5) Hardware Connection.
- (6) Parameter setting



□ loading types with a constant pressure water supply function:

Parameter	Keyboard Display	Setting	Meanings
E00	Loading type	9	Multi-pump constant pressure water supply, need constant pressure water supply interface board, while realize 4 pump constant pressure water supply pump function.

□ PID adjust in constant pressure water supply

Parameter	Keyboard Display	Setting	Meanings
F01	Keyboard set frequency	0	Keyboard set the frequency 0hz
F02	Frequency main set mode	0	Keyboard set frequency or RS485 set frequency.
F03	Frequency secondary set mode	7	PID adjusting mode
F04	relationship between main and auxiliary frequencies given	2	main+ auxiliary set mode
F05	Running control mode	3	Terminal control
A29	baud rate	3	baud rate 9600
P00	PID configure	0000	single-way, the negative regulator, failure is not action
P02	Feedback signal select	3	External analog feedback signal given by the AI3
P03	Give signal select	2	External analog given by AI2
P05	PID integration time	0.250	Setting according the site.
P06	PID differential time	0	Setting according the site.
P07	PID proportional gain	100.0	Setting according the site.
P09	Deviation Limit	5.0	Setting according the site.
P12	PID Display Range	1.6	adjust according actual requirement, display the actual pressure value is 160.0, it means 1.6Mpa.

□ Constant pressure water supply specific parameters

Parameter	Keyboard Display	Setting	Meanings
E01	Starting pressure deviation	10%	Starting pressure deviation is 10%
E02	Starting time delay	2.0	Starting delay time is second.
E03	shutdown frequency	15.00	shutdown at frequency 15HZ.
E04	Shutdown time delay	2.0	shutdown time is 2 second.
E05	High pressure arrival	80%	when feedback pressure reach and exceed the high pressure reached value of this parameter, the I / O output terminal select 25, then it will output arrival signal.
E06	Low pressure arrival	60%	when feedback pressure less than the low pressure reached value of this parameter, the I / O output terminal select 26, then it will output arrival signal.

E07	Regular time water supply	0000	Regular time water supply function invalid
-----	---------------------------	------	--

□ Multi-function constant pressure water supply pump specific parameters

Parameter	Keyboard Display	Setting	Meaning
E08	E08 regular rotation interval	0.25	According first start first stop principles to control pump rotation, rotation time of 0.25 hours
E09	Electromagnetic switching action delay	0.500	When set up a station pump (drive motor) to switch from variable frequency industry frequency, or from industry frequency to variable frequency, and set its electromagnetic switching action delay time is 0.5 seconds.
E10	Pump switch to judge the time	100	To set the determine time 100 seconds from inverter output frequency reaches the upper limit frequencies until increase pump (drive motor); or from inverter output frequency reaches the lower limit frequencies until decrease pump (drive motor).
E11	Constant Pressure Water Supply Configuration	0	Shutdown: When the inverter failure, the rotation switching way is from variable frequency pump to industry frequency and the pump maintain the status.
E12	Multi-pump configuration	2111	N. 1 ~ 3 pumps are frequency controlled pump, pump 4 is soft-starter controlled pump.
E13	Multi-pump status	1112	Multi-pump control mode, displays the status of each pump
E14	Soft-start Pump Control	★	Multi-pump control mode, set the control mode of each pump, i currently set to Full Stop

□ constant pressure water supply IO parameters:

Parameter	Value read On Keyboard Display	Setting Value	Meanings
o21	o1 input signal select 1	25	High pressure arrival
o22	o2 input signal select 2	26	Low pressure arrival
o23	o3 input signal select 3	1	Fault input alarm
o36	(DI1) input terminal function selection	1	FWD
o37	(DI2) input terminal function selection	39	Free parking
o38	(DI3) input terminal function selection	59	Manual rotation command
o39	(DI4) input terminal function selection	60	Timing of water supply time-zero
o40	(DI5) input terminal function selection	55	Pump 3 soft starting
o41	(DI6) input terminal function selection	56	Pump 3 stopping