



Compatible motor type instruction

1. Parameter Pn218 is used to set 'Compatible motor type'. If this parameter is set wrong, A.42 alarm will occur when re-power on.
2. Estun new driver can drive different motor with relevant power by changing Compatible motor type parameter Pn218. For instance, driver EDB-10A□A can drive EMJ-10APA□□ or EMG-10APA□□ by changing parameter Pn218.

Parameter definition as follows:

Servo driver types	Servo motor types	Compatible motor type parameter Pn218
EDB-08A□A	EMJ-08APA□□	0
EDB-10A□A	EMJ-10APA□□	0
EDB-10A□A	EMG-10APA□□	1
EDB-15A□A	EMG-15APA□□	1
EDB-20A□A	EMG-20APA□□	1
EDB-30A□A	EMG-30APA□□	1
EDB-50A□A	EMG-50APA□□	1
EDB-10A□A	EML-10APA□□	2
EDB-20A□A	EML-20APA□□	2
EDB-30A□A	EML-30APA□□	2
EDB-50A□A	EML-40APA□□	2
EDC-02APE	EMJ-02APA□□	0
EDC-04APE	EMJ-04APA□□	0
EDC-08APE	EMJ-08APA□□	0