

Devices for telpher control



**Devices for telpher control MBP type**

They represent different combinations of START and STOP buttons mounted in plastic boxes in different sizes. They are connected to the operating circuits of cranes or telfhers and serve as a remote control of their movement. They are connected directly to the operating cable of the telpher and send commands directly to the executive mechanisms. They are designed to provide protection from dust and moisture IP65.

- Consumed power: <5VA
- Electrical wear resistance: 1x10<sup>5</sup> cycles
- Operating temperature: -10 +40°C
- Humidity: 35 – 85% RH
- Number of contacts: according to the number of the buttons
- Commuting capacity: up to 6A
- Plastic: UV rays wear resistance
- IP code: IP65
- Weight: according to the number of the contacts

**Technical data:**

- Supplying voltage: 230V; 50/60Hz

**Mounting:**

- directly to the control cable of the telpher (crane)

**MBP-Axxxx** — stop button type  
 — button type – one-speed (x81) or two-speed (x91)  
 — number of buttons



Type	Number of buttons	Contact block and scheme Emergency	For the directions	Packing / Box (pcs)	Catalogue number
MBP-A281	2	-	NO+NC	1 / 20	<b>46281</b>
MBP-A291 two speed	2	-	NO+NC	1 / 20	<b>46291</b>
MBP-A2813	2+1	emergency button	NO+NC	1 / 20	<b>46283</b>
MBP-A2813K	2+1	emergency button with switch	NO+NC	1 / 20	<b>46283K</b>
MBP-A2913 two speed	2+1	emergency button	NO+NC	1 / 20	<b>46294</b>
MBP-A2913K two speed	2+1	emergency button with switch	NO+NC	1/20	<b>46294K</b>
MBP-A481	4	-	NO+NC	1 / 20	<b>46481</b>
MBP-A491 two speed	4	-	NO+NC	1 / 20	<b>46491</b>
MBP-A4813	4+1	emergency button	NO+NC	1 / 20	<b>46483</b>
MBP-A4813K	4+1	emergency button with switch	NO+NC	1 / 20	<b>46483K</b>
MBP-A4913 two speed	4+1	emergency button	NO+NC	1 / 20	<b>46493</b>
MBP-A4913K two speed	4+1	emergency button with switch	NO+NC	1/20	<b>46493K</b>
MBP-A681	6	-	NO+NC	1 / 20	<b>46681</b>
MBP-A691 two speed	6	-	NO+NC	1 / 20	<b>46691</b>
MBP-A6813	6+1	emergency button	NO+NC	1 / 20	<b>46683</b>
MBP-A6813K	6+1	emergency button with switch	NO+NC	1 / 20	<b>46683K</b>
MBP-A6913 two speed	6+1	emergency button	NO+NC	1 / 20	<b>46693</b>
MBP-A6913K two speed	6+1	emergency button with switch	NO+NC	1/20	<b>46693K</b>
MBP-A881	8	-	NO+NC	1 / 20	<b>46881</b>
MBP-A891 two speed	8	-	NO+NC	1 / 20	<b>46891</b>
MBP-A8813	8+1	emergency button	NO+NC	1 / 20	<b>46883</b>
MBP-A8813K	8+1	emergency button with switch	NO+NC	1 / 20	<b>46883K</b>
MBP-A8913 two speed	8+1	emergency button	NO+NC	1 / 20	<b>46893</b>
MBP-8913K two speed	8+1	emergency button with switch	NO+NC	1/20	<b>46893K</b>