$oldsymbol{i}^3$ BX Intelligent Control Station

- 240 x 128 Monochrome LCD Display
- High Resolution Resistive Touch Screen
- MicroSD[™] Data storage
- Real Time Clock
- 1 CAN Port, 2 RS-232 / RS-485
- 1 Integral Ethernet Port
- Addressable function keys
- 256kB RAM (Program), 16MB (Graphical)
- IP65 (NEMA4X)
- 10 30 VDC Power Supply
- Free Configuration Software
- Remote I/O Communication
- Optional Modem (SMS, GSM, GPRS)
- Supports i³RMI Webserver Functionality




Options & Ordering Codes

Standard Options	DI	D0	Al	AO
i3BX12Y/10D03-SEHF	12	6 Relay	4	-
i3BX12Y/13C14-SEHF	12	12	2*	2
i3BX12Y/20B05-SEHF	24	16	2	-
i3BX12Y/10E24-SEHF	12	12	6*	4

^{*} Universal Analogue Inputs





$oldsymbol{\dot{i}}^{\scriptscriptstyle 3}$ BX Intelligent Control Station



Technical Specifications

General Specifications			
Required Power (Steady State)	84mA @ 24VDC		
Required Power (Inrush)	30A for 1ms @ 24VDC		
Primary Voltage Range	10-30VDC		
Relative Humidity	5 to 95% Non-Condensing		
Clock Accuracy	+/-90 Seconds per month at 20°C		
Operating Air Temperature	-10°C to +60°C		
Storage Temperature	-20°C to +70°C		
Weight	0.340kg		
Approvals	cUL, UL, CE, FCC		

Control & Logic Specifications				
Control Language Support	Advanced Ladder Logic Full IEC 61131-3			
Logic Program Size & Logic Scan Rate	256kB Maximum 0.8ms/k			
	Digital Inputs - 2048			
1/0.0	Digital Outputs - 2048			
I/O Support	Analogue Inputs - 512			
	Analogue Outputs - 512			
General Purpose Registers	9,999 (words) Retentive 2,048 (bits) Retentive 2,048 (bits) Non-retentive			

Display Specifications		
Display Type	Transreflective Touchscreen LCD (outdoor readable)	
Resolution	160 x 128	
Colour	Monochrome	
Screen Memory	16MB	
User-Programmable Screens	1023 (maximum 50 objects per screen)	
Backlight	LED - 30,000 hour life	
Touchscreen Life & Type	1 million touch+; Resistive Type	
Screen Update Rate	User configurable within the scan time (perceived as instantaneous in many cases)	


Connectivity	
Serial Ports	1 RS-232 or 1 RS-485 on first modular jack (MJ1) 1 RS-232 or 1 RS-485 on second modular jack (MJ2)
USB mini-B	USB 2.0 (480MHz) Programming & Data Access
CAN	Remote I/O, Peer-to-Peer Comms, i3 Configurator
Ethernet	10/100MB (Auto-MDX), Modbus TCP, HTTP, FTP, SMTP, i3 Configurator, Ethernet IP, ASCII TCP
Remote I/O	IOS, Smart I/O, iSmart
Removable Memory	MicroSD™ (support for 32GB max) Application updates, Datalogging, more
Audio	Beeper (system/software controlled)

4
1
500kHz each
32-bits each
es Supported
Quadrature
ent

There are 4 high-speed inputs of the total DC inputs. There are 2 high-speed outputs of the total DC outputs. Model 10D03, 10B04, 20B05 feature 12-bit Analogue I/O. Model 13C14 features 14/16-bit Analogue I/O. High-speed outputs can be used for PWM and Pulse Train Outputs, currently limited to <10kHz and <65kHz for the 10E24 model. Model 10E14 features a 14/17 bit Analogue I/O.

2 Position Controlled Outputs 1 ON/OFF Setpoint per Output

Dimensions & Panel Cutout




3.622" (92.0mm) 3.622" (92.0mm)

CUTOUT TOLERANCE TO MEET NEMA STANDARDS IS ±0.005" (0.1mm) Max. Panel Thickness is 5mm

$oldsymbol{\dot{i}}^{\scriptscriptstyle{3}}$ BX Intelligent Control Station

IMO

Ports & Connectors



DC Input / Frame

Torque rating: 4.5-7 Lb-in (0.50-0.78Nm)

DC- is internally connected to I/O V-, but is isolated from CAN V-

A Class 2 power supply must be used

Primary Power Port Pins			
Pin Signal Signal Description			
1	Ground	Frame Ground	
2	DC-	Input Power Supply Ground	
3	DC+	Input Power Supply Voltage	



MJ1 Independent Serial Ports

Two multiplexed serial ports on one modular jack (8posn)

PIN	MJ1 P	INS
	Signal	Direction
8	TXD RS-232	OUT
7	RXD RS-232	IN
6	0 V	Ground
5	+5V@60mA	OUT
4	RTS RS-232	OUT
3	CTS RS-232	IN
2	RX- / TX- RS-485	IN / OUT
1	RX+ / TX+ RS-485	IN / OUT


ON 1 2 3 ON 1 3 ON 1

DIP Switches

Switch	Name	Function	Default
1	RS-485 Termination (MJ1)	ON = Terminated	OFF
2	RS-485 Termination (MJ2)	ON = Terminated	OFF
3	Factory Use	Always Off	OFF

Fixed	Digital/Analog			i3BX Model		
Address	I/O Function	10D03	10B04	20B05	13C14	10E24
	Digital Inputs	1-12	1-12	1-24	1-12	1-12
%I1	Reserved	13-32	13-31	25-31	13-31	13-31
	ESCP Alarm	n/a	32	32	32	32
%Q1	Digital Outputs	1-6	1-12	1-16	1-12	1-12
%U1	Reserved	7-24	13-24	17-24	13-24	13-24
%AI1	Analogue Inputs	1-4	1-2	1-2	1-2	1-4;33-38
70AII	Reserved	5-12	3-12	3-12	3-12	n/a
%AQ1	Reserved	n/a	1-8	1-8	1-8	1-8
/oAU I	Analogue Outputs	n/a	n/a	n/a	9-10	9-12

Reserved areas maintain backward compatability with other i3 Controller models



CAN

Mounting screw torque rating: 4.5 Lb-in (0.50Nm)

SHLD and V+ pins are not internally connected to i³B

Primary Power Port Pins				
Pin	Signal	Description	Direction	
1	V-	CAN Ground - Black	-	
2	CN L	CAN Data Low - Blue	IN / OUT	
3	SHLD	Shield Ground - None	-	
4	CN H	CAN Data High - White	IN / OUT	
5	V+ (NC)	No Connect - Red	-	



MJ2 Serial Port

Two multiplexed serial ports on one modular jack (8posn)

PIN	MJ2 PINS		
	Signal	Direction	
8	TXD RS-232	OUT	
7	RXD RS-232	IN	
6	0 V	Ground	
5	+5V@60mA	OUT	
4	TX- RS-485	OUT	
3	TX+ RS-485	OUT	
2	RX- (RX- / TX-*) RS-485	IN or IN/OUT	
1	RX+ (RX+ / TX+*) RS-485	IN or IN/OUT	

^{*} In half duplex mode

Built-in I/O

I/O is mapped into i3 Register space, in three separate areas — Digital/Analogue I/O, High-Speed Counter I/O, and High-Speed Output I/O. Digital/Analogue I/O location is fixed starting at 1, but the High-Speed Counter and High-Speed Output references may be mapped to any open register location. For more details on using the High-Speed Counter and High-Speed Outputs, see the i3BX User's Manual.

Default Address*	High Speed Counter Function	i3BX Models
%I1601	Status Bits	1-8
%Q1601	Command Bits	1-32
%AI0401	Accumulator 1&2	1-8
%AQ0401	Preload & Match Values	1-12

^{*}Starting Address locations for %I, %Q, %AI & %AQ may be re-mapped by user

Default Address*	High Speed Output Function	i3BX Models
%I1617	Status Bits	1-8
%Q**	Command Bits	1-32
n/a	n/a	n/a
%AQ0421	PWM or Pulse Train Parameters	1-20

*Starting Address locations for %I & %AQ may be re-mapped by user

**Q1-Q2 are part of the Fixed I/O Map. In High Speed Output mode they can be used to initiate a Stepper/PTO Move

$oldsymbol{\dot{i}}^3$ BX Intelligent Control Station




13C14 I/O Board Specifications

Digi	tal DC Inputs	Digital DC Outputs		
Inputs per Module	12 including 4 configurable HSC inputs	Outputs per Module	12 including 2 configurable PWM outputs	
Commons per Module	1	Commons per Module	6	
Input Voltage Range	10-30 VDC	Output Type	Sourcing / 10 K Pull-Down	
Absolute Max. Voltage	35 VDC Max	Absolute Max. Voltage	28 VDC Max	
Input Impedance	10 kΩ	Output Protection	Short Circuit	
Input Current	Positive Logic Negative Logic	Max. Output Current per Point	0.5A	
Upper Threshold	0.8mA -1.6mA	Max. Total Current	4 A Continuous	
Lower Threshold	0.3mA -2.1mA	Max. Output Supply Voltage	30 VDC	
Max. Upper Threshold	8 VDC	Min. Output Supply Voltage	10 VDC	
Max. Lower Threshold	3 VDC	Max. Voltage Drop at Rated Current	0.25V	
OFF to ON Response	1 ms	Max. Inrush Current	650 mA per channel	
ON to OFF Response	1 ms	Min. Load	None	
		OFF to ON Response	1 ms	
HSC Max. Switching Rate	500kHz	ON to OFF Response	1 ms	
		Output Characteristics	Current Sourcing (Positive Logic)	
	Analogue Inputs,	High Resolution		
Number of Channels	2	Thermocouple	Temperature Range	
Input Ranges (Selectable)	0 - 10 VDC, 0 – 20 mA, 4 – 20 mA, 100mV PT100 RTD, and J, K, N, T, E, R, S, B Thermocouple	B/R/S E T J K/N	2912°F to 32.0°F (1600°C to 0°C) 1652°F to -328°F (900°C to -200°C) 752.0°F to -400°F (400°C to -240°C) 1382.0°F to -346.0°F (750°C to -210°C) 2498.0°F to -400°F (1370°C to -240°C)	
Nominal Resolution	10V, 20mA, 100mV: 14 Bits RTD, Thermocouple: 16 Bits	Thermocouple Common Mode Range	±10V	
Converter Type	Delta Sigma	Max. Thermocouple Error	±0.2% (±0.3% below -100°C)	
Input Impedance (Clamped @ -0.5 VDC to 12 VDC)	Current Mode: 100 Ω , 35mA Max. Continuous Voltage Mode: 500 k Ω , 35mA Max. Continuous	Max. Error at 25°C (*excluding zero)	4-20 mA ±0.10% *0-20 mA ±0.10% *0-10 VDC ±0.10% RTD (PT100) ±1.0°C 0-100 mV ±0.05%	
Al Full Scale	10 V, 20 mA, 100 mV: 32,000 counts full scale. RTD / T/C: 20 counts / °C	Conversion Speed, Both Channels Converted	10V, 20mA, 100mV: 30 Times/Second RTD, Thermocouple: 7.5 Times/Second	
Max. Over-Current	35mA	Conversion Time per Channel	10V, 20mA, 100mV: 16.7mS RTD, Thermocouple: 66.7mS	
Open Thermocouple Detect Current			250μ A	
	,	Outputs		
Number of Channels	4	Minimum Current Load	500Ω	
Output Ranges	0-10VDC, 0-20mA, 4-20mA	Galvanic Isolation	None	
Nomimnal Resolution	12 Bits	Conversion Speed	Min. all channels once per scan	
Response Time	One update per ladder scan			
Max. Error at 25°C (excluding zero)	0-20mA 0.1% of FS 0-10V 0.1% of FS	Additional Error for temperatures other than 25°C	20mA 0.0126%/°C	

i^3 BX Intelligent Control Station



J1 (Orange)	Name		
11	IN1		
12	IN2		
13	IN3		
14	IN4		
15	IN5		
16	IN6		
17 IN7			
18	18 IN8		
H1	HSC1 / IN9		
H2	HSC2 / IN10		
Н3	HSC3 / IN11		
H4	HSC4 / IN12		
NC	No Connect		
NC	No Connect		
OV	Common		





J2 (Black)	Name		
OV	Common		
V+	Output Power		
NC	No Connect		
Q12	OUT12		
Q11	0UT11		
Q10	0UT10		
Q9	OUT9		
Q8	OUT8		
Q7	OUT7		
Q6	OUT6		
Q5	OUT5		
Q4	OUT4		
Q3	OUT3		
Q2	OUT2 / PWM2		
Q1	OUT1 / PWM1		


Digital Outputs				
	0V			
-O ⁺	V+			
10 - 30VDC	NC			
- LOAD +	Q12			
- LOAD +	Q11			
- LOAD +	Q10			
- LOAD +	Q9			
- LOAD +	Q8			
- LOAD +	Q7			
- LOAD +	Q6			
- LOAD +	Q5			
- LOAD +	Q4			
- LOAD +	Q3			
- LOAD +	Q2			
LOAD +	Q1 <			

J2 (Black) Positive Logic


J3 (Orange)	Name		
T1+	TC (1+) or RTD (1+) or 100mV (1+)		
T1-	TC (1-) or RTD (1-) or 100mV (1-)		
T2+	TC (2+) or RTD (2+) or 100mV (2+)		
Т2-	TC (2-) or RTD (2-) or 100mV (2-)		
AQ1	10V or 20mA Out (1)		
AQ2	10V or 20mA Out (2)		
OV	Common		
MA1	0-20mA In (1)		
V1	0-10V In (1)		
OV	Common		
MA2	0-20mA In (2)		
V2	0-10V In (2)		
OV	Common		









Jumper Setting Details








$oldsymbol{i}^3$ BX Intelligent Control Station



Example of Universal Input Wiring Schematic



Configuration

The data registers as follows:-

Digital Inputs	Digital Outputs	Analogue Inputs	Analogue Outputs		
%I1-12	%Q1-12	%AI1-4, %AI33-38	%AQ9-12		

Note: The first four Analogue inputs are mapped to both %Al1-4 and %Al33-36, analogue input channels 5 & 6 are mapped to %Al37 and %Al38 respectively only.

Data Values

The analogue inputs return data types as follows:-

Input Mode	Data Format	Comment
0-20mA, 4-20mA	0-32000	
0-10V, 0-60mV	0-32000	
TC, RTD	Temperature in °C or °F to 1 decimal place xxx.y	°C or °F may be selected in the I/O config section. The value is an integer, the user should divide by 10.

Status Register

Register	Descriptions								
%R1	Bit-wise status register enable – R1.1 – R1.9 enable for registers R2 to R9								
%R2	Firmware version								
%R3	Watchdog count – cleared on power-up.								
%R4	Status bits -				164	3	2	1	
% ∩ 4				Reserved	Normal	Config	Calibration		
%R5	Scan rate of the 10E24 board (average) in units of 100μ S.								
%R6	Scan rate of the 10E24 board (max) in units of 100μ S.								
%R7	Channel Status Channel 2			Channel 1	Channel 1				
	8	7	6	5	4	3	2	1	
	Open RTD	Out of Limits	Shorted RTD	Open TC	Open RTD	Out of Limits	Shorted RTD	Open TC	
%R8	Channel Status	el Status Channel 4			Channel 3	•			
	8	7	6	5	4	3	2	1	
	Open RTD	Out of Limits	Shorted RTD	Open TC	Open RTD	Out of Limits	Shorted RTD	Open TC	
%R9	Channel Status Channel 6			Channel 5					
	8	7	6	5	4	3	2	1	
	Open RTD	Out of Limits	Shorted RTD	Open TC	Open RTD	Out of Limits	Shorted RTD	Open TC	
%R10-14	Reserved								

Note: For the purposes of the example, the block is shown starting at %R1, but it can be set to anywhere in the %R memory map.

$oldsymbol{\dot{l}}^{\scriptscriptstyle{3}}$ BX Intelligent Control Station



Safety

WARNING: Battery may explode if mistreated. Do not recharge, disassemble or dispose of in fire.

WARNING: EXPLOSION HAZARD - BATTERIES MUST ONLY BE CHANGED IN AN AREA KNOWN TO BE NON-HAZARDOUS

This equipment is suitable for use in Class 1, Division 2, Groups A, B, C and D or Non-hazardous locations only.

FOR U.S. & CANADA ONLY

Power input and output (I/O) wiring must be in accordance with Class 1, Division 2 wiring methods of the National Electric Code, NFPA70 for installations in the U.S. or as specified in Section 18-1J2 of the Canadian Electric Code for installations within Canada and in accordance with the authority having jurisdiction.

WARNING: EXPLOSION HAZARD - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

WARNING: EXPLOSION HAZARD - Substitution of components may impair suitability for Class 1, Division 2.

Digital outputs shall be supplied from the same source as the i3 Controller.

WARNING: Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.

WARNING: To avoid the risk of electric shock or burns, always connects the earth ground before making any other connections.

WARNING: To reduce the risk of fire, electrical shock, or physical injury it is strongly recommended to fuse all Power Sources connected to the i3 controller. Be sure to locate fuses as close to the source as possible.

WARNING: Replace fuse with the same type and rating to provide protection against risk of fire and shock hazards.

WARNING: In the event of repeated failure, do not replace the fuse again as a repeated failure indicates a defective condition that will not clear by replacing the fuse.

Jumpers on connector JP1 and others shall not be removed or replaced while the circuit is live unless the area is known to be free of ignitable concentrations of flammable gases or vapours.

Common Cause of Analogue Input Tranzorb Failure

If a 4-20mA circuit is initially wired with loop power, but without a load, the analogue Input could see 24VDC. This is higher than the rating of the tranzorb. This can be solved by NOT connecting loop power prior to load connection, or by installing a low-cost PTC in series between the load and analogue input.

