$oldsymbol{i}^3$ CX Intelligent Control Station

IMO

- 640 x 480 colour touch display
- High resolution resistive touch screen
- Addressable function keys
- Real time clock
- Built-in Ethernet
- 3 x communications ports (RS 232 / RS 485)
- 1 x USB A, 1 x USB mini B
- 10 30 VDC power supply
- 1MB RAM (program), 27MB (Graphical)
- Free configuration software
- IP65 (NEMA4)
- Remote I/O communication
- Optional: MicroSD (up to 32GB)
 Modem (SMS, GSM, GPRS)
 USB drive up to 2TB






Options & Ordering Codes

Standard Options	DI	D0	Al	AO
i3CX12Z/10D03-SEHF	12	6 Relay	4	-
i3CX12Z/13C14-SEHF	12	12	2*	2
i3CX12C/20B05-SEHF	24	16	4	-
i3CX12Z/10B04-SEHF	12	12	2	-
i3CX12Z/10E24-SEHF	12	12	6*	4
i3CX12Z/00000-SEHF	-	-	-	-

^{*} Universal Analog Inputs



$oldsymbol{\dot{i}}^3$ CX Intelligent Control Station



Technical Specifications

General Specifications	
Required Power (Steady State)	420mA @ 12VDC / 230mA @ 24VDC
Required Power (Inrush)	25A for <1ms @ 24VDC DC Switched
Primary Power Range	10-30VDC
Relative Humidity	5 to 95% Non-Condensing
Clock Accuracy	+/-20ppm Maximum at 25°C (+/-1 Minute per month)
Operating Air Temperature	-10°C to +60°C
Storage Temperature	-40°C to +60°C
Weight	1.98kg / 4.375 lbs (without I/O)
Approvals	UL, CE


Control & Logic Specifications				
Control Language Support	Advanced Ladder Logic Full IEC 61131-3			
Logic Program Size & Logic Scan Rate	1MB Maximum 0.013ms/k			
Online Programming Changes	Supported in Advanced Ladder			
	Digital Inputs - 2048			
I/O Cupport	Digital Outputs - 2048			
I/O Support	Analog Inputs - 512			
	Analog Outputs - 512			
General Purpose Registers	50,000 (words) Retentive 16,384 (bits) Retentive 16,384 (bits) Non-retentive			

Display Specifications	
Display Type	5.7" VGA TFT (450 nit typical)
Resolution	640 x 480
Colour	16-bit (65,536)
Screen Memory	27MB
User-Programmable Screens	1023
Backlight	LED - 30,000 hour life
Screen Update Rate	User configurable within the scan time. (perceived as instantaneous in many cases)


Connectivity	
Serial Ports	1 RS-232 & 1 RS-485 on first modular jack (MJ1/2) 1 RS-232 or 1 RS-485 on second Modular Jack (MJ3)
USB mini-B	USB 2.0 (480MHz) Programming & Data Access
USB A	USB 2.0 (480MHz) for USB FLASH Drives (up to 2TB)
CAN	Remote I/O, Peer-to-Peer Comms, i3 Configurator
Ethernet	10/100MB (Auto-MDX), Modbus TCP, HTTP, FTP, SMTP, i3 Configurator, Ethernet IP
Remote I/O	IOS, Smart IO, iSmart
Removable Memory	MicroSD (support for 32GB max) Application updates, Datalogging, more

2
1
500kHz each
32-bits each
Supported
Quadrature
Frequency Measurement
r

Dimensions & Panel Cutout




*Up to six mA/V In, RTD/TC, and mA/V Out



$oldsymbol{i}^3$ CX Intelligent Control Station

IMO

Ports & Connectors



DC Input / Frame

Torque rating: 4.5-7 Lb-in (0.50-0.78Nm)

DC- is internally connected to I/O V-, but is isolated from CAN V-

A Class 2 power supply must be used


Primary Power Port Pins			
Pin	Signal	Signal Description	
1	Ground	Frame Ground	
2	DC-	Input Power Supply Ground	
3	DC+	Input Power Supply Voltage	




MJ1/2 Independent Serial Ports

MJ1: RS-232 w/Full Handshaking MJ2: RS-485 Half-Duplex

PIN	MJ1 PINS		MJ2 I	PINS
	Signal	Direction	Signal	Direction
8	TXD	OUT	-	-
7	RXD	IN	-	-
6	0 V	Ground	0 V	Ground
5	+5V@60mA	OUT	+5V@60mA	OUT
4	RTS	OUT	-	-
3	CTS	IN	-	-
2	-	-	RX- / TX-	IN / OUT
1	-	-	RX+/TX+	IN / OUT



DIP Switches



Switch	Name	Function	Default
1	MJ3 RS485 Termination	ON = Terminated	OFF
2	M I2 Duploy	ON = Half	OFF
3	MJ3 Duplex	OFF = Full	UFF
4	MJ3 RS485 Termination	ON = Terminated	OFF

Fixed	Digital/Analog			i3CX Model		
Address I/O Function	I/O Function	10D03	10B04	20B05	13C14	10E14
	Digital Inputs	1-12	1-12	1-24	1-12	1-12
%I1	Reserved	13-32	13-31	25-31	13-31	13-31
	ESCP Alarm	n/a	32	32	32	32
%Q1	Digital Outputs	1-6	1-12	1-16	1-12	1-12
76 U I	Reserved	7-24	13-24	17-24	13-24	13-24
%AI1	Analog Inputs	1-4	1-2	1-2	1-2	1-4:33-38
70AII	Reserved	5-12	3-12	3-12	3-12	n/a
%AQ1	Reserved	n/a	1-8	1-8	1-8	1-12
/0AUT	Analog Outputs	n/a	n/a	n/a	9-10	n/a

Reserved areas maintain backward compatability with other i3 Controller models



CAN

Locking Spring-Clamp 2-Terminators Per Conductor Mounting screw torque rating: 4.5 Lb-in (0.50Nm)

SHLD and V+ pins are not internally connected to i3CX

Primary Power Port Pins				
Pin	Signal Description Directio		Direction	
1	V-	CAN Ground - Black	-	
2	CN L	CAN Data Low - Blue	IN / OUT	
3	SHLD	Shield Ground - None	-	
4	CN H	CAN Data High - White	IN / OUT	
5	V+ (NC)	No Connect - Red	-	



MJ3 Serial Port

2 multiplexed Serial Ports on One Modular Jack (8posn)

PIN	MJ3 PINS	
	Signal	Direction
8	TXD RS232	OUT
7	RXD RS232	IN
6	0 V	Ground
5	+5V@60mA	OUT
4	TX- RS485	OUT
3	TX+ RS485	OUT
2	RX- RS485	IN
1	RX+ RS485	IN

Built-in I/O

I/O is mapped into i3 Register space, in three separate areas — Digital/Analog I/O, High-Speed Counter I/O, and High-Speed Output I/O. Digital/Analog I/O location is fixed starting at 1, but the High-Speed Counter and High-Speed Output references may be mapped to any open register location. For more details on using the High-Speed Counter and High-Speed Outputs, see the i3CX User's Manual.

Default Address*	High Speed Counter Function	i3CX Models
%I1601	Status Bits	1-8
&Q1601	Command Bits	1-32
%AI0401	Accumulator 1&2	1-8
%AQ0401	Preload & Match Values	1-12

*Starting Address locations for %I, %Q, %AI & %AQ may be re-mapped by user

Default Address*	High Speed Output Function	i3CX Models
%I1617	Status Bits	1-8
&Q**	Command Bits	1-32
n/a	n/a	n/a
%AQ0421	PWM or Pulse Train Parameters	1-20

*Starting Address locations for %I & %AQ may be re-mapped by user

**Q1-Q2 are part of the Fixed I/O Map. In High Speed Output mode they can be used to initiate a Stepper/PTO Move


i^3 CX Intelligent Control Station

IMO


10B04 & 20B05 I/O Board Specifications

Digital DC Inputs	10B04	20B05	Digital DC Outputs	10B04	20B05
Inputs per Module	12 including 4 configurable HSC inputs	24 including 4 configurable HSC inputs	Outputs per Module	12 including 2 configurable PWM outputs	16 including 2 configurable PWM outputs
Commons per Module	r Module 1		Commons per Module	1	
Input Voltage Range	10-30 VDC		Output Type	Sourcing / 10 K Pull-Down	
Absolute Max Voltage	35 VDC Max		Absolute Max Voltage	28 VDC Max	
Input Impedance	10 kΩ		Output Protection	Short Circuit	
Input Current	Positive Logic	Negative Logic	Max Output Current per Point	0.5 A	
Upper Threshold	0.8mA	-1.6mA	Max Total Current	4 A Continuous	
Lower Threshold	0.3mA	-2.1mA	Max Output Supply Voltage	30 VDC	
Max Upper Threshold	8 VDC		Min Output Supply Voltage	10 VDC	
Max Lower Threshold	3 VDC		Max Voltage Drop at Rated Current	0.25V	
OFF to ON Response	1 ms		Max Inrush Current	650 mA per channel	
ON to OFF Response	1 ms		Min Load	None	
HSC Max Switching Rate	e 500 KHz each		OFF to ON Response	1 ms	
ON to OFF Response	1 ms		Output Characteristics	Current Source	ing (Pos Logic)

J1 (Orange)	Signal Name	
11	IN1	
12	IN2	
13	IN3	
14	IN4	
15	IN5	
16	IN6	
17	IN7	
18	IN8	
H1	HSC1 / IN9	
H2	HSC2 / IN10	
Н3	HSC3 / IN11	
H4	HSC4 / IN12	
A1	Analog IN1	
A2	Analog IN2	
0V	Common	



20B05 Signal Name	
IN13	
IN14	
IN15	
IN16	
IN17	
IN18	
IN19	
IN20	
IN21	
IN22	
IN23	
IN24	
Common	



J2 (Black)	10B04	20B05	
0V	Common		
V+	V+		
NC	No Connect	0UT13	
Q12	OUT12		
Q11	0UT11		
Q10	OUT10		
Q9	OUT9		
Q8	OUT8		
Q7	OUT7		
Q6	OUT6		
Q5	OUT5		
Q4	OUT4		
Q3	OUT3		
Q2	OUT2 / PWM2		
Q1	OUT1 / PWM1		

J4 (Orange)

Q16

Q15

Q14

0UT14

0010	+ toap +
T2 / PWM2	- +
T1 / PWM1	
	J4 Orang Positive Lo Digital O
20B05	
OUT16	10-30VDC
0UT15	

J2 Black Positive Logic Digital Out		
10 - 30MDC	0V	
	V+	
- toad +	Q13	
- LOAD +	Q12	
+ toad +	Q11	
+ toan +	Q10	
+ toad +	Q9	
- +	Q8	
+ toan +	Q7	
- LOAD +	Q6	
- +	Q5	
tOAD +	Q4	
- toad +	Q3	
- +	Q2	
- +	Q1	



Jumper Setting Details	JP1 Digital DC Inputs		
J4	F	Positive Logic	Negative Logic
JP1		Default	
J1 JP3 J2		JP3 Ana	log Inputs
9 B		20mA	10VDC
	A1 1	2	A1 1 🗆 🗆 :
J3	A2 3	4	A2 3 🗆 🗆 '
Location of I/O jumpers (JP1 & JP3) and wiring connectors (J1, J2, J3 & J4) with back	Note:	The Module Setup configuration must match the selected I/O (JP) jumper settings	
cover removed.	Note:	When using JP2 (A1-A2), each channel can be independently configured.	

Note: 10B04 uses J1 and J2 only 20B05 uses J1, J2, J3 and J4

* Please refer to medium analog resolution specification overleaf.

$oldsymbol{i}^3$ CX Intelligent Control Station



Analog Inputs, Medium Resolution					
Number of Channels	4	Input Ranges	0-10 VDC, 0-20 mA, 4-20 mA		
Safe Input Voltage Range	-0.5V to 12V	Input Impedance (clamped @ -0.5VDC to 12VDC)	Current Mode: Voltage Mode: $100~\Omega$ $500~k~\Omega$		
Nominal Resolution	10 Bits	%Al Full Scale	32,000		
Max Over Current	35 mA	Conversion Speed	Once per Ladder Scan		
Max Error at 25°C (excluding zero) Adjusting filtering may tighten	4-20 mA 1.00% of FS 0-20 mA 1.00% of FS 0-10 VDC 1.50% of FS	Filtering	160 Hz hash (noise) filter 1-128 scan digital running average filter		

Safety

WARNING: Battery may explode if mistreated. Do not recharge, disassemble or dispose of in fire.

WARNING: EXPLOSION HAZARD - BATTERIES MUST ONLY BE CHANGED IN AN AREA KNOWN TO BE NON-HAZARDOUS

This equipment is suitable for use in Class 1, Division 2, Groups A, B, C and D or Non-hazardous locations only.

FOR U.S. & CANADA ONLY

Power input and output (I/O) wiring must be in accordance with Class 1, Division 2 wiring methods of the National Electric Code, NFPA70 for installations in the U.S. or as specified in Section 18-1J2 of the Canadian Electric Code for installations within Canada and in accordance with the authority having jurisdiction.

WARNING: EXPLOSION HAZARD - Do not disconect equipment unless power has been switched off or the area is known to be non-hazardous.

WARNING: EXPLOSION HAZARD - Substitution of components may impair suitability for Class 1, Division 2.

Digital outputs shall be supplied from the same source as the i3 Controller.

WARNING: Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.

WARNING: To avoid the risk of electric shock or burns, always connects the earth ground before making any other connections.

WARNING: To reduce the risk of fire, electrical shock, or physical injury it is strongly recommended to fuse all Power Sources connected to the i3 controller. Be sure to locate fuses as close to the source as possible.

WARNING: Replace fuse with the same type and rating to provide protection against risk of fire and shock hazards.

WARNING: In the event of repeated failure, do not replace the fuse again as a repeated failure indicates a defective condition that will not clear by replacing the fuse.

Jumpers on connector JP1 and others shall not be removed or replaced while the circuit is live unless the area is known to be free of ignitable concentrations of flammable gases or vapours.

Common Cause of Analog Input Tranzorb Failure

If a 4-20mA circuit is initially wired with loop power, but without a load, the Analog Input could see 24VDC. This is higher than the rating of the tranzorb. This can be solved by NOT connecting loop power prior to load connection, or by installing a low-cost PTC in series between the load and Analog Input.

